SERVICE PARTS LIST



SPECIFY CATALOG NO. AND SERIAL NO. WHEN ORDERING PARTS REVISED BULLETIN DATE May 2019 M18™ FUEL™ ONE KEY™ 1/2" Square Impact Wrench WIRING INSTRUCTION STARTING 2863-20 CATALOG NO. **J39A** See Pages 2 and 3 SERIAL NO




FIG.	PART NO.	DESCRIPTION OF PART	NO. REQ.
13	32-62-0700	Planet Gear	(3)
14	44-60-1960	Planet Gear Pin	(3)
15	45-88-2020	Washer	(1)
16	02-04-0375	Ball Bearing	(1)
17	43-44-0011	Gasket	(1)
18	34-60-5002	Retaining Ring	(1)
34	06-82-4001	M4 x 22mm Pan Hd. ST T-20 Screw	(4)
35	06-82-4002	M4 x 35mm Pan Hd. ST T-20 Screw	(2)
36	06-82-4003	M4 x 16mm Pan Hd. ST T-20 Screw	(5)
37		Right Housing Halve - Cover	(1)
38	45-30-0255	Rubber Slug	(4)
39		Left Housing Halve - Support	(1)
40	45-24-0022	Forward/Reverse Shuttle	(1)
41		3V Coin Cell Battery (CR 2032)	(1)
42	22-09-2757	Coin Cell Board Assembly	(1)
43	31-15-0011	Coin Cell Cover	(1)
44	05-81-1100	M2.6 x 6mm ST Phillips Screw	(2)
49	12-20-2810	Service Nameplate	(1)
100	42-55-0063	Blow Molded Carrying Case	(1)
101	31-44-0053	Housing Assembly	(1)
102	45-24-0061	Speed Selector Assembly	(1)
110	16-01-0400	Rotor/End Cap Assembly	(1)
111	14-20-0064	Electronics Assembly	(1)
112	14-30-0019	Front Gear Case Assembly	(1)
113	42-06-2760	1/2" Square Drive Anvil Assembly	(1)


FIG.	PART NO.	DESCRIPTION OF PART	NO. REQ.
114	14-46-2820	Gear Box Assembly	(1)
115	32-65-0375	Ring Gear	(1)
116	44-66-0006	Rear Gear Case	(1)
117	49-16-2767	Rubber Boot, Accessory	(1)
120	43-81-0310	Hammer	(1)
121	36-10-0910	Camshaft	(1)

LUBRICATION

Use Type 'J' Grease, No. 49-08-4220 (1 lb. can)


NOTE: Service grease may not be compatable with grease used during manufacturing. 90-95% of the old grease must be removed prior to any new grease being added. See grease application to gear and hammering mechanism on page two.

SCREW TORQUE SPECIFICATIONS						
			SEAT TORQUE			
FIG.	PART NO.	WHERE USED	(KG/CM)	(IN/LBS)		
1	06-82-4000	Front Gear Case	36±3	31±2		
34	06-82-4004	Rotor/End Cap Assy.	16±2	14±1		
35	06-82-4002	Right Housing Halve	16±2	14±1		
36	06-82-4003	Right Housing Halve	16±2	14±1		
44	05-81-1100	Coin Cell Cover	2.5-3.5	2-3		



WIRING

Prior to installing the electronics assembly in left housing halve, PCBA Assembly must be installed in bottom cavitiy of front and rear gear case assemblies. Orient PCBA so wires can be inserted through slot in the bottom of rear gear case as shown.



With PCBA squarely and firmly seated, place gasket onto rear gear case. Install gear/hammer/anvil mechanisms in front gear case assembly. Carefully place those assemblies into and onto the rear gear case, trapping the PCBA inside.





