SPECIFICATIONS

-IMPORTANT

THE SPECIFICATIONS GIVEN IN THIS PUBLICATION DO NOT INCLUDE NORMAL MANUFACTURING TOLERANCES. THEREFORE, THIS UNIT MAY NOT MATCH THE LISTED SPECIFICATIONS EXACTLY. ALSO, THIS PRODUCT IS TESTED AND CALIBRATED UNDER CLOSELY CONTROLLED CONDITIONS, AND SOME MINOR DIFFERENCES IN PERFORMANCE CAN BE EXPECTED IF THOSE CONDITIONS ARE CHANGED.

SUPER TRADELINE / TRADELINE MODELS

SUPER TRADELINE/TRADELINE models offer features not available on TRADELINE or standard models, and are designed to replace a wide range of Honeywell and competitive models. SUPER TRADELINE/TRADELINE models are selected and packaged to provide ease of stocking and handling as well as maximum replacement value. Specifications for SUPER TRADELINE and TRADELINE models are the same as those of standard models except as noted below.

SUPER TRADELINE MODELS AVAILABLE:

L4064B Fan and Limit Controller. L4064T Fan and Limit Controller.

SUPER TRADELINE FEATURES INCLUDE:

- Universal adapters for 5/8, 3/4, and 1 in. diameter elements.
- · Wiring space for related controls.
- All TRADELINE pack features as listed below.

TRADELINE MODELS AVAILABLE:

L4064B Fan and Limit Controller.

TRADELINE FEATURES INCLUDE:

 High limit stop—adjustable, factory-set at 200 F 193 C1.

- Mounting means—surface or rigid bracket.
- Two round wiring knockouts in top and 2 slotted in bottom of case.
- 110265A Rigid Bracket, single wing with No. 8-32 setscrew.
- · Mounting screws provided.
- 123198A Push-in Screw Terminal Adapter.
- 127123 Steel Bushing with 135236 Wire Snap Ring to adapt insertion element to 1 in. [25.4 mm] hole in plenum.
- 137813 Strain Relief Bushing.
- TRADELINE pack with cross reference label and special instruction sheet.

STANDARD MODELS -

MODELS: L4064A—F,J,R,T Fan and Limit Controllers. See Tables I and II. Table I gives specifications in

Fahrenheit degrees. Table II gives specifications in Celsius degrees.

TABLE I - L4064 SPECIFICATIONS IN DEGREES FAHRENHEIT.

MODEL		MANUAL FAN SWITCH	SCALE RANGE	FAN-ON		FAN-OFF		HIGH LIMIT	
	SENSING ELEMENT			RANGE	FACTORY- SET	RANGE	FACTORY- SET	RANGE	FACTORY- SET
L4064A	Helical bimetal	No							
L4064B		Yes	50	65		50		100	
L4064C	Flat, spiral bimetal	No	to	to	125	to	100	to	250
L4064D		Yes	250	215	125	200	100	250	250
L4064E		No	-			200		250	
L4064F		Yes							
L4064J	Helical bimetal	No	80 to	100 to		80 to		150 to	
L4064R		Yes	350	305		290		350	
Standard L4064T		No	50	None fan		50		100	
SUPER TRADELINE		Yes	to	comes on 90 sec.		to		to	
L4064T		r es	250	after call for heat		200		250	

(continued on page 3)

ORDERING INFORMATION

WHEN PURCHASING REPLACEMENT AND MODERNIZATION PRODUCTS FROM YOUR TRADELINE WHOLESALER OR YOUR DISTRIBUTOR, REFER TO THE TRADELINE CATALOG OR PRICE SHEETS FOR COMPLETE ORDERING NUMBER, OR SPECIFY—

- 1. Order number.
- 2. Insertion depth-L4064A,B,E,F,J,R,T only.
- 3. Adjustable high limit stop, if desired (include desired set point).
- 4. Accessories, if desired.

IF YOU HAVE ADDITIONAL QUESTIONS, NEED FURTHER INFORMATION, OR WOULD LIKE TO COMMENT ON OUR PRODUCTS OR SERVICES, PLEASE WRITE OR PHONE:

- 1. YOUR LOCAL HONEYWELL RESIDENTIAL GROUP SALES OFFICE (CHECK WHITE PAGES OF PHONE DIRECTORY).
- RESIDENTIAL GROUP CUSTOMER SERVICE HONEYWELL INC., 1885 DOUGLAS DRIVE NORTH MINNEAPOLIS, MINNESOTA 55422 (612) 542-7500

(IN CANADA—HONEYWELL CONTROLS LIMITED, 740 ELLESMERE ROAD, SCARBOROUGH, ONTARIO M1P 2V9) INTERNATIONAL SALES AND SERVICE OFFICES IN ALL PRINCIPAL CITIES OF THE WORLD.

TABLE II - L4064 SPECIFICATIONS IN DEGREES CELSIUS.

MODEL		MANUAL FAN SWITCH	SCALE RANGE	FAN-ON		FAN-OFF		HIGH LIMIT	
	SENSING ELEMENT			RANGE	FACTORY- SET	RANGE	FACTORY- SET	RANGE	FACTORY SET
L4064A	Helical bimetal	No	10 to 121	18 to 102	52	10	10 to 38	38	121
L4064B		Yes							
L4064C	Flat, spiral bimetal	No						to	
L4064D		Yes				93	36	121	
L4064E		No					observations and the control of the		
L4064F		Yes							
L4064J	'Helical bimetal	No	27 to	38 to		27 to		66 to	
L4064R		Yes	177	152		143		177	
Standard L4064T		No	10	None — fan comes on 90 sec. after call for heat		10		38	
SUPER TRADELINE L4064T		Yes	to 121			to 93		to 121	

ELECTRICAL RATINGS (amperes):

	120 Vac		240) Vac	24 Vac			
	FAN	LIMIT	FAN	LIMIT	FAN	LIMIT	TIMER	
Full Load	14	8	7	4	_	440040	sarene	
Locked Rotor	84	48	42	24	_	enettine	unimeter .	
Max. Amp		-				2	.2	

Pilot Duty—2 A at 25 Vac; 0.25 A at 0.25 to 12 Vdc. Maximum Combined Connected Load—2000 VA.

HIGH LIMIT DIFFERENTIAL: 25 F [14 C].
LIMIT STOP SETTING: 150 F to 250 F [66 C to 121 C]
in 10 F [5.6 C] increments (specify when ordering).
MINIMUM SWITCH TEMPERATURE:
 L4064A,T—minus 40 F [minus 40 C].
 L4064B-F,J,R—plus 32 F [0 C].
MAXIMUM SWITCH TEMPERATURE: 190 F [88 C].
MAXIMUM ELEMENT TEMPERATURE:
 L4064A-F,T—350 F [177 C].

L4064J,R—600 F [316 C].
MOUNTING DIMENSIONS: See Fig. 1.

 $-2\frac{1}{2}$ [63.5] [6.5] [6.5] 1/4 INCH [6.5 mm] MOUNTING HOLES (2) 3 [60.4] $1\frac{29}{32}[48.6]$ $-\frac{5}{16}[8.0]$ $\lceil \frac{9}{32} [7.2] \rceil$ $-1\frac{5}{16}[33.4]$ 129250A DOUBLE WING BRACKET [25.4] 3/4 [19.1] ELEMENT THIS SLOT ON HORIZONTAL CENTER LINE 5 9 OUTER CASE 5 32 DIM. FOR [134.2] TRADELINE L4064 ONLY [57.2] (3) 1/4 INCH [58.8] [6.5 mm] SLOTS EQUALLY SPACED 1 [12.7] THIS CUTOUT DOWN 32 [8.8](4)-F 32 REQUIRES 1-9/16 INCH [39.8 mm] HOLE IN PLENUM [5.6](4) 32642A SWIVEL BRACKET [19.1] 9 16 [14.4] $-1\frac{3}{16}[30.2]$ -13138.11-3 [76.2]-[24.0] NOTE: OVERALL DEPTH IS 2 INCHES [50.8 mm] ON ALL MODELS. DIA [19.1](2) [6.35] 110265A SINGLE WING BRACKET

FIG. 1-MOUNTING DIMENSIONS IN in. [mm IN BRACKETS].

3

SETTINGS AND ADJUSTMENTS

CAUTION

When adjusting the fan and limit setting levers, hold the scaleplate dial to keep it from turning and straining the sensing element.

-IMPORTANT-

To L4064T uses a bimetal heater to turn on the fan 90 seconds after a call for heat. When the call for heat ends, the fan will continue to run until the fan-off temperature is reached. If the L4064T is used to replace an L4064A or B, the blower fan may circulate cold air until the plenum heats up. No adjustment of the fan-on time is possible.

Move the setting levers to the control points recommended by the burner or furnace manufacturer. Use gentle finger pressure.

 Move the FAN OFF setting lever to the temperature at which the fan is to stop to prevent circulation of cool air.

- 2. Move the FAN ON setting lever as follows:
 - L4064A-F—FAN ON range is from 15 F [8 C] above the FAN OFF setting to 35 F [19 C] below the LIMIT OFF setting.
 - L4064J,R—FAN ON range is from 20 F [11 C] above the FAN OFF setting to 45 F [25 C] below the LIMIT OFF setting.
 - L4064T—Move the FAN ON indicator as needed for setting the FAN OFF indicator and LIMIT indicator. The FAN ON indicator is nonfunctional on the L4064T; the bimetal heater acts to turn on the fan 90 seconds after a call for heat from the thermostat.
- 3. Move the LIMIT setting lever to the temperature at which the high limit switch is to break the burner circuit. L4064A-F,T limit range is 100 F to 250 F [55 C to 139 C]; L4064J,R limit range is 150 F to 350 F [83 C to 194 C].

MANUAL SWITCH (L4064B, D, R, T)

For constant fan operation (overriding fan setting levers), push the FAN switch button in. For fan to cycle automatically, pull button out.

OPERATION

L4064A-F,J,R—As the plenum temperature rises, the bimetal sensing element of the control warps and mechanically makes the fan contacts (at the FAN ON temperature setting). During normal operation, the call for heat ends before the LIMIT setting is reached and the fan contacts break as the plenum temperature falls and the FAN OFF setting is reached.

If the call for heat continues until the temperature in the plenum rises to the LIMIT setting, the bimetal element will mechanically break the limit contacts and de-energize the gas control circuit.

L4064T—The operation of the L4064T is the same as that of the L4064B except that this combination fan and limit control uses a bimetal heater to heat its bimetal sensing element. This heater acts to anticipate the rise in plenum temperature and turns on the fan 90 seconds after the thermostat calls for heat.

CHECKOUT

When installation is complete, turn on the power supply. Disconnect the fan at the fan motor or L4064. Set thermostat to call for heat. Burner should come on and limit controller should shut burner off when plenum temperature reaches the limit set point. Turn off power, reconnect the fan switch, turn on power and again set

thermostat to call for heat. On L4064A-F,J,R fan should come on when plenum temperature has reached fan-on setting. On L4064T, fan should come on 90 seconds after call for heat. Fan should shut off on all L4064 models when call for heat ends and plenum has cooled to fan-off setting.

Dear Customer,

We welcome your comments and suggestions for improving this publication. Your assistance is greatly appreciated and will enable us to provide better technical information for you.

Please send your comments and suggestions to: Honeywell Inc. 10400 Yellow Circle Drive

Minnetonka, Minnesota 55343 ATTN: RCC Publications Supervisor MN38-3247

HONEYWELL MINNEAPOLIS, MN 55408 INTERNATIONAL Sales Offices in all principal cities of the world. Manufacturing in Australia, Canada, Finland, France, Germany, Japan, Mexico, Netherlands, Spain, Taiwan, United Kingdom, U.S.A.

PRINTED IN U.S.A.