



Work Instruction: Install ROXOR Hood Stripe

ROXOR Hood Stripe (P/N 2302GUA00101N)

WORK INSTRUCTION OVERVIEW

⚠ WARNING

- DO NOT ATTEMPT THIS PROCEDURE IF YOU DO NOT HAVE PROPER TOOLS, TRAINING, AND FACILITIES.
- To protect bystanders and the service technician(s), shut vehicle off, remove the Ignition Key and secure vehicle to prevent unintended movement.


TOOLS REQUIRED

<ul style="list-style-type: none"> ◦ Razor Blades ◦ Spray Bottle (80% Water - 20% Isopropyl Alcohol) 	<ul style="list-style-type: none"> ◦ Squeegee ◦ Paper Towel
--	---

TORQUE SPECIFICATION

None Required

MATTE BLACK HOOD STRIPE

Kit Component	Description	Qty
	ROXOR Matte Black Hood Stripe P/N# - 2302GUA00101N	1

INSTALLATION PROCEDURE

1. Prepare the surface by wiping with a clean cloth and water / isopropyl alcohol mixture.
2. Install (1) Matte Black Hood Stripe. Align to center of hood, approximately 3/8" from rear edge of hood.

