



Smart Card Reader

MF1-H

Installation Guide



International Currency Technologies Corp.

Use of Materials Limitations

International Currency Technologies Corporation (ICT) all rights reserved.

All materials contained are the copyrighted property of ICT.

All trademarks, service marks, and trade names are proprietary to ICT.

ICT reserves the right at all times to disclose or to modify any information as ICT deems necessary to satisfy any applicable law, regulation, legal process or governmental request, or to edit, refuse to post or to remove any information or materials, in whole or in part, in ICT's sole discretion.

Contents

1. Introduction	
1-1. Features.....	2
1-2. Specifications.....	2
1-3. Dimension.....	3
1-4. Function Define.....	4
2. LCD Idling Function.....	5
3. Transfer Credit function.....	7
4. Setup.....	10
5. Set C & M & T Card Parameter	
5-1. How to into setting mode?.....	14
6. Other Error Message.....	17
7. USB Charger Demonstration.....	18

1. Introduction


1-1. Features

- MF1-H Top-up device.
- Build-in backlight for easy read.
- Build-in memory to store up to 100,000 transaction for audit.
- PC tool synchronize transaction data, generate report.
- Build-in lithium battery.
- Mini USB charger battery.

1-2. Specification

Power	5VDC
Connector Port	Mini USB
Card Type	G card for User S Card for Supervisor
Synchronize	USB to PC Tool


1-3. Dimension



Unit : mm [inch]

1-3 FIG.01


1-4. Function Define




1-4 FIG.01

2. LCD Idling Function


Step 1. Power up (Turn ON Power switch)




Default "0000"




Step 2. Idling (No Cards insert)



Step 3. Insert S card




Step 4. Input S card Password




8 digital number.

Step 5. S Card password correct.




Step 6. Insert G Card to Transfer Credit function.



3. Transfer Credit function

Step 1. Choice Function



Step 2. Input 4 Digit Transfer Password

Password?


Step 3. Input Transfer Credit

How Much?


 **Remove Card direct back to Idling.**

Step 4. Transfer Credit Confirm.

4.1. S card Transfer to G card.



4.2. G Card Remain Credit



 **Remove Card direct back to Idling.**

Step 5. Transfer Successful

5.1. Transfer Successful.

```
Source=      xxxxxxxx
Deduct(-)=   xxxxxxxx
User =       xxxxxxxx
Processing.....Done
```

5.2. Transfer fail

```
Source=      xxxxxxxx
Deduct(-)=   xxxxxxxx
User =       xxxxxxxx
Processing.....NG
```



If not indicate credit result. Please don't remove card.

4. Setup

- SETUP MODE**
1. Password
 2. Load Store ID
 3. Clock.
 4. Show Version



4 FIG.01

(1). Password

A. Setup Password.

1. Machine PW
2. Transfer PW



4 FIG.02

B. Input current Password.

Old Password

C. Input New password.

New Password

D. Input New Password again.





E. Password setting Finish.





(2). Load Store ID

A. Waiting Insert C card to S slot.



4 FIG.03

B. Setting Finish.




4 FIG.04

MF 1 - H

(3). Clock

A. Set Year

20YY/MM/DD	hh : mm
2015/ /	:
Set Year	



4 FIG.05

B. Set Month

20YY/MM/DD	hh : mm
2015/07/	:
Set Month	



4 FIG.06

C. Set Date

20YY/MM/DD	hh : mm
2015/07/08	:
Set Date	

D. Set Hour

20YY/MM/DD	hh : mm
2015/ 07 /08	10 :
Set Hour	

E. Set Minute

20YY/MM/DD hh : mm
2015/07/08 10 : 00
Set Minute

F. Confirm

20YY/MM/DD hh : mm
2015/07/08 10 : 00
Confirm? (Enter)



4 FIG.07

Enter

G. Setting Finish.

Clock has been
changed

(4). Show Version

SW VERSION :
HDRF00A C614
Serial Number :
000000000000

Show Version




4 FIG.08


5. Set C & M & T Card Parameter

5-1. How to into setting mode?


Step 1. Idling state insert C card



Step 2. Input C card ID




Step 3. Input C card Password



8 digital number.

Step 4. Card setup mean




4.1. Set Dest ID & PW



Set Dest ID & PW




5-1 FIG.03




5-1 FIG.04




4.2. Confirm Renew in down slot card ID and PW



4.3. Finish (Take out card)



4.4. Continue insert card/ Remove TOP slot cad to back menu.



6. Other Error Message

Source Card
Type Error
Take out card

Solution

Please insert correct S card into
S slot.

Dest Card
Type Error
Take out card

Solution

Please insert correct G card into
G slot.

Source Card
Data Error
Take out card

Solution

S card data error or damage.
Please change S card.

Dest Card
Data Error
Take out card

Solution

G card data error or damage.
Please change G card.

 MARIO★LAND

No Power

Solution


Please Using Mini USB cable
charger Battery,
(Refer to page 18)



If the error can not be solved after corrective actions or happen again, please contact ICT for technical support.

7. USB Charger Demonstration

Cable no. "WEL-RG809" connect to PC USB port into Charger Mode.





Taiwan

International Currency Technologies Corporation

No.28, Ln. 15, Sec. 6, Minquan E. Rd., Neihu Dist., Taipei City 114, Taiwan

sales@ictgroup.com.tw (For Sales)

fae@ictgroup.com.tw (For Customer Service)

Website: www.ictgroup.com.tw

