



Index No.	Parts No.	Description	Required
1	AB1400001	Motor Housing	1
2	AB0840016	Spring Pin	1
3	AB0920002	Wire-Thread Insert	4
4	AB0800121	Washer	1
5	AB1610007	Throttle Valve	1
6	AB0810005	Spring	1
7	AB1800009	Exhaust Deflector	1
8	AB0800011	Washer	1
9	AB0850058	"O"Ring	1
10	AB1800017	Air Strainer	1
11	AB1800005	Reverse Valve Bushing	1
12	AB0840173	Throttle Valve Pin	1
13	AB1800019	Control Valve	1
14	AB1300106	Reverse Valve	1
15	AB0810021	Spring	4
16	AB0870002	Steel Ball	2
17	AB1800006	Reverse Valve Bushing	1
18	AB0880026	Screw	1
19	AB1400010	Control Valve Knob	1
20	AB0840012	Spring Pin	2
21	AB1400009	Trigger	1
22	AB0840063	Spring Pin	1
23	AB0890058	Housing Cover Packing	1
24	AB1400006	Housing Cover	1
25	AB0880008	Screw	8
26	AB0890048	End Plate Gasket	1
27	AB0860003	Bearing	1
28	AB1300104	Rear End Plate	1
29	AB0840076	Pin	2

Index No.	Parts No.	Description	Required
30	AB1300004	Liner	1
31	AB1300108	Vane	6
32	AB1300103	Rotor	1
33	AB1300105	Front End Plate	1
34	AB0800105	Washer	1
35	AB1900010	Hammer Frame	1
36	AB1610030	Hammer	2
37	AB0840093	Pin	2
38	AB1900009	Anvil Shank	1
39	AB0850003	"O"Ring	1
40	AB0810006	Circlet	1
41	AB1800035	Shank Bushing	1
42	AB1300102	Clutch Housing	1
43	AB0800007	Washer	8
44	AB0870001	Steel Ball	2
45	AB0840018	Spring Pin	1
46	AB0860026	Bearing	1
47	AB0880083	Screw	2
48	AB0840097	Spring Pin	1
AW-130PL			
38	AB1900022	Anvil Shank	1
AW-130PL-2.5			
38	AB1900023	Anvil Shank	1
AW-130P-1/A W-130PL-1/A W-130PL-2.5-1			
10	AB1800037	Air Strainer	1
AW-130P-2/A W-130PL-2/A W-130PL-2.5-2			
10	AB1800038	Air Strainer	1