




FIG.	PART NO.	DESCRIPTION OF PART	NO. REQ.
90	10-22-1027	Tri-lingual Warning Label (Not Shown) Located on Tube	(1)
91	10-22-1028	Bi-lingual Warning Label (Not Shown) Located on Tube	(1)
92	10-22-1029	Multi-Symbol Warning Label (Not Shown) Located on Hand Guard	(1)
93	-----	'Place Handle Here' Label (Not Shown) Located on Tube	(1)

FIG.	PART NO.	DESCRIPTION OF PART	NO. REQ.
48	-----	Hand Guard Bottom Clamp	(1)
49	-----	Hand Guard	(1)
50	28-20-0108	Gearcase Cover	(1)
51	-----	Bevel Internal Retaining Ring	(1)
52	-----	6T Splined Coupler	(1)
53	45-06-0108	Felt Seal	(1)
54	43-44-0048	Gearcase Gasket	(1)
56	-----	Bevel Pinion	(1)
57	-----	Ball Bearing	(2)
58	-----	Ball Bearing	(1)
59	-----	Bottom Gearcase Housing	(1)
60	-----	Top Gearcase Housing	(1)
61	06-57-0625	Nylon Insert Lock Nut	(2)
62	-----	Ball Bearing	(1)
63	31-86-0045	Bevel C-Ring	(1)
64	32-05-0042	Bevel Gear	(1)
65	36-17-0022	Crank Shaft	(1)
66	05-78-0019	M5 x 25mm Pan Hd. T-25 Machine Screw	(2)
67	42-40-0123	Bushing	(2)
68	-----	Blade Assembly	(1)
69	-----	Retaining Sleeve	(1)
70	-----	E-Ring	(1)
71	45-88-0885	Flat Washer	(1)
72	-----	Drive Shaft	(1)
73	-----	Extruded Sleeve	(1)
74	05-74-0015	M6 x 21.5mm Cap Hd. T-30 Machine Screw	(1)
75	45-56-0011	Shoulder Strap Mounting Band	(1)
76	44-66-0039	Shoulder Strap Mounting Plate	(1)
77	43-74-0116	Shoulder Strap	(1)
78	31-44-0408	Bail Handle	(1)
79	-----	Hedge Trimmer Tube	(1)
81	05-59-8571	M5 Accorn Nut	(2)
82	-----	Blade Tip Guard	(1)
83	42-40-6478	Bushing	(2)
84	45-88-1457	Flat Washer	(2)
85	45-04-9155	M5 x 21mm Pan Hd. T-25 Screw	(2)
86	-----	M4 Hex Nut	(1)
87	-----	M4 x 6mm Pan Hd. T-20 Machine Screw	(1)
102	14-30-6407	Gearcase Service Kit	(1)
103	14-73-5574	Drive Shaft Service Assembly	(1)
104	42-26-5271	Blade Service Kit	(1)
107	43-74-3315	Harness Hook Service Kit	(1)
110	14-75-0661	Retaining Sleeve Service Assembly	(1)
111	14-34-8122	Bail Handle Service Kit	(1)
112	43-54-1741	Hand Guard Service Kit	(1)
113	14-46-6784	Blade Tip Service Kit	(1)





FIG.	PART NO.	DESCRIPTION OF PART	NO. REQ.
1	28-28-0053	Bail Handle Plate	(2)
2	05-74-0242	M6 x 25mm Pan Hd. T-30 Machine Screw	(2)
25	05-78-0029	M5 x 8mm Pan Hd. T-25 Machine Screw	(2)
26	05-78-0033	M5 x 20mm Pan Hd. T-25 Machine Screw	(10)
44	05-85-0080	M8 x 8mm Hex Hd. T-25 Machine Screw	(1)
45	44-22-0050	277 Red Loctite	(1)
46	05-55-0019	Hex Nut	(2)
47	49-62-0018	Blade Sheath	(1)