


PARTS BREAKDOWN

6-759A



PARTS LIST

Index #	Part #	Description	Qty.	Index #	Part #	Description	Qty.
1	32201	Housing	1	22	32222	Spindle Collar	1
2	32202	Throttle Valve Bushing	1	23	32223	Front End Plate	1
3	32203	O-ring	2	24	21417	Ball Bearing	2
4	32204	O-ring	1	25	32225	Bevel Gear	1
5	32205	O-ring	1	26	32226	Clamp Nut	1
6	32206	Throttle Pin	1	27	32227	Housing Cap	1
7	32207	Spring	1	28	32228	Angle Housing (incl. # 30)	1
8	32208	Air Regulator	1	29	32229	Bevel Gear	1
9	32209	O-ring	1	30	32230	Flush Type Grease Fitting	1
10	32210	O-ring	1	31	32231	Clamp Nut	1
11	32211	Valve Plug	1	32	32232	Chuck Spindle	1
12	32212	Safety Throttle Lever	1	33	32233	Woodruff Key	1
13	32213	Pin	1	34	32234A	Collet (1/4")	1
14	32214	Hose Adaptor	1		32234B	Collet (1/8")—opt.	
15	32215	O-ring 32209	1	35	32235	Collet Nut	1
16	106A12	Ball Bearing 30516	2	36	32236	Spanner Wrench 12/17mm	2
17	32217	Rear End Plate	1	37	32237	Muffler	1
18	32218	Rotor	1				
19	32219	Rotor Blade	4				
20	32220	Steel Ball	3				
21	32221	Cylinder	1				

AG 2-25-05

Rev. 3/16/01

PLEASE REVIEW ALL WARNING INSTRUCTIONS PRIOR TO OPERATION. SAVE THIS MANUAL FOR FUTURE REFERENCE.