


MODEL UT 8792 Jitterbug Sander



Parts List

Ref. No.	Description	Part No.
1	Lever	9102101
2	Rubber grip	9102102
3	Grip screw (4)	9102103
4	Body	9102148
5	Lever pin	9102106
6	Lever retainer	9102107
7	Retaining ring (2)	9102149
8	O-Ring	9102150
9	Speed regulator	9102151
10	Muffer	9102111
11	Spring	9102112
12	O-Ring	9102113
13	Plunger	9102114
14	Retaining ring	9102115
15	Ball bearing (2)	9102116
16	End plate (2)	9102117
17	Cylinder	9102118
18	Balance	9102119
19	Rotor	9102120
20	Rotor blade (4)	9102121
21	Rotor shaft	9102122
22	Key	9102123
23	Gasket	9102124

Ref. No.	Description	Part No.
24	Base	9102152
25	Mount screw (8)	9102126
26	Spring washer (10)	9102127
27	Rubber post (4)	9102128
28	Cap screw (2)	9102129
29	Cap screw (2)	9102130
30	Balancer lock screw	9102131
31	Nut (12)	9102132
32	Screw with O-Ring	9102133
33	Bearing housing	9102134
34	Screw	9102135
35	Ball bearing	9102136
36	Bearing plate	9102137
37	Washer	9102138
38	Paper clamp (2)	9102139
39	Screw (12)	9102140
40	Inlet	9102141
41	Shoe plate	9102142
42	Sanding pad	9102143
43	Muffer element	9102144
44	Spring pin	9102146
45	O-Ring	9102147