

Models:

10710 - 5" Pad, 3/16" Orbit, Non-Vac
10712 - 5" Pad, 3/16" Orbit, Vac-Ready
10720 - 6" Pad, 3/16" Orbit, Non-Vac
10722 - 6" Pad, 3/16" Orbit, Vac-Ready
10724 - 6" Pad, 3/16" Orbit, Central Vac

10730 - 5" Pad, 3/8" Orbit, Non-Vac
10731 - 5" Pad, 3/8" Orbit, Vac-Ready
10733 - 6" Pad, 3/8" Orbit, Non-Vac
10734 - 6" Pad, 3/8" Orbit, Vac-Ready
10735 - 6" Pad, 3/8" Orbit, Central Vac

5" & 6" 2-Hand Random Orbital Sander

12,000 RPM Air Motor and Machine Parts

⚠ WARNING

Always operate, inspect and maintain this tool in accordance with the Safety Code for portable air tools (ANSI B186.1) and any other applicable safety codes and regulations. Please refer to Dynabrade's Warning/Safety Operating Instructions for more complete safety information.

Index Key

No.	Part #	Description
1		Sanding Pad: See Chart
2	57069	Balancer Shaft
3	95630	Snap Ring
4	95628	Bearing Shield
5	56053	Bearing Seal
6	56052	Bearing
7		Motor Shaft Balancer
	57364	5", 3/16" Orbit
	56687	5", 3/8" Orbit
	57365	6", 3/16" Orbit
	56688	6", 3/8" Orbit
8	54673	Key
9	56046	Lock Ring
10	02695	Bearing
11	54630	Front Bearing Plate
12	54705	Rotor/Blade Set (5/pkg.)
13	56595	Cylinder Assembly (Includes: 95865 Pin)
14	01020	O-Ring
15	54629	Rear Bearing Plate
16	01206	Bearing
17	95626	Retaining Ring
18		Shroud
	57369	Lip Seal Shroud
	57737	6" Vacuum Shroud
19		Housing Assembly: See Chart (Includes: 13160 Housing Grip)
20	95627	Pin
21	56582	Safety Throttle Lever
22	98459	O-Ring
23	56579	Valve Stem
24	56578	Speed Regulator
25	01025	O-Ring (3)
26	56598	Seal
27	51944	Tip Valve
28	51943	Spring
29	56586*	Vacuum Plug
30	56469	Exhaust Gasket
31	96459	O-Ring
32	56468	Handle Housing Assy. (Includes 51938 Screen)
33	96469	Screw (2)
34	96454	Screw (2)
35	56597*	Muffler
36	56596*	Muffler Clip

***Specific Components for Models:**

5", 6" Non-Vacuum
 6" Central Vacuum

