

Dynabug "Model T"

Vacuum Sander

Models:

10485 — Vinyl-Face Pad

10487 — Hook-Face Pad


Air Motor and Machine Parts



Always operate, inspect and maintain this tool in accordance with the Safety Code for portable air tools (ANSI B186.1) and any other applicable safety codes and regulations. Please refer to Dynabrade's Warning/Safety Operating Instructions for more complete safety information.

Index Key

No.	Part #	Description
1	53856	Throttle Lever
2	53861	Housing
3	57988	Inlet Hose Assembly
4	12156	O-Ring
5	96492	Button Head Screws (4)
6	57982	Clip Retainer
7	96493	Set Screw (3)
8	57971	Vac Base Plate
9	57942	Vacuum Tube
10	57981	Turbine Wheel Assembly
11	97121	O-Ring
12	57983	Base Plate Door
13	57979	Motor Shaft
14	53858	Vacuum Plate Assembly
15	95405	Button Head Screw (4)
16	56285	Hook Pad
	56286	Vinly Pad
17	95979	Pin
18	53863	Gasket
19	53852	Plate Seal
20	01464	Seal
21	01472	Tip Valve
22	01468	Spring
23	01494	Inlet Bushing
24	57093	Vacuum Adapter
25	57066	Muffler Body
26	56027	Muffler Insert (2)
27	56028	Muffler Cap
28	95697	Snap Ring
29	01025	O-Ring
30	53857	Valve Stem
31	57064	Speed Regulator



KEY

- G** Grease: **G₁** = Lubriplate 630 AA
- A** Adhesive: **A₂** = Loctite #271
A₆ = Loctite #380
A₈ = Loctite #567
- T** Torque: **N•m** x 8.85 = **in. - lbs.**