




EXPLODED TOOL PARTS DIAGRAM



PLEASE REVIEW ALL WARNING INSTRUCTIONS PRIOR TO OPERATION. SAVE THIS MANUAL FOR FUTURE REFERENCE.



TOOL PARTS LIST

REF#	PART#	DESCRIPTION	QTY
1	RS1201	REGULATOR SET	1
2	RS288304	SNAP RING	1
3	RS387206	VALVE STEM SET	1
4	RS15407	AIR INLET	1
5	RS1205	EXHAUST SLEEVE SET	1
6	RS588005	MUFFLER	1
7	RS588006	VALVE SET	1
8	RS1208	PROTECTING RUBBER	1
9	RS29015	HOUSING	1
10	RS71011	SAFETY THROTTLE	1
11	RS820R11	SPRING PIN	1
12	RS21114	BEARING (626ZZ)	1
13	RS15419B	REAR PLATE	1
14	RS850XLR22	ROTOR BLADE (each)	4
15	RS1215	ROTOR	1
16	RS1216	CYLINDER SET	1
17	RS1217	BEARING SPACER	1
18	RS1218	FRONT PLATE	1
19	RS10920	BEARING (6000ZZ)	1
20	RS1220	BEVEL GEAR	1
21	RS29128	NUT	1
22	RS850XLR33	CLAMP NUT	1
23	RS1223	HEAD SET	1
24	RS47224	WASHER	1
25	RS1225	BEVEL GEAR SET	1

REF#	PART#	DESCRIPTION	QTY
26	RS850XLR41	BEARING (each)	2
27	RS1227	SCREW (each)	2
28	RS1228	O-RING	1
29	RS1229	HEAD GUARD SET	1
30	RS47230	SCREW (each)	8
31	RS710132	NUT SET	1
32	RS1232	LEAF SPRING	1
33	RS1233	ATTACHMENT SUPPORT	1
34	RS1234	LEAF SPRING	1
35	RS1235	SCREW	1
36	RS1236	BUTTON	1
37	RS1237	BUTTON SHAFT	1
38	RS1238	BUTTON	1
39	RS1239	SCREW	1
40	RS1240	ATTACHMENT	1
41	RS1241	WASHER SET	1
42	RS1242	DRIVE SHAFT	1
43	RS1243	HOLDER CAP SET	1
44	RS103949	HANDLE	1
45		6" RECIP. SAW BLADE (14T)	1
46		9" RECIP. SAW BLADESAW (10/14T)	1
N/S	RSCAS12WL	WARNING LABEL	1

PLEASE REVIEW ALL WARNING INSTRUCTIONS PRIOR TO OPERATION. SAVE THIS MANUAL FOR FUTURE REFERENCE.