



**Astro Pneumatic  
Tool Company**

372 Old US Highway 52 South  
Mount Airy, NC 27030

Model:


**PRN1**

Product Type:

**3/8" CAPACITY PNEUMATIC RIVET  
NUT SETTING KIT - METRIC & SAE**

Call 1.800.221.9705 for questions concerning performance of the product  
or other inquiries.

## PARTS BREAKDOWN





**Astro Pneumatic  
Tool Company**

372 Old US Highway 52 South  
Mount Airy, NC 27030

Model:

**PRN1**

Product Type:

**3/8" CAPACITY PNEUMATIC RIVET  
NUT SETTING KIT - METRIC & SAE**

Call 1.800.221.9705 for questions concerning performance of the product or other inquiries.

**Parts List**

Index	Part No.	Description	Qty
1	PRN1-A01A	Nosepiece, M4	1
	PRN1-A01B	Nosepiece, M5	1
	PRN1-A01C	Nosepiece, M6	1
	PRN1-A01D	Nosepiece, M8	1
	PRN1-A01E	Nosepiece, M10	1
	PRN1-A01F	Nosepiece, 1/4	1
	PRN1-A01G	Nosepiece, 5/16	1
	PRN1-A01H	Nosepiece, 3/8	1
2	PRN1-A02	Nose Nut	1
3	PRN1-A03	Stroke Adaptor Cover	1
4	PRN1-A04	Connector Housing	1
5	PRN1-A05	Jaw Case, Rear	1
6	PRN1-A06A	Screw Mandrel (M4)	1
	PRN1-A06B	Screw Mandrel (M5)	1
	PRN1-A06C	Screw Mandrel (M6)	1
	PRN1-A06D	Screw Mandrel (M8)	1
	PRN1-A06E	Screw Mandrel (M10)	1
	PRN1-A06F	Screw Mandrel (1/4)	1
	PRN1-A06G	Screw Mandrel (5/16)	1
	PRN1-A06H	Screw Mandrel (3/8)	1
7	PRN1-A07	Spindle Guide	1
8	PRN1-A08	E Ring	1
9	PRN1-A09	Return Tube	1
10	PRN1-A10	Lock Nut	1
11	PRN1-A11	O Ring	2
12	PRN1-A12	Backup Ring	1
13	PRN1-A13	Frame	1
14	PRN1-A14	Piston	1
15	PRN1-A15	O Ring	1
16	PRN1-A16	Backup Ring	1
17	PRN1-A17	Piston Ring	1
18	PRN1-A18	Hanging Clip	1
19	PRN1-A19	O Ring	1
20	PRN1-A20	Frame Cap	1
21	PRN1-A21	Safety Cap Nut	1
22	PRN1-A22	O Ring	2

Index	Part No.	Description	Qty
23	PRN1-A23	Backup Ring	1
24	PRN1-A24	Cylinder	1
25	PRN1-A25	Rubber Cushion	1
26	PRN1-A26	Lock Nut, Frame	1
27	PRN1-A27	Stem, Air Piston	1
28	PRN1-A28	Plate, Large	1
29	PRN1-A29	Piston Ring	1
30	PRN1-A30	Washer	1
31	PRN1-A31	Spring	1
32	PRN1-A32	Lock Nut, Piston	1
33	PRN1-A33	O Ring	1
34	PRN1-A34	Cap, Cylinder	1
35	PRN1-A35	Spring Pin	1
36	PRN1-A36	Spring Pin	1
37	PRN1-A37	Pusher, Valve	1
38	PRN1-A38	Spring, Valve	1
39	PRN1-A39	Collar, Valve	1
40	PRN1-A40	O Ring	1
41	PRN1-A41	Spring Pin	1
42	PRN1-A42	Spring Pin	1
43	PRN1-A43	Valve	1
44	PRN1-A44	Spring, Valve	1
45	PRN1-A45	O Ring	1
46	PRN1-A46	Cap, Valve	1
47	PRN1-A47	Spring Pin	2
48	PRN1-A48	Trigger	1
49	PRN1-A49	Trigger Rod	1
50	PRN1-A50	Trigger Lever	1
51	PRN1-A51	Spanner	1
52	PRN1-A52	Spanner	1
53	PRN1-A53	O Ring	1
54	5706A	brass regulator	1
55	PRN1-A55	Rubber Sleeve	1
56	PRN1-A56	Oil Pot	1
57	PRN1-A57	Nipple	1