

Item	Part #	Models	Description
18	84972	Tx51-200 (post s/n 72000)	Outlet Pipe, 25mm (Tx51-200 – post s/n 72000)
18	84804	Tx151C (pre s/n 72000)	Outlet Pipe, Combi, Tx151C (pre s/n 72000)
18	84970	Tx151C (post s/n 72000)	Outlet Pipe, Combi, Tx151C (post s/n 72000)
18	84998	Tx200C	Outlet Pipe, Combi, Tx200C
19	82539	Lx150-800, M100(V), Ti100-400, Ts80	Auto Air Vent, 1/8" NPT
19	84474	Tft60-399, Tx51-200, Tx200C	Auto Air Vent, 1/2" NPT
20	83608	Lx150-400, Tft60-399, Ts80	Flue Sensor, Dual
20	84039	Lx500-800	Flue Sensor, Dual (Commercial)
20	82660 (82660-1)	M100(V), Ti100-200	Stack Limit 1/4BSP, 190F, Dif=30 (c/w Disconnects)
20	81873	T150-200	Sensor, Stack Safety (Manual Reset)
20	84780	Tx51-200, Tx151C, Tx200C	Flue Sensor (all Tx models)
21	82765	Lx150-200, M100(V), Ti100-200, Ts80	Composite Flue Outlet Gasket Lx150-200
21	83245	T150-200	Supply/Return Pipe Assembly Non-Combi
21	84458	Tft155-250	Return Pipe, SS 1-1/4"
21	84461	Tft300-399	Return Pipe, SS 1-1/2"
21	84455	Tft60-110	Return Pipe, SS 1"
21	84810	Tx51 (pre s/n 72000)	Inlet Pipe, 18mm (Tx51 – pre s/n 72000)
21	84974	Tx51, Tx200 (post s/n 72000)	Inlet Pipe, 25mm (Tx51 & Tx200 – post s/n 72000)
21	84807	Tx81-151 (pre s/n 72000)	Inlet Pipe, 19mm, Tx81-151 (pre s/n 72000)
21	84973	Tx81-151 (post s/n 72000)	Inlet Pipe, 25mm, Tx81-151 (post s/n 72000)
21	84805	Tx151C (pre s/n 72000)	Inlet Pipe, Combi, 19mm, Tx151C (pre s/n 72000)
21	84971	Tx151C (post s/n 72000)	Inlet Pipe, Combi, 25mm, Tx151C (post s/n 72000)
21	84999	Tx200C	Inlet Pipe, Combi, 25mm, Tx200C
22	82763	Lx150-200, M100(V), Ti100-200, Ts80	Composite Flue Box
22	82373 (82373-1)	T150-200	Boiler Flue Box SS (Smoke Hood) T-series
22	84801	Tx51-200, Tx151C, Tx200C	Auto Air Vent Adapter (all Tx models)
23	82764	Lx150-200, M100(V), T150-200, Ti100-200, Ts80	Trinity Flue Box To Heat Exchanger Gasket
23	84423	Tft60-399, Tx51-200, Tx151C, Tx200C	Receptacle, 120VAC

Item	Part #	Models	Description
24	83605	Lx150-800, Ts80	Sensor, Inlet Single Lx/Ts (80-800)
24	83507	M100(V)	Flow Meter [M100(V) manufactured after 2/21/2008]
24	81896	M100(V), Combi (T/Ti)	Flow Switch FS-380, .5 activate [M100(V) manufacuted before 2/21/2008]
24	84745	Tx51-200, Tx151C, Tx200C	Inlet/Pressure Sensor (all Tx models)
25	83706	Lx150-400, Ts80	Plug, Brass 1/4" NPT Lx150-400
25	84075	Lx500-800	Plug, Brass 1/2" NPT (Commercial)
25	82659	M100(V), Ti100-200 (see bullets)	Manifold Limit 1/8" BSP (see bullets) - All non-ASME M100(V) & Ti100-150 models manufactured before 3/20/2008 - All Ti200 models manufactured before 2/1/2008
25	82992 (82992-1)	M100(V), Ti100-400 (see bullets)	Manifold Limit 1/4" NPT c/w Disconnects (see bullets) - All M100(V) models sold in US - All Ti400 models - All ASME stamped Ti100-150 models - All M100(V) & Ti100-150 models manufactured after 3/20/2008 - All Ti200 models manufactured after 2/1/2008
25	82232	T150-200	Safety Limit # 37T31 #31466, T-series
25	84546	Tft60-399	Sight Glass Assembly Tft-series
25	84913	Tx51-200, Tx151C, Tx200C	Sight Glass, c/w gasket (all Tx models)
25a	81873	T150-200	NO Flow Sensor (Manual Reset)
26	83395	Lx150 (CAN)	Heat Exchanger, Lx150 (Not Lx150E), Canada Only
26	83012	Lx150 (US), M100(V) (US), Ti100-150 (US)	Heat Exchanger ASME, Lx/Ti100-150 (Not Lx150E), US Only
26	83396	Lx150E, Lx200	Heat Exchanger ASME, Lx150E-200
26	84022	Lx300	Heat Exchanger ASME, Lx300
26	82926 (82926-1)	Lx400, Ti400	Heat Exchanger Assembly ASME, Lx/Ti400
26	84311	Lx500	Heat Exchanger ASME, Lx500
26	84312	Lx600	Heat Exchanger ASME, Lx600
26	84005	Lx700-800	Heat Exchanger ASME, Lx700-800
26	82596	M100(V) (CAN), Ti100-150 (CAN)	Heat Exchanger Kit Ti100-150 (Kit includes p/n: 83395)
26	82061 (82061-1)	T150	Heat Exchanger Assembly T150 c/w Flue Outlet Gasket
26	82062 (82061-2)	T200	Heat Exchanger Assembly T200 c/w Flue Outlet Gasket
26	84456	Tft155-250	Heat Exchanger ASME Tft155-250