

## V7E/LX7-USD6

### V7E/LX7 Option Switch Settings: 1(Pulse/ICT002U/MDB/RS232 A0)

Supported bill USD 1, 5, 10, 20, 50, 100 6bills.

V7E/LX7 dip-switch settings and functions:

FUNCTION	SW1	SW2	SW3	SW4	SW5	SW6	SW7	SW8	SW1	SW2	SW3	SW4
★ Reject USD 1	ON											
★ Accept USD 1	OFF											
★ Reject USD 5		ON										
★ Accept USD 5		OFF										
★ Reject USD 10			ON									
★ Accept USD 10			OFF									
★ Reject USD 20				ON								
★ Accept USD 20				OFF								
★ Reject USD 50 & 100					ON							
★ Accept USD 50 & 100					OFF							
★ Reserved						ON						
★ Reserved						OFF						
<b>Pulse Mode</b>	<b>Other Mode</b>											
★ Harness Disable	BA stops working when fishing						ON					
★ Harness Enable	Normal						OFF					
★ Inhibit Active High							ON					
★ Inhibit Active Low							OFF					
★ 1 pulse / USD 1								OFF	OFF			
★ 2 pulses / USD 1								ON	OFF			
★ 4 pulses / USD 1								OFF	ON			
★ 20 pulses / USD 1								ON	ON			
★ Pulse Speed	50ms LO / 50ms HI								OFF	OFF		
	60ms LO / 300ms HI								ON	OFF		
	30ms LO / 50ms HI								OFF	ON		
	150ms LO / 150ms HI								ON	ON		

★ Manufacture setting.

Note : 1. Default setting

2. Use 2nd and 3rd dip of the internal dip-switch to change different interface protocol.
3. Remove the front cover and the dip-switch in on the CPU board.  
(Please refer to "SW1" setting.)

## V7E/LX7-USD6(Pulse/ICT002U/MDB/RS232 A0)

### DIP SWITCHES SETTING : 2(Pulse)

FUNCTION	SW1	SW2	SW3	SW4
★ Pulse Normal High	ON			
Pulse Normal Low	OFF			
★ Pulse Mode		ON	OFF	
★ ICT002U Interface		OFF	ON	
MDB Interface		ON	ON	
RS232 A0 Mode		OFF	OFF	
★ Reserved				ON OFF

### DIP SWITCHES SETTING : 2(ICT002U)

FUNCTION	SW1	SW2	SW3	SW4
★ Reserved	ON			
	OFF			
Pulse Mode		ON	OFF	
★ ICT002U Interface		OFF	ON	
MDB Interface		ON	ON	
RS232 A0 Mode		OFF	OFF	
★ Reserved				ON OFF

### DIP SWITCHES SETTING : 2(MDB)

FUNCTION	SW1	SW2	SW3	SW4
★ Scaling Factor (SF) = 100 Decimal Point Position (DPP) = 2	ON			
Scaling Factor (SF) = 1 Decimal Point Position (DPP) = 0	OFF			
Pulse Mode		ON	OFF	
★ ICT002U Interface		OFF	ON	
MDB Interface		ON	ON	
RS232 A0 Mode		OFF	OFF	
★ Reserved				ON OFF

★ Manufacture setting

### Currency Assign Data

Interface Bill value	Pulse	RS232 A0	ICT002U	MDB
BV1	USD 1	USD 1	USD 1	USD 1
BV2	USD 5		USD 5	
BV3	USD 10	USD 5	USD 10	USD 5
BV4	USD 20	USD 10	USD 20	USD 10
BV5	USD 50	USD 20	USD 50	USD 20
BV6	USD 100	USD 50	USD 100	USD 50
BV7		USD 100		USD 100

### DIP SWITCHES SETTING : 2(RS232 A0)

FUNCTION	SW1	SW2	SW3	SW4
★ Reserved	ON			
	OFF			
Pulse Mode		ON	OFF	
★ ICT002U Interface		OFF	ON	
MDB Interface		ON	ON	
RS232 A0 Mode		OFF	OFF	
★ Reserved				ON OFF

★ Manufacture setting

Note : (1) Default setting.

- (2) Use 2nd and 3rd dip of the internal dip-switch to change different interface protocol.
- (3) Remove the front cover and the dip-switch in on the CPU board.  
(Please refer to "SW1" setting.)

### RS232 A0 INFORMATION

BillType Data	
Code	Denomination
1	USD 1
2	Reserved
3	USD 5
4	USD 10
5	USD 20
6	USD 50
7	USD 100