FLEXIBLE GAS PIPING DESIGN GUIDE and INSTALLATION INSTRUCTIONS



RESIDENTIAL




TABLE OF CONTENTS

Chapter 1	Introduction	
1.0	User Warnings	. 3
1.1	Listing of applicable codes and standards	. 4
	TracPipe® CounterStrike® Specification Data Sheet	. 5
Chapter 2	Description of System and Components	
2.0	Tubing	6
2.0	Fittings	. 6
	Accessories.	
	Manifolds	
	Pressure Regulators	
	Protection Devices	
0.1	Shut-off Valves	
2.1	Material Use and Limitations	
2.2	System Components	. 9
	TracPipe® CounterStrike® Flexible Gas Piping	. 9
	AutoFlare Fittings	
	TracPipe® CounterStrike® Accessories	11
Chapter 3	System Configurations and Sizing	
3.1	System Configurations	13
3.1.1	Low-Pressure Systems-Series and Parallel	13
3.1.2	Dual Pressure Systems	13
3.1.3	System Design	14
3.1.4	System Pressure Choices	14
3.2	Sizing Methods and Examples.	
3.2.1	Use of Sizing Tables	15
3.2.2	Sizing Examples-Branch Length Method	15
0.2.2	Low-Pressure Systems	
	Elevated Pressure Systems	17
	Medium Pressure Systems	
3.2.3	Sizing Hybrid Systems-Black Iron and <i>TracPipe® CounterStrike®</i> Combination	10
3.2.4	Alternate Sizing Method (Sum of Pressure Loss Calculations)	21
Chapter 4	Installation Practices	۱ ے
4.1	General Installation Practices	25
4.1		
	Debris Protection	
	Minimum Bend Radius	20
4.0	Support- Vertical Runs/ Horizontal Runs	20
4.2	Fitting Assembly	27
404	Tubing Cutting/End Preparation	27
4.2.1	Assembly Procedure - AutoFlare®	27
	Minimum Tightening Torque - AutoFlare®	
4.2.2	Assembly Procedure - <i>AutoSnap</i> ®	29
	Minimum Tightening Torque - AutoSnap®	30
	Disassembly Procedure - AutoSnap®	30
	Trouble Shooting Fitting Connections	31
	Reassembly Procedure	
4.3	Routing of Tubing	
	Clearance Holes and Notching	32
4.3.1	Concealed Locations for Fittings-General Provisions	32
4.3.2	Outdoor Installation Issues.	33
4.4	Protection	34
4.4.1	Striker Plate Requirements	34
	Spiral Metal Hose Requirements	
4.4.2	Through Wall Penetrations	
4.5	Meter Connections.	
	Termination Mounts/Meter Mounts	
	Direct Connection.	
4.6	Appliance Connections	
4.0	Termination Fittings with Appliance Connectors	
	Fixed Appliance Connections	
4.6.1	Recessed Wall Box.	
4.6.2	Pad Mounted Equipment, Roof Top Equipment	
4.6.3	Outdoor Appliances Barbeque Grills abd Gas Light Connections	
4.6.4	Fireplace Installations	4 ა
4.7	Manifold and Regulator Station	
4.0	Allowable Locations	
4.8	Pressure Regulators and Elevated Pressure Systems	
	Installation Requirements	
	Vent Limiter Option	45
	Vent Line and Sizing Requirements	
4.8.1	Adjustments	
4.8.2	Regulator Supply Pressure and Capacities Drop For Single and Multiple Appliances	46

4.8.3	Over Pressure Protection	
4.9	Underground Installations	48
4.9.1	Guidelines for Underground Installations	
4.9.2 4.9.3	TracPipe® PS-II	5
4.9.3 4.10	Electrical Bonding/Grounding	52
4.10.1	TracPipe® CounterStrike® Bonding Instruction	5-
4.10.2	When Bonding is Required	54
Chapter 5	Inspection, Repair and Replacement	
5.1	Minimum Inspection Requirements (Checklist)	56
5.2	Repair/ of Damaged Tubing	57
5.3	Repair of Damaged Jacket	. 57
Chapter 6	Pressure/Leakage Testing	
6.0	Pressure Test Procedure	58
6.1	Pressure Test for Elevated Pressure Systems	58
6.1.1	Appliance Connection Leakage Check Procedure	55
6.1.2	Regulator Performance-Optional Testing	58
Chapter 7 7.0	Sizing Tables	60
7.0	Table N-1 Low Pressure (Standard)	
	Table N-2A Low Pressure (Canada & USA 1 inch Drop).	
	Table N-2B Low Pressure (Canada & USA 1.5 inch Drop)	62
	Table N-2C Low Pressure (Canada & USA 2.0 inch Drop)	62
	Table N-2D Low Pressure (Canada & USA 2.5 inch Drop)	63
	Table N-3 Regulator Outlet (8 inches W.C.)	63
	Table N-3A 3P Regulator Oùtlet (11 inches W.C.)	64
	Table N-4 Medium Pressure	
	Table N-5 Elevated Pressure 2 PSI	
	Table N-5A Elevated Pressure 2 PSI	
	Table N-6 Elevated Pressure 5 PSI	66
	Table N-7 Elevated Pressure 10 PSI	67
	Table P-1 Propane Low Pressure (Standard).	
	Table P-1A Propane Low Pressure	68
	Table P-1B Propane	69
	Table P-2 Propane Medium Pressure	
	Table P-3 Propane Elevated Pressure 2 PSI	70
	Table P-4 Propane Elevated Pressure 5 PSI	
	Table P-5 Propane Elevated Pressure 10 PSI	
- 4	Table P-6 Propane Elevated Pressure 25 PSI	71
7.1	Pressure Drop per Foot Tables for <i>TracPipe® CounterStrike®</i> (Natural Gas)	/2
	Table PD-2A Pressure Drop per Foot for Black Iron (Natural Gas)	76
7.2	Sizing Table For Steel Pipe.	
• • • •	Table SP-1 Maximum Capacity of Pipe in Cubic Feet of Gas per Hour	
Chapter 8	Definition of Terminology	
<u>-</u>	Definitions	82
	UL Classification	
	Manufactured Housing Guidelines	
C1.1	AutoTrip® Low Pressure Excess Flow Valves for Natural Gas and Propane Service	92
C1.1	AutoTrip® LFD Series Excess Flow Valves for Meter and	32
01.2	Branch Line/Manifold Applications	93
C1.2.1	Application, and Selection of <i>AutoTrip</i> ® LFD Series Excess Flow Valves	94
C1.2.2	Gas Piping System Sizing with LFD Series Excess Flow Valves	95
C1.2.3	Methods of Sizing	95
C1.2.4	Sizing Instructions For <i>AutoTrip</i> ® LFD Series EFVs Used With <i>ConunterStrike</i> ® CSST Systems	95
C1.2.5	Sizing Instructions For <i>AutoTrip®</i> LFD Series EFVs Used With	
01.0.0	Low Pressure Steel Pipe Systems.	96
C1.2.6 C1.3	LFD Installation Instructions	
	Application and Selection of <i>AutoTrip</i> ® AFD Series Excess Flow Valves	97
C1.3.1	AFD Installation Instructions.	90
3 1.0.2	Table C.2 AutoTrip® AFD Series Appliance Connector Inlet Excess Flow Valves	90
C1.4	GasBreaker® Excess Flow Valves	. 100
AutoTrip "Lf	D" Series Capacity Charts	. 101
	TABLE N-1AT AutoTrip® TracPipe® CounterStrike® (Low Pressure System)	. 101
	TABLE N-3AT <i>AutoTrip® TracPipe® CounterStrike®</i> (Dual Pressure System-8	
	in w.c Regulator outlet @ manifold)	. 101
	TABLE N-5ĂT® <i>TracPipe® CounterStrike®</i> (2 PSI system)	
	TABLE 3.3 PROPANE— <i>TracPipe® CounterStrike® AutoTrip®</i> LFD Series Excess Flow Valves	102
	TABLE P-1AT AutoTrip ® (Propane Low Pressure System 11 in w.c.) TracPipe® CounterStrike®	. 103
	TABLE C.4 <i>TracPipe® CounterStrike® AutoTrip®</i> - GasBreaker Equivalency Chart	. 104
	FIGURE C-3 Pressure Drop across <i>TracPipe® CounterStrike® AutoTrip®</i> LFD Series	
	EFV at given Flow Rates	106

CHAPTER 1 INTRODUCTION



SECTION 1.0 — USER WARNINGS

Each installer must meet applicable qualifications in accordance with state and/or local requirements as established by the administrative authority which enforces the plumbing or mechanical codes where gas piping is installed. The TracPipe® CounterStrike® CSST (corrugated stainless steel tubing) flexible gas piping material must only be installed by a qualified person who has been sucessfully trained through the The TracPipe® CounterStrike® gas piping installation program.

This guide is updated periodically. Installers must use the most current version of the guide. Copies of updated guides are available for free at locations where **The TracPipe® CounterStrike®** is sold or online at www.tracpipe.com.

The guide must be used in conjunction with state and local building codes. Local codes will take precedence in the event of a conflict between this guide and the local code. In the absence of local codes, installation must be in accordance with the current edition of National Fuel Gas Code, ANSI Z223.1/NFPA 54, the National Standard of Canada, Natural Gas and Propane Installation Code, CSA B149.1, the Uniform Plumbing Code, the International Fuel Gas Code, the Federal Manufactured Home Construction and Safety Standards, ICC/ANSI 2.0 or the Standard on Manufactured Housing, NFPA 501, as applicable.

The jacket on the **The TracPipe® CounterStrike® CSST** shall not be removed, altered or modified in any fashion including full or partial painting or coating of the surface and the mounting of adhesively attached

plastic or paper labels without the express consent of **OmegaFlex®.**

Sound engineering principles and practices must be exercised for the proper design of fuel gas piping systems, in addition to compliance with local codes. The installation instructions and procedures contained in this Design Guide must be strictly followed. All installations must pass inspections by the local authority having jurisdiction prior to having the gas service turned on.

Only the components provided or specified by **OmegaFlex®** as part of the approved piping system are to be used in the installation.



The inter-connection of **TracPipe® CounterStrike®** tubing or **TracPipe® AutoFlare® or AutoSnap®** fittings directly with or on tubing or fittings from other CSST manufacturers is strictly prohibited and may result in a hazardous condition leading to serious bodily injury or property damage.

If this system is used or installed improperly, fire, explosion or asphyxiation may result. The installation instructions and applicable local codes must be strictly followed.







Omega Flex, Inc. 451 Creamery Way, Exton, PA 19341-2509 610-524-7272 Fax: 610-524-7282









1-800-671-8622

www.omegaflex.com

©Omega Flex Inc. 1997, 1998, 1999, 2001, 2002, 2003, 2004, 2005, 2007, 2009, 2011, 2014, 2015, 2016

OmegaFlex, TracPipe, AutoFlare, AutoTrip and CounterStrike are registered trademarks of Omega Flex, Inc.

SECTION 1.1 - APPLICABLE CODES AND STANDARDS

MODEL CODES:

NFPA-54 / ANSI Z223.1 - National Fuel Gas Code

NFPA-58 LP Gas Code

NFPA-70 National Electrical Code

NFPA-501 Manufactured Housing Code

ICC- International Fuel Gas Code

ICC- International Mechanical Code

ICC- International Residential Code

IAPMO- Uniform Plumbing Code

IAPMO- Uniform Mechanical Code

STANDARDS:

ANSI LC-1 / CSA 6.26 Standard for Fuel Gas Piping Systems Using Corrugated Stainless Steel Tubing

ICC- ES LC-1024 PMG Listing Criteria for Stainless Steel Tubing

IAPMO- IGC-201 The interim Guide Criteria for polyethylene Sleeved Corrugated Stainless Steel Tubing for use in Fuel Gas Piping Systems

LISTINGS:

CSA Certificate of Compliance #1082441

ICC- PMG 1046

ICC- PMG 1052

ICC- PMG 1058

IAPMO- ES 3682

IAPMO- ES 4665

IAPMO- ER 0227

UL- Through Penetration Firestop Systems / ASTM E84 Compliant

OTHER:

California Plumbing Code

California Mechanical Code

Massachussetts Product Approval

City of L.A. Product Approval RR 5495

City of L.A. Product Approval RR 5707

NOTICE: TracPipe® is the original yellow jacketed CSST gas piping system manufactured by **OmegaFlex®**. **TracPipe® CounterStrike®** is a next generation of CSST system which includes a revolutionary arc resistant black jacket.


NOTICE:

While every effort has been made to prepare this document in accordance with the most current model codes in effect at its printing, **OmegaFlex®** cannot guarantee that the local administrative authority adopts or accepts the most recent edition of these codes. The installer must use the current edition of the **TracPipe®** CounterStrike® Design Guide and Installation Instructions.

The installer is ultimately responsible to determine suitability and acceptance of any building component, including gas piping. **OmegaFlex®** assumes no responsibilty for materials or labor for installations made without prior determination of local code authority acceptance.

TracPipe® CounterStrike®

SPECIFICATION DATA SHEET



racPipe CounterStrike


Part No.	FGP-CS-375	FGP-CS-500	FGP-CS-750	FGP-CS-1000	FGP-CS-1250	FGP-CS-1500	FGP-CS-2000	
Size (inch)	3/8"	1/2"	3/4"	1"	1-1/4"	1-1/2"	2"	
EHD (AGA size)	15	19	25	31	39	46	62	
Jacket O.D. (max.)	.700	.888	1.140	1.415	1.700	1.940	2.515	
Inside Diameter (nom)	.440	.597	.820	1.040	1.290	1.525	2.060	
Wall Thickness (in.)	.01	.01	.01	.01	.012	.012	.012	

^{*}EHD (Equivalent Hydraulic Diameter) A relative measure of Flow Capacity; This number is used to compare individual sizes between different manufacturers. The higher the EHD number the greater flow capacity of the piping.

STRAIGHT AUTOFLARE® / AUTOSNAP® FITTINGS




- 1. ADAPTER Brass
- 2. INSERT Stainless Steel
- 3. NUT-Brass
- 4. SPLIT-RINGS Brass or Stainless Steel
- 5. FLEXIBLE PIPE Stainless Steel




4. FLEXIBLE PIPE - Stainless Steel

AVAILABLE IN SIZES							
Tube size	3/8"	1/2"	3/4"	1"	1-1/4"	1-1/2"	2"
NPT Thread	1/2"or 3/8"	1/2"or 3/4"	3/4"or 1/2"	1"or 3/4"	1-1/4"	1-1/2"	2"

FLANGE MOUNT AUTOFLARE® / AUTOSNAP® FITTINGS





AVAILABLE IN SIZES					
Tube Size	3/8"	1/2"	3/4"	1"	1-1/4"
NPT Thread	1/2"or 3/8"	1/2"	3/4"	1"	1-1/4"

CHAPTER 2 DESCRIPTION of SYSTEM and COMPONENTS

SECTION 2.0 — TracPipe® CounterStrike® FLEXIBLE GAS PIPING MATERIAL DESCRIPTION

1. TUBING

The **TracPipe® CounterStrike®** fuel gas piping system consists of corrugated, flexible, semi-rigid, stainless steel tubing with brass mechanical attachment fittings terminating in NPT pipe threads for easy attachment to traditional black iron pipe systems and direct connections to gas appliances. Tubing is available in sizes 3/8 inch, 1/2 inch 3/4 inch, 1 inch, 1-1/4 inch, 1-1/2 inch, and 2 inch.

The 300 series stainless steel tubing is jacketed with a non-metallic cover which provides ease of running through joists, studs, and other building components. The jacket is marked at intervals with the amount

of tubing left on the reel, for quick measurement.

2. FITTINGS

Straight NPT pipe fittings are standard and are available in sizes shown above to fit all tubing. Additional fittings include termina-



3. ACCESSORIES

tings.

Accessories are available for expansion of the flexible piping material and additions to existing fuel gas piping systems. These accessories include: A. Manifolds: Allows parallel installations with "home runs" to each appliance. 1/2 inch female NPT outlets and 3/4 inch and 1/2 inch female NPT inlets. Large size manifolds are also available for use with commercial size *TracPipe® CounterStrike®*.



B. Pressure
Regulators:
Pounds to
inches - for
use in elevated pressure
system installations (over
14 inches
water column
- one half



PSI) to reduce pressure to standard low pressure for appliances.

Regulators are available for use with natural and propane gas.

C. Protection Devices: For use where flexible piping passes through studs, joists and other building materials and is restricted from moving to avoid nails, screws and other puncture threats.



There are five striker plate configurations made from stamped steel and specially hardened to resist penetration from screws and pneumatic nail guns. These are quarter-striker, half striker, three quarter striker, full-striker and 6 inch X 17 inch flat plate striker. Spiral wound galvanized steel "floppy" conduit is available for use as additional protection.

D. Shut-off Valves-for use in elevated pressure

installations: 2 PSI up to 5 PSI. (Standard gas-cocks should be used at appliance stub outs and other low pressure



areas of the piping system.) Brass lever-handle ball valves supplied by **OmegaFlex**® are rated for 5 PSI use and are available in 1/2 inch and 3/4 inch sizes.

NOTICE: For additional specifications see submittal sheets on the website at **www.tracpipe.com.**

SECTION 2.1 — MATERIAL USE AND LIMITATIONS

This Design and Installation Guide has been written in accordance with the most current edition of ANSI LC 1/ CSA 6.26, FUEL GAS PIPING SYSTEMS USING CORRUGATED STAINLESS STEEL TUBING (CSST).

This Design Guide is intended to aid the professional gas pipe installer in the design, installation and testing of flexible fuel gas piping systems for residential, commercial and industrial buildings. It is not possible for this guide to anticipate every variation in construction style, building configuration, appliance requirement, or local restriction. This document will not cover every application. The user should either exercise his own engineering judgment on system design and installation, or seek technical input from other qualified sources. Additional information pertaining to gas

piping systems is available from your local gas utility or propane supplier. Some of the special usage features of *TracPipe® CounterStrike®* flexible gas piping are outlined below:

- Flexible gas piping is used to provide safe, efficient, timely installation of fuel gas piping within buildings, residential, commercial, and industrial, or for outdoor connections to appliances that are attached or in close proximity to the building.
- 2. Flexible gas piping can be routed in most locations where traditional gas piping materials are installed: inside hollow wall cavities, along or through floor joists in basements, on top of the joists in attics, on roof tops or along soffits or in chases outside of buildings. TracPipe® CounterStrike® gas piping has been tested and is listed by CSA International for both outdoor and indoor use.
- 3. **TracPipe® CounterStrike®** is listed by CSA International for fuel gas use in the USA and Canada for pressures up to 25 PSI. For local gas utility approved use only, **TracPipe® CounterStrike®** has been tested for use up to 125 PSI for sizes 3/8 inch up to 1-1/4 inch.
- 4. In North America, the most common pressure for Natural Gas is 6-7 inches water column, standard low pressure. Elevated pressures of either 2 PSI or one half PSI are also available from utilities in most areas for new residential construction. 5 PSI systems are commonly installed in commercial or industrial buildings. Elevated pressures allow the use of smaller diameter piping, while providing for increased loads and longer length runs.
- Flexible gas piping can be used for natural gas and propane (Liquefied petroleum gas) and other fuel gases recognized in NFPA 54 National Fuel Gas Code.

- 6. TracPipe® CounterStrike® with the black polyethylene jacket has been tested by Underwriters Laboratory to ASTM E84 (UL723) Surface Burning Characteristics with flame spread and smoke density ratings meeting the requirements of ANSI/CSA LC-1 for use in air ducts and plenums. It is mandatory, however, to follow fire and building code requirements in all installations.
- 7. For underground or under slab burial the flexible gas piping run must be encased in a sleeve of polyethylene, or other approved water resistant material. See Section 4.9, **Underground Installations**. Sleeved runs under concrete slabs beneath buildings must be installed as required by local codes. Most codes require venting of the sleeves under buildings. This can be accomplished using pre-sleeved **TracPipe® PS-II** with available accessories.
- 8. Flexible gas piping can be used in conjunction with both steel pipe (black iron or galvanized) and copper tubing in either new construction or renovation and replacement piping installations. All *TracPipe® CounterStrike®* fittings terminate in standard NPT male or female pipe threads to interface with appliances, valves, unions and couplings.
- 9. For retrofit installations, *TracPipe® CounterStrike®* can be snaked through hollow wall cavities without major restoration as is typical when running rigid pipe through existing construction. The replacement or addition of gas appliances, fireplaces, and gas logs is greatly facilitated with flexible piping on reels requiring no special tooling or oily threading equipment.
- 10. TracPipe® CounterStrike® gas piping can be run directly to the shut off valves of fixed appliances. For moveable appliances such as ranges or dryers, the use of an approved flexible appliance con-

nector is required.

TracPipe® CounterStrike® cannot be substituted as a connector for this use when the appliance is free to move for cleaning, etc.

- 11. **TracPipe® AutoFlare®** and **AutoSnap®** fittings have been tested by CSA International and are listed for use in concealed locations as defined in NFPA 54 National Fuel Gas Code, The Uniform Plumbing Code, and The International Fuel Gas Code.
- 12. **TracPipe® CounterStrike®** has been evaluated for resistance to damage imposed by shifting appliances and/or by damage to structural framing caused by earthquakes.



SECTION 2.2 — SYSTEM COMPONENTS *TracPipe® CounterStrike®* Flexible Gas Piping

Component	Material		D	escrip	tion/E	Dimen	sions		
TracPipe® Counter- Strike® Flexible Gas Piping	Corrugated Stainless Steel (300 Series) with Polyethylene Jacket	part no. Size (inch) EHD (AGA size) Jacket O.D. (max.) Inside Dia. (nom) *EHD (Equivalent Hompare individual flow capacity of the compare to the compare individual flow capacity of the ca	FGP-CS-375 3/8" 15 .700 .440 Hydraulic D sizes betw	1/2" 19 .888 .597 ameter) A i	76P-CS-750 3/4" 25 1.140 .820		1-1/4" 39 1.700 1.290 w Capacity;	1-1/2" 46 1.940 1.525	
TracPipe® Counter- Strike® on		Not	te: othe	reel le	aylug aylug aylug aylug aylug aylug	yailable	upon re	quest.	
Reels	packaging	Pipe S	ize	Stan	dard R	eel Leng	tth	Maxin Reel W	
		3/8 in	ch			100 feet		37 po	unds
		1/2 in	ch		00 feet	250 feet 50 feet		98 poi	unds
		3/4 in	ch	10		50 feet		70 po	unds
		1 inc	h	10	180 1 00 feet	feet 50 feet		70 po	unds
		1-1/4 i	nch		250 f 150 f			129 pou	unds
		1-1/2 i			250 f 150 f	feet feet		182 pou	
		2 inc	h		150 1	feet		137 pou	ands

TracPipe® AutoFlare® / AutoSnap® Fittings

The fittings and accessories pictured on the following pages are representative of the range of products available from *CounterStrike*°. Refer to the latest *CounterStrike*° Price Sheet for a complete listing of part numbers.

Component	Material	Description/Dimensions
TracPipe® PS-II Accessories		PS-II Vent Nut Split Adapter Coupling Rings
Straight Mechanical Fitting Reducer Fitting	Brass Fitting AutoSnap® AutoFlare® Insert	Sizes: 3/8, 1/2, 3/4, 1, 1-1/4, 1-1/2 and 2 inch Note size 3/8 fitting has either 1/2" NPT or 3/8" NPT Thread
Termination and Flange Mount Fittings- Straight and 90 Elbow	Brass Fitting AutoSnap® AutoFlare® Insert Brass Flange	Sizes: 3/8, 1/2, 3/4, 1 inch and 1-1/4 inches Note size 3/8 fitting has either 1/2" NPT or 3/8" NPT Thread Elbow Sizes: 3/8 in. and 1/2 in.
Meter Termination Fitting Stud Bracket	Brass Fitting AutoSnap® AutoFlare® Insert Galv. steel Mounting Bracket	
Flange Mounting Bracket	Galvanized Steel	One size fits all: Size 3/8 through 1-1/4 inches
Tee Fitting & Coupling	Brass Tee Fitting & Coupling AutoSnap® AutoFlare® Insert	Sizes: 3/8, 1/2, 3/4, 1, 1-1/4, 1-1/2, and 2 inch Reducer tees available for 1/2, 3/4, 1, 1-1/4, 1-1/2, and 2 inch sizes

TracPipe® CounterStrike® Accessories

Component	Material	Description/Dimensions
Load Center Manifold Bracket	Painted Steel Galvanized Steel	
Multi- Port Manifolds	Malleable Iron Poly Coated	
Pressure Regulators	Cast Housing Suitable for Outdoor Use	Sizes: 1/2 inch & 3/4 inch & 1 inch Regulator includes approved vent limiting device for REG-3 (1/2 inch), REG-5A (3/4 inch) and REG-7L (1 inch). Note: Stainless steel high pressure tags are available for use where required by code
Shut Off Valves	Brass Housing with Stainless Steel Ball	Sizes: 1/2 inch & 3/4 inch

TracPipe® CounterStrike® Accessories

Component	Material	Description/Dimensions
Full Striker Plate	Carbon Steel Hardened	size: 3" x 12"
Half Striker Plate & Three Quarter Striker Plate	Carbon Steel Hardened	size: 3" x 7" size: 3" x 8"
Quarter Striker Plate	Carbon Steel Hardened	size: 3" x 2"
6.5 inch x 17 inch Striker Plate	Carbon Steel Hardened	size: 6.5" x 17"
Floppy Strip Wound Conduit	Type RW Galvanized Steel	sizes: Fits 3/8", 1/2", 3/4", 1", 1-1/4", 1-1/2" and 2" CounterStrike ®


CHAPTER 3 SYSTEM CONFIGURATIONS AND SIZING

SECTION 3.1 — SYSTEM CONFIGURATIONS

There are several piping system options available to the installer using *TracPipe® CounterStrike®* gas piping material. This flexibility of design is one of the major benefits of CSST.


3.1.1 - LOW PRESSURE SYSTEMS

1. SERIES: A series layout is the most common arrangement utilized for black iron pipe. This consists of a main run with tees branching off to each appliance.



Series Layout


2. PARALLEL: A parallel system consists of a central distribution manifold with branch runs to the appliances. This is usually accomplished by providing a main supply line to a manifold and installing "home runs" to each appliance location. In the parallel system shown below the pressure is not elevated above 1/2 pound and no regulator is required.



Parallel Layout

3.1.2 — DUAL PRESSURE SYSTEMS

Elevated pressure systems (2 PSI for residential and up to 5 PSI for commercial installations) are usually piped with one or more line gas pressure regulators (pounds-to-inches) followed by a manifold and runs to each of the appliances. It is possible that these runs to appliances may contain tees branching off to an additional appliance where gas loads permit.



NOTICE:

HYBRID SYSTEMS - FLEXIBLE GAS PIPE and RIGID BLACK PIPE COMBINATIONS. In low or medium pressure systems, it is often advantageous to use both corrugated stainless steel tubing and rigid pipe in the same system. This is the case when a larger diameter main branch is required to provide for the total appliance load in a parallel system. TracPipe® CounterStrike® is certified for use in combination with black iron pipe and copper tube gas piping systems. For additional information on Hybrid Systems, see examples showing the method for sizing hybrid systems using both TracPipe® CounterStrike® and black iron pipe. These are included in the SIZING EXAMPLES section of this manual. Refer to Section 3.2C

SECTION 3.1.3 - SYSTEM DESIGN

- Start by creating a sketch or layout of the gas piping system you are about to install. The information you will need is the location of each appliance, the point of delivery (location of utility meter or second stage LP regulator), appliance load demands, and possible pipe routing locations. The load demand data is usually available on the appliance manufacturer's nameplate, or can be provided by the builder.
- 2. Determine local piping restrictions prior to installing flexible gas piping. The major code bodies in North America have written Corrugated Stainless Steel Tubing into the latest revisions of their mechanical codes, but local and state adoption of these codes often lags behind.

Confirm that the local code authority has accepted the use of flexible gas piping. Your *TracPipe® CounterStrike®* distributor should be able to provide that information but confirmation by the installer should be made where there is any questions.

SECTION 3.1.4 — SYSTEM PRESSURE CHOICES

- 1. NATURAL GAS -Determine the delivery pressure provided by the Local Distribution Utility where the piping will be installed.
 - a. LOW PRESSURE-6 to 7 inches water column (equivalent to 4 ounces or 1/4 pound) is the standard pressure supplied by natural gas utilities in the USA and Canada.
 - b. MEDIUM PRESSURE-1/2 PSI (12 to 14 inches water column) is available from many natural gas utilities as an alternate pressure supply. The increase in pressure provides for reductions in pipe size and does not require a pressure regulator. Most natural gas appliances manufactured for use in

- the US and Canada are designed to operate up to a maximum of 14 inches water column.
- c. ELEVATED PRESSURE-2 PSI is the highest natural gas pressure usually supplied within residential buildings in North America. This pressure always requires the installation of a pounds-to-inches line pressure regulator between the utility meter set and the appliances.
- 2. PROPANE (LP GAS) is typically supplied within residential buildings at 11 inches water column which is set at the second stage regulator mounted outside the building. Propane can also be utilized at medium pressure with the use of a 13-14 inch setting. For 2 PSI propane elevated pressure use, use a line gas pressure regulator that is set for 11 inches water column outlet pressure.

NOTICE: TracPipe® CounterStrike® has been tested by CSA International for a working pressure of 125 PSI for sizes 3/8 inch through 1-1/4 inch.

PRESSURE CONVERSION CHART

1/4 PSI = 7" w.c. = 4 oz.

1/2 PSI = 14" w.c. = 8 oz.

1 PSI = 28 "w.c. = 16 oz.

2 PSI = 56" w.c. = 32 oz.

SECTION 3.2 SIZING METHODS and EXAMPLES

SECTION 3.2.1 — USE OF SIZING TABLES

This Chapter includes flexible gas piping sizing procedures for both low pressure and elevated pressure systems. Every piping system introduces pressure loss to the fluid flowing within. The amount of loss depends on the piping size and the gas flow, expressed in cubic feet per hour (and converted to BTU's). The object of the sizing exercise is to determine the smallest size piping which will introduce the allowed pressure loss or drop within the length of piping required. Sizing tables (capacity charts) provide the maximum flow capacity for a given length of run for each pipe size. A different sizing table is used for each system pressure and pressure drop combination.

- 1. The low pressure series system (standard arrangement) is sized in the same way as a conventional low pressure black iron pipe system using *TracPipe® CounterStrike®* sizing tables or tables found in National Fuel Gas Code NFPA 54. This method is known as the "Branch Length Method". Pressure drop in a low pressure system is usually limited to 0.5 inch water column over the system.
- Elevated pressure systems incorporate two operating pressures downstream of the utility meter set. The first pressure, set by the service regulator at the meter, is usually 2 PSI. This part of the system is sized separately and ends at the line pressure regulator.
- 3. For a 2 PSI system, the proper drop is usually 1 PSI for this part of the system; this allows for the approximate 3/4 PSI regulator drop downstream and provides the 1/4 PSI (6-7 inches w.c.) necessary for appliances. The regulator reduces the pressure from pounds to 8 inches water column. This part of the system is sized the same as a low pressure system, except that a special Table N-3 is used allowing 3 inches of water column drop. These lines

are typically sized for only one appliance load installed as a "home run" from the manifold.

SECTION 3.2.2— SIZING EXAMPLES -BRANCH LENGTH METHOD

To size each of the following systems, determine the required size for each section and outlet. To size each section of the system, determine both the total gas load for all appliances and the maximum distance (longest length) in which a particular section delivers gas.

EXAMPLE 1: LOW PRESSURE SYSTEM SERIES ARRANGEMENT





Figure: 3-1



LENGTH OF RUNS

A = 10 Feet

B = 10 Feet C = 15 Feet

Supply pressure 6 inches w.c. Allowable drop 0.5 inches w.c.

1. The system presented in Figure: 3-1 is typical of a single family installation in which there are a limited number of appliances located in one general area. The supply pressure is 6 inches water column and the allowable drop is 0.5 inch.

- 2. To size section A, determine the longest run from the meter that includes section A and the total gas load it must deliver:
 - Meter to Furnace is 20 ft. (A+B).
 - Meter to Water Heater is 25 ft. (A+C). This is the longest run.
 - Determine the maximum load transported by Section A.
 - Furnace plus water heater = 100 CFH (100,000 BTU).
 - Select Table N-1 "Low Pressure 6 inches- 0.5 inch w.c. drop".
 - Using the longest run method, select the column showing the measured length, or the next longest length if the table does not give the exact length. Referring to table N-1 the column for 25 feet of piping shows that sizes 3/8 inch and 1/2 inch are too small and the next available size is 3/4 supplying 157 CFH.
 - The correct size is 3/4".
- 3. To size Section B, determine the length of run from the meter to the Furnace and the load delivered:
- Length is 20 ft (A+B) and load is 65 CFH (65,000 BTU).
 - Table N-1 shows that size 1/2 inch supplies 70 CFH.
 - The correct size is 1/2 inch.
- 4 To size Section C, determine the length of run from the meter to the Water Heater and the load delivered:
 - Length is 25 ft (A+C) and load is 35 CFH (35,000 BTU).
 - Table N-1 shows that size 1/2 inch is required, because size 3/8 inch only supplies 29 CFH (29,000 BTU).
 - The correct size is 1/2 inch.

EXAMPLE 2: MEDIUM PRESSURE 12-14 INCHES W.C. (1/2 PSI)

1. The system shown in Figure: 3-2 is typical

of a single family installation with several appliances. The arrangement chosen is parallel. The MEDIUM PRESSURE SYSTEM (1/2 PSI) allows a higher pressure drop (6 inches water column) than is available with low pressure systems.





Figure: 3-2



LENGTH OF RUNS

A = 10 Feet

B = 20 Feet

C = 10 Feet

D = 40 Feet

E = 10 Feet

Supply pressure 1/2 PSI (12 inch-14 inch w.c.) Allowable drop: 6 inch w.c.

- 2. To size SECTION A, determine the LONGEST RUN from the meter to the furthest appliance:
 - Meter to dryer is 50 feet (10+40)
 A+D.
 - Determine maximum load transported by section A.
 - Dryer + range + water heater + furnace = 205 CFH (205,000 BTU).
 - Select table N-4 "Medium Pressure 1/2 PSI with 6 inch drop". Table N-4 shows that 1/2 inch size is too small for 205 CFH at 50 ft. but 3/4 inch can handle 375 CFH.
 - The correct size is 3/4 inch.
- 3. To size SECTION B, the distance from the meter to the range is 30 ft (10+20) A+B:
 - Load is 55 CFH (55,000 BTU).
 - Table N-4 shows that 3/8 inch size can handle 90 CFH.
 - The correct size for section B is 3/8 inch.

- 4. To size SECTION C, the distance from the meter to the water heater is 20 ft (10+10) A+C:
 - Load is 40 CFH (40,000 BTU).
 - Table N-4 shows that that 3/8 inch size can handle 112 CFH.
 - The correct size for section C is 3/8 inch.
- 5. To size SECTION D, the distance from the meter to the dryer is 50 ft (10+40) A+D:
 - Load is 30 CFH (30,000 BTU).
 - Table N-4 shows that that 3/8 inch size can handle 69 CFH at 50 feet
 - The correct size for section D is 3/8 inch.
- 6. To size SECTION E, the distance from the meter to the furnace is 20 ft (10+10) A+E:
 - Load is 80 CFH (80,000 BTU)
 - Table N-4 shows that 3/8 inch size can handle 112 CFH at 20 feet
 - The correct size for section E is 3/8 inch.

EXAMPLE 3: ELEVATED PRESSURE 2 PSI SYSTEM-PARALLEL ARRANGEMENT

1. The system shown in Figure: 3-3 is adapted for multifamily or single family application with an extended (100 feet) tubing run from





Figure: 3-3



LENGTH OF RUNS

A = 100 Feet

B = 15 Feet

C = 10 Feet

D = 25 Feet E = 20 Feet

Supply pressure 2 PSI Allowable drop: 1 PSI up to reg. 3 inches w.c.-reg. to appliance

the meter to the regulator. The 2 PSI system is well adapted to handle the long runs required in multifamily buildings with centralized meter banks.

- 2. To size section A determine the entire gas load it will deliver:
 - furnace + water heater + dryer + range = 80 CFH + 40 CFH + 30 CFH + 55 CFH = 205 CFH (205,000 BTUH) Select Table N-5 "Elevated Pressure 2 PSI with 1 PSI drop". This is the standard table chosen to stay within the FGP-REG-3 regulator capacity. See note below.
 - Length is 100 ft.
 - Table N-5 shows that 3/8 inch size is too small for 205 CFH but 1/2 inch can handle 226 CFH.
 - The correct size is 1/2 inch.
- 3. To size each of the other sections:

Select Table N-3 "Regulator Outlet 8.0 inches w.c with a drop of 3.0 inches w.c.

- Section B is 15 feet with a 40 CFH load 3/8 inch has a capacity of 90 CFH.
- Section C is 10 feet with a 80 CFH load 3/8 inch has a capacity of 112 CFH.
- Section D is 25 feet with a 30 CFH load 3/8 inch has a capacity of 69 CFH.
- Section E is 20 feet with a 55 CFH load 3/8 inch has a capacity of 78 CFH.
- The correct size for all these runs is 3/8 inch.

Supply Pressure and Capacities

Based on flow in cubic feet per hour natural gas

P/N	1/2 PSI (34 mbar)	3/4 PSI (52 mbar)	1 PSI (69 mbar)	1-1/2 PSI (103 mbar)
FGP-REG-3	145 (4.1)	200 (5.7)	250 (7.1)	250 (7.1)
FGP-REG-5A	335 (9.5)	475 (13.5)	550 (15.6)	500 (15.6)
FGP-REG-7L	690 (19.5)	970 (27.5)	1000 (28.3)	1000 (28.3)

EXAMPLE 4: MEDIUM PRESSURE 12-14 INCHES W.C. 1/2 PSI) PARALLEL SYSTEM WITH A SERIES BRANCH

 The system shown in Figure: 3-4 has a barbeque installed nearby the range. A parallel arrangement was chosen for the medium pressure system (12 inch W.C. with 6 inches W.C. drop) with a single run feeding both range and barbeque in series.




Figure: 3-4

LENGTH OF RUNS

A = 20 Feet

B = 35 Feet

C = 20 Feet

D = 10 Feet

E = 10 Feet

F = 10 Feet

G = 15 Feet

- To size SECTION A, determine the length of the longest run from the meter and the entire gas load it must deliver:
 - Range + barbeque + water heater + furnace + dryer = 260 CFH (260,000 BTUH).
 - Meter to barbeque is 75 ft (A+B+C) This is the longest length.
 - Select Table N-4 Medium Pressure.
 Table N-4 shows that 1 inch is required for 260 CFH at 75 ft.
 - The correct size is 3/4 inch.

- 3. To size SECTION B, the line from the manifold serves both the range and the barbeque:
 - Total load is 105 CFH (110,000 BTUH).
 - Longest length is 75 feet (A+B+C) from the meter to the barbeque.
 - Table N-4 shows that size 1/2 inch can handle 120 CFH at 75 ft.
 - The correct size is 1/2 inch.
- 4. To size SECTION C, the distance from the meter to the barbeque is 75 ft (A+B+C):
 - Load is 55 CFH (55,000 BTUH).
 - Table N-4 shows that size 3/8 inch can handle 55 CFH at 80 ft.
 - The correct size is 3/8 inch.
- 5. To size SECTION D, the distance from the meter to the range is 65 ft (A+B+D).
 - Load is 50 CFH (50,000 BTUH).
 - Table N-4 shows that size 3/8 inch can handle 58 CFH at 70 ft.
 - The correct size is 3/8 inch.
- 6. To size SECTION E, the distance from the meter to the water heater is 30 ft (A+F):
 - Load is 40 CFH (40,000 BTUH).
 - Table N-4 shows that size 3/8 inch can handle 90 CFH at 30 ft.
 - The correct size is 3/8 inch.
- 7. To size SECTION F, the distance from the meter to the furnace is 30 ft (A+E)
 - Load is 80 CFH (80,000 BTUH).
 - Table N-4 shows that size 3/8 inch can handle 90 CFH at 30 ft.
 - The correct size is 3/8 inch.
- 8. To size SECTION G, the distance from the meter to the dryer is 35 ft (A+G).
 - Load is 35 CFH (35,000 BTUH).
 - Table N-4 shows that size 3/8 inch can handle 78 CFH at 40 ft.
 - The correct size is 3/8 inch.


SECTION 3.2.3 —SIZING HYBRID SYSTEMS - Black Iron and *TracPipe® CounterStrike®* Combination

To size a commercial or a residential system with a rigid black iron trunk line and flexible *TracPipe® CounterStrike®* branches feeding the appliances, you will need both the standard gas piping capacity tables for black iron printed in many plumbing and mechanical codes (and contained in both National and International Fuel Gas Code) and the *TracPipe® CounterStrike®* Capacity Tables printed later in this manual.

NOTICE: Black iron pipe capacity table is provided in this design guide Section 7.2.

Section A correct size is 11/2 inch black pipe.

- 3. To determine rigid pipe size (section B) reduce load by the load carried in section A1 to Radiant Heater (175 CFH). Use same number for length: 70 ft. is longest run. Load for this section is 540 CFH Section B correct size is 1 1/2 inch black pipe.
- 4. To determine rigid pipe size (section C) reduce load further by the load carried in section B1 to first unit heater (250 CFH). Use same number for length: 70 ft. is longest run. Load for this section is 290 CFH. Section C correct size is 11/4 inch black pipe.



5. To determine **TracPipe® CounterStrike®** sizing for the branch runs the length to be used is the total length of black pipe plus **TracPipe® Counter-Strike®** from the meter to that appliance. The load used is the load of the individual piece of equipment.

6. To determine the size of TracPipe® Counter-Strike® (section D1) the length is 70 ft and the load is 40 CFH. Using Table N-1: Section D correct size is 3/4 inch.

EXAMPLE 5: LOW PRESSURE HYBRID SYSTEM Black Iron and CounterStrike® Combination - SERIES ARRANGEMENT

A = 15 Feet C = 20 Feet

A1 = 45 Feet C1 = 5 Feet B = 15 Feet D1 = 20 Feet B1 = 10 Feet

LENGTH OF RUNS

- The system shown in Figure: 3-5 is a typical commercial building with 4 appliances. The gas pressure for this example is standard low pressure with 6-inch supply pressure and 0.5inch pressure drop.
- To determine rigid pipe size (section A) determine the longest run from the meter to the furthest appliance:
 Meter to water heater Add A + B + C + D1 =

70 ft. Total Load is 715 CFH (715,000 BTU)

- 7. To determine the size of **TracPipe® Counter- Strike®** (section C1) the length is 55 ft and the load is 250 CFH. Using Table N-1: Section C1 correct size is 1 1/4 inch.
- 8. To determine the size of **TracPipe® Counter- Strike®** (section B1) the length is 40 ft and the load is 250 CFH. Using Table N-1:
 Section B1 correct size is 1 1/4 inch.
- 9. To determine the size of **TracPipe® Counter- Strike®** (section A1) the length is 60 ft and the load is 175 CFH. Using Table N-1:
 Section A1 correct size is 1 1/4 inch.

EXAMPLE 6: LOW PRESSURE HYBRID SYSTEM -Black Iron and CounterStrike® Combination - SERIES ARRANGEMENT





Figure: 3-6

- 1. The system presented in Figure: 3-6 is a typical residence with 5 appliances. The supply pressure is 7 inches w.c. The allowable drop is 1.0 inch w.c. total.
- **NOTICE:** Check with your local inspection department and/or gas utility before sizing any low-pressure system with a total drop of more than 0.5 inch w.c.
- 2. The black iron trunk line (A+B+C1+C2+D) will first be sized for a drop of 0.5 inch, w.c. in accordance with the standard method (longest total run) and each *TracPipe® CounterStrike®* branch run to an appliance will then be sized for 1.0 inch w.c. drop based on the length from that appliance back to the meter. The maximum pressure drop to each appliance will be 1.0 inch w.c.
- 3. The longest total run is 122 ft. (total length of all black iron sections and *TracPipe® CounterStrike®* section to the furthest appliance). The total load is 70+40+55+35+30=230 CFH.Correct size for A is 1-1/4 inch.
- Section B, the longest run remains 122 ft but the load is reduced to 175 CFH. Correct size is 1 inch.

- 5. Section C1, the longest run is 122 ft and load is reduced to 105. Correct size is 1 inch.
- 6. Section C2, the longest run is 122 ft and load is reduced to 70. Correct size is 3/4 inch.
- 7. Section D, the longest run is 122 ft and load is reduced to 30. Correct size is 1/2 inch.
- 8. Section E, length is 60 ft and the load is 55 CFH. From Table N-2A the correct size is 1/2 inch.
- 9. Section F, length is 90 ft and the load is 70 CFH. From Table N-2A the correct size is 3/4 inch.
- 10. Section G, length is 97 ft and the load is 40 CFH. From Table N-2A the correct size is 1/2 inch.
- 11. Section H, length is 122 ft and the load is 30 CFH. From Table N-2A the correct size is 1/2 inch.
- 12. Section I, length is 96 ft and the load is 35 CFH. From Table N-2A the correct size is 1/2 inch.

EXAMPLE 7: LOW PRESSURE HYBRID STEEL PIPE AND CounterStrike® -PARALLEL ARRANGEMENT-MANIFOLD-USING THE BRANCH LENGTH METHOD

The system presented in Figure: 3-7 is typical of a residential installation with four appliances. The supply pressure is 7-8 inches water column. The system will be sized with 0.5 inches w. c. drop for the steel pipe trunk line and 1.0 inch w.c. drop for the *TracPipe® CounterStrike®* branches.



- To size the steel pipe trunk line, determine the longest run from the meter to the most remote appliance and the total load. The longest run is to the fireplace:
 - Meter to fireplace is 50 ft (A + D).
 - Total load is 195 CFH (75 + 35 + 30 + 55). Using steel pipe Table: SP-1 following the 50 ft column down, the correct size for the steel pipe is 1 inch.
- 3. To determine the size of the *TracPipe® CounterStrike®* run "C" to the furnace use the load through that branch (75 CFH) and calculate the length from the meter to the furnace:
 - Meter to furnace is 30 ft (A + B).
 - Furnace load is 75 CFH.

Using Table N-2A the 1.0-inch w.c. pressure drop chart for *TracPipe® Counter-Strike®*. Follow the 30 ft column down, the correct size for the furnace branch line "C" is 1/2 inch.

- 4. To determine the size of the *TracPipe® CounterStrike®* run "B" to the water heater use the load through that branch (35 CFH) and calculate the length from the meter to the water heater:
 - Meter to water heater is 30 ft (A + C).
 - Water heater load is 35 CFH.

Using Table N-2A the 1.0 inch w.c. pressure drop chart for *TracPipe® CounterStrike®*. Follow the 30 ft column down, the correct size for the water heater branch line "B" is 3/8 inch.

- 5. To determine the size of the **TracPipe® CounterStrike®** run "D" to the fireplace use the load through that branch (30 CFH) and calculate the length from the meter to the fireplace:
 - Meter to fireplace is 50 ft (A + D).
 - Fireplace load is 30 CFH.

Using Table: N-2A (the 1.0 inch w.c. pressure drop chart for *TracPipe® Counter-Strike®*). Follow the 50 ft column down, the correct size for the fireplace branch line "D" is 1/2 inch.


- 6. To determine the size of the **TracPipe® CounterStrike®** run "E" to the range use the load through that branch (55 CFH) and calculate the length from the meter to the range:
 - Meter to range is 45 ft (A + E).
 - Range load is 55 CFH. Using Table: N-2A the 1.0 inch w.c. pressure drop chart for *TracPipe® CounterStrike®*. Follow the 50 ft column down, the correct size for the range branch line "D" is 1/2".

SECTION 3.2.4 — ALTERNATE SIZING METHOD: SUM OF PRESSURE LOSS CALCULATIONS

1. In addition to the longest run sizing method, there is another approach to pipe sizing, which yields results closer to the actual friction loss results (obtained from testing) for each section of an installed gas piping system. This engineered approach "Sum of Pressure Loss Calculations" avoids the simplified, conservative approximations of the longest run method. Mechanical engineers who design piping systems understand that placing a building's entire load (theoretically) at the farthest equipment outlet is not only inaccurate but will often yield pipe sizes which are larger than necessary. The longest run method was devised at a time when gas utilities could not always guarantee a constant pressure at every meter during times of high demands; it is a conservative approach and, although it is the customary sizing approach in North America, other engineered calculations are permitted by most codes.

- 2. Pressure loss calculations which sum up friction losses in each section of a gas piping system can provide a system design with more accurate and possibly smaller piping diameters than the traditional longest run method. These calculations utilize pressure loss charts for each size of CSST, which have been developed from actual test results. The maximum flow capacity is predicted with more precision than with the longest run method. The Sum of Pressure Loss method is described below with tables providing pressure loss per foot based upon the total load supplied by that length of pipe with all appliances operating.
- 3. The system designer has simply to determine the load and the length for each run. A tentative size is chosen and pressure loss in that leg is determined by multiplying the loss per foot (inches w.c. from the chart) by the length. Starting at the meter and working outward the pressure loss for each lea is then summed up until the farthest appliance is reached. The total calculated loss is then compared with the allowable loss, which must not be exceeded from the meter to the farthest appliance. The allowable pressure loss for each system is the responsibility of the system designer, based on model codes and on the available pressure at the meter set (or second stage regulator) and the pressure required for each appliance (usually found on the manufacturer's data plate.) Current language in many model codes states: The allowable loss under maximum probable flow conditions, from the point of delivery to the inlet connection of the appliance, shall be such that the supply pressure at the appliance is greater that the "minimum inlet pressure" as stated on the appliance manufacturers data plate. If the initial proposed design calculation yields a total pressure loss, which is higher than allowed, simply go back and calculate again with larger sizes, starting from the meter.

USING SUM OF PRESSURE LOSS METHOD EXAMPLE 8: LOW PRESSURE SYSTEM



rigure. 5-0

SERIES ARRANGEMENT

- 1. The system presented in Figure: 3-8 is similar to that in 3-1, a single-family installation with the addition of one more appliance, a dryer. The supply pressure is 6 inches water column and the allowable pressure drop is 0.5 inch.
- 2. To size section A, calculate the load carried by that section:
 - Furnace plus Water Heater plus Dryer = 135 CFH (MBTU).

Using Table PD-1A find pressure loss at 135 MBTU load through 3/4 inch **TracPipe® CounterStrike®** Average of 0.0135 and 0.0158 is 0.0147. Drop per foot is 0.0147; multiply by length 10 feet = 0.147 drop.

- 3. To size section B find the drop per foot for the load carried by that section:
 - Furnace Load 65 CFH (MBTU).

Using Table PD-1A find pressure loss at 65 MBTU through 1/2 inch **TracPipe® CounterStrike®**. Use the average of loss between 60 and 70 MBTU: Average of 0.0177 and 0.0244 is 0.0211; Drop per foot is 0.0211; Multiply by length 10 feet = 0.211 drop.

Sum pressure loss meter to Furnace 0.147 + 0.211 = 0.358 inch w.c.

This leg is sized properly at 1/2 inch because sum of loss is less than 0.5 inch w.c.

- 4. To size section C1 find the drop per foot for the load carried by that section:
 - 70 CFH (MBTU)

Using Table PD-1A find pressure loss at 70 MBTU load through 1/2 inch **TracPipe® CounterStrike®**

Drop per foot is 0.0244; length is 5 ft; 5 X 0.0244 is 0.122.

- 5. To size section C2 find the drop per foot for the load carried by that section:
 - 35 CFH (MBTU)

Using Table: PD-1A find pressure loss at 35 CFH load through 1/2 inch **TracPipe® CounterStrike®** Average of 0.0077 and 0.0042 is 0.0060; length is 10 ft; 10X 0.006 is 0.06. Sum pressure loss to water heater 0.147 + 0.122 + 0.06 = 0.329 inch w.c. This leg is sized properly at 1/2 inch because sum of loss is less than 0.5 in. w.c.


- 6. To size section D find the drop per foot for the load carried by that section:
 - 35 CFH (MBTU)

Using Table: PD-1A find pressure loss at 35 CHF MBTU through 1/2 inch **TracPipe® CounterStrike®**. Drop per foot is 0.006 (See number 4 above); Multiply by length 15 feet = 0.09. Sum pressure loss to dryer 0.147 + 0.122 + 0.09 = 0.359 inch w.c. This leg is sized properly at 1/2 inch because sum of loss is less than 0.5 in. w.c.

The sum of pressure loss method allows the addition of an appliance without increasing trunk line size.

EXAMPLE9: LOW PRESSURE HYBRID SYSTEM - TracPipe® CounterStrike® Steel Pipe and Combination - SERIES ARRANGEMENT USING SUM OF PRESSURE LOSS METHOD

1. The system presented in Figure: 3-9 is identical to that in Figure: 3-6 a single-family installation with 5 appliances. Low pressure 6-7 inches and a pressure drop of 0.5 inches water column. **NOTICE:** in Example: 6 this system was sized using the longest run method. Here we will use the sum of pressure loss method discussed in section 3.2D.



- 2. Begin by using pipe sizes determined in Example: 6 and determine if these are correct with this method. It is possible that smaller pipe sizes may be sufficient; this will be determined by calculating the sum of pressure losses from the meter to each appliance. To use this method a tentative size will be assigned to each run and this size will be confirmed or revised by the calculation. The sum total loss of a run from the meter to the appliance cannot exceed the allowable pressure loss.
- 3. To determine pressure loss through section A (steel pipe trunk), use the load through that section (230 CFH) for 1-1/4 inch steel pipe and find the pressure loss per foot using Table: PD-2A. (Since 230 CFH is not listed in the chart you must extrapolate the pressure drop using the two flow rates above and below the desired capacity.) This would equate to approximately 0.0018 inch w.c. Pressure drop per foot. Multiply the length: 40 feet by the loss per foot: 0.0018. The pressure loss for this section is 0.072.
- 4. To determine the pressure loss through section B, we use the load through that section (175 CFH). Find the loss for 1 inch size using Table: PD-2A. This would be approximately 0.0041 inch w.c. per foot. Multiply the length: 20 feet by the loss per foot: 0.0041. The pressure loss for this section is 0.0820.

- 5. To determine the pressure loss through section C1 we use the load through that section (105 CFH). Find the pressure loss for 1 inch using Table: PD-2A. This would be approximately 0.0016 inch w.c. Multiply the length: 5 feet by the loss per foot 0.0016. The pressure loss for this section is 0.0080" w.c.
- 6. To determine pressure loss through section C2 we use the load through that section (70 CFH). Find the pressure loss for 3/4 inch using Table: PD-2A. This would be 0.0024' w.c. Multiply the length: 5 feet by the loss per foot: 0.0024. The pressure loss for this section is 0.0120' w.c.
- 7. To determine pressure loss through section D we use the load through that section (30 CFH). Find the pressure loss for 1/2 inch using Table: PD-2A. This would be 0.0020" w.c. Multiply the length: 10 feet by the loss per foot: 0.0020. The pressure loss for this section is 0.0200" w.c.
- 8. To determine pressure loss through section E (*TracPipe® CounterStrike®* drop to range) use the load through that section (55 CFH) and extrapolate the pressure loss using Table: PD-1A. Trying the 3/4 inch column we find that the pressure loss would be approx 0.0029 inch w.c. Multiply the length: 30 feet by the loss per foot 0.0029. The pressure loss for this section is 0.0870. Add the loss of section A to the loss of section E for the total loss from the meter to the range. 0.072 + 0.0870 = 0.159. Since this is less than the 0.5 inch w.c. allowable drop the correct size for section E is 3/4 inch.
- 9. To determine pressure loss through section F (*TracPipe® CounterStrike®* drop to the furnace), use the load (70 CFH) and find pressure loss from Table: PD-1A. In the 3/4 inch column we find 0.0038. Multiply the length: 30 feet by 0.0038. The pressure loss for this section is 0.1140. Add the loss of sections A + B to the loss of section F for total loss from meter to furnace. 0.072 + 0.082 + 0.114 = 0.2680. The correct size for section F is 3/4 inch.
- 10.To determine pressure loss through section G (*TracPipe® CounterStrike®* drop

- to the water heater), use the load (40 CFH) and find pressure loss from Table: PD-1. In the 1/2 inch column we find 0.0077. Multiply the length: 25 feet by 0.008. The pressure loss for this section is 0.1925. Add the loss of sections A + B + C1 + C2 to the loss of section G for total loss from meter to furnace. 0.072 + 0.0820 + 0.0080 + 0.0120 = 0.1740. The correct size for section G is 1/2 inch.
- To determine pressure loss through section H (*TracPipe® CounterStrike®* drop to the fireplace), use the load (30 CFH) and find pressure loss from Table: PD-1. In the 1/2 inch column we find 0.0042. Multiply the length: 40 feet by 0.0042. The pressure loss for this section is 0.1680. Add the loss of sections A + B + C1 + C2 + D to the loss of section H for total loss from meter to furnace. 0.072 + 0.0820 + 0.0080 + 0.0120 + 0.1680 = 0.3420. The correct size for section H is 1/2 inch.
- 12. To determine pressure loss through section I (*TracPipe*[®] *CounterStrike*[®] drop to the dryer), use the load (35 CFH) and find pressure loss from Table: PD-1. In the 1/2 inch column we find 0.006. Multiply the length: 30 feet by 0.006. The pressure loss for this section is 0.18. Add the loss of sections A + B + C1 to the loss of section I for total loss from meter to dryer. 0.072 + 0.0820 + 0.0080 + 0.18 = 0.3420. The correct size for section I is 1/2 inch. Using the Sum of Pressure Loss Method we calculate that three of the five TracPipe® CounterStrike® sections (when compared with the longest length method) can utilize reduced sizes to deliver the necessary load with a pressure loss equal to or less than the allowable 0.5 inches water column. This enables the installer to use 1/2 inch TracPipe® CounterStrike®on all but the furnace and range drops, which remain 3/4 inch.

CHAPTER 4 INSTALLATION PRACTICES

SECTION 4.1 — GENERAL INSTALLATION PRACTICES

Precautions must be taken to ensure that any exposed flexible piping is not damaged or abused during building construction. All system hardware should be stored in a secure, dry location prior to installation.


- 1. The piping system is for use with fuel gas at operating pressures up to 25 PSI (USA and Canada restriction). *TracPipe® CounterStrike®* gas piping (3/8 inch up to 1-1/4 inch sizes) has been tested and is approved for pressures up to 125 PSI, and may ONLY be used at this pressure with the consent of the local gas utility and code authority. Pressure tests up to 125 PSI are permitted on sizes up to 1-1/4 inch.
- Only components provided by *OmegaFlex*[®] or specified as part of the *TracPipe*[®] *CounterStrike*[®] piping system are to be used in the installation.

Do not use **TracPipe® CounterStrike®** tubing or fittings with tubing or fittings of any other manufacturer. Itermixing of CSST tubing or fitting components between CSST manufacturers is prohibited. Connections between two different brands of CSST may be accomplished using standard malleable iron fittings.

- 3. Ends of the piping are to be temporarily capped, plugged or taped closed prior to installation and pulling through structure to prevent entrance of dirt, or other debris.

5. BENDING **TracPipe® CounterStrike®**

Undue stress or strain on the tubing or fittings is to be avoided. Bending flexible gas piping is one feature



which contributes to the speed of installation. Multiple tight bends can restrict the gas flow and increase pressure drop. The tightest bend allowed for each size of **TracPipe® CounterStrike®** is shown in Table: 4-1.

MINIMUM BENDING RADIUS FOR FLEXIBLE GAS PIPING Table: 4-1

TUBING SIZE	MINIMUM
	BEND RADIUS (R)
3/8 inch	9/16 inch
1/2 inch	3/4 inch
3/4 inch	1 inch
1 inch	3 inch
1-1/4 inch	3 inch
1-1/2 inch	3 inch
2 inch	4 inch

Typical locations requiring tight bends are termination mount installations in hollow stud walls.

6. SUPPORTING

TracPipe® CounterStrike® Piping shall be supported in a workmanlike manner with pipe straps, bands, brackets or hangers suitable for the size and weight of the piping. **TracPipe® CounterStrike®** which passes over or through a structural member is considered to be supported by that member.

6A. VERTICAL RUNS

Spacing of supports is not to exceed 10 feet, requiring hangers only where the height of each floor is greater than 10 feet.

PIPING SIZE

6B. HORIZONTAL RUNS

Spacing of supports Hangers, supports and anchors-Piping shall be supported at intervals not to exceed those shown in Table: 4-2.

NOTICE: Some codes do not allow the use of plastic hangars for gas piping systems.

SPACING OF SUPPORTS

HORIZONTAL OR INCLINED RUNS

Table: 4-2

3/8 inch	4 FEET
1/2 inch	6 FEET
3/4 inch	8 FEET
1 inch	8 FEET
1-1/4 inch	8 FEET
1-1/2 inch	8 FEET
2 inch	8 FEET

SECTION 4.2

Section 4.2.1 HOW TO ASSEMBLE TracPipe® AutoFlare® FITTINGS

1. CUT-TO-LENGTH: Determine proper length. Cut through plastic jacket and stainless tube using a tube cutter with a sharp wheel. Cut must be centered between two corrugations. Use full circular strokes in one direction and tighten roller pressure slightly (a quarter turn) after each revolution. DO NOT OVERTIGHTEN ROLLER, which may flatten tube. Figure: 4-2

NOTICE: Due to the large diameter and depth of corrugation on sizes over 1 inch, tubing must be cut with a standard tubing cutter RIDGID™ 152 or equal using a **TracPipe® CounterStrike®** cutting wheel no. FGP-E-5272 (P/N E-5272 or equal).



Use of a small cutting wheel may flatten the first corrugation and make cutting and/or sealing of fittings difficult.

2. STRIP JACKET: Using a utility knife, strip back the jacket. See Table: 4-3 for maximum jacket strip length. Care should be taken to minimize the amount of jacket material removed. Figure: 4-3, 4-4

↑ CAUTION:

For your personal safety--Knife blade and cut tube ends are both sharp. Use care when cutting the jacket and handling the tube.

Table: 4-3
MAXIMUM STRIP LENGTH

Tubing Size		FST Fittings	Termination Type and PS-II Fittings
3/8"	-375	1-1/8"	1-1/2"
1/2"	-500	1-3/16"	1-1/2"
3/4"	-750	1-1/4"	1-3/4"
1"	-1000	1-3/8"	2"
1-1/4"	-1250	1-5/8"	2-1/4"
1-1/2"	-1500	1-5/8"	2-1/2"
2"	-2000	2"	2-3/4"




Figure: 4-2




Figure: 4-3




Figure: 4-4




Figure: 4-5

4. WRENCH FITTING: Place the adapter into the nut and engage threads. Note that the **TracPipe® AutoFlare®** fitting is designed to form a leak tight seat on the stainless tubing as you tighten the fitting. (The piloting feature of the adapter will not always enter the bore of the tubing before the tightening operation, but will center the fitting when tightened). Using appropriate wrenches, tighten the fitting until adapter bottoms and the resistance to wrenching increases greatly. The flare has now been created on the tubing end.

warning: Do not use any thread sealants for this connection. Sealants are to be used on the pipe thread only.

Table: 4-4

Flexible Pipe Size	Fitting	Torque Value
3/8" FGP-CS-375	FGP-FST-375	40 ftlb.
1/2" FGP-CS-500	FGP-FST-500	42 ftlb.
3/4" FGP-CS-750	FGP-FST-750	45 ftlb.
1" FGP-CS-1000	FGP-FST-1000	75 ftlb.
1-1/4" FGP-CS-1250	FGP-FST-1250	150-200 ftlb.
1-1/2" FGP-CS-1500	FGP-FST-1500	200-250 ftlb.
2" FGP-CS-2000	FGP-FST-2000	250-300 ftlb.

 INSTALL FITTING NUT: Slide nut over cut end: place two split-rings into the first corrugation next to the tube cut. Slide nut forward to trap the rings. Figure: 4-5




Figure: 4-6


5. FINAL TORQUE: Tighten nut and adapter to the torque values shown in Table 4-4. When a torque wrench is not available, use the following method: Tighten nut and adapter as though you were making up a flared tubing joint. Note relation between hex flats at this point and continue to tighten for two additional hex flats (one-third turn) to obtain required torque and final leak-tight seal. Figure: 4-6

Section 4.2.2 HOW TO ASSEMBLE TracPipe AutoSnap FITTINGS

____WARNING: These instructions must be followed for installing **TracPipe® AutoSnap®** fittings to **TracPipe® CounterStrike®** flexible gas piping.


⚠WARNING: Do not use pipe sealants on any part of these fittings except the NPT threads. Use of pipe wrenches is not recommended and may cause damage to the fittings. Use adjustable or open end wrenches whenever possible.

1. CUT PIPE: Determine proper pipe length and cut through the plastic jacket and stainless steel pipe using a tubing cutter with a sharp wheel. Use full circular rotations in one direction, gradually tightening roller pressure after each revolution until a clean cut is obtained. Avoid over-tightening roller as this may flatten the crowns of the corrugations and interfere with a gas tight seal. Inspect pipe for a clean cut without tears or distortion.



NOTICE: Due to the corrugation depth on pipe sizes over 1", a RIDGIDTM 152 or equal tubing cutter with a special, hardened *TracPipe® CounterStrike®* FGP-E-5272 cutting wheel must be used or damage to the pipe corrugations will occur making sealing difficult. A RIDGID™ plastic cutting wheel is not suitable, and will chip/ break.


2. STRIP JACKET: Using a utility knife with a sharp blade, strip back the jacket so <u>THREE</u> corrugation peeks are exposed for straight fittings and couplings and strip <u>FIVE</u> corrugations for termination fittings. This is critical for proper insertion of pipe into fitting. Figure: 4-7



A CAUTION: Knife blade and pipe ends are very sharp. Use care when stripping jacket and handling tubing.

INSTALLING STRAIGHT FITTINGS AND COUPLINGS

3. NPT CONNECTION: For couplings, skip this step. For straight fittings, connect NPT threaded end to termination point, i.e. manifold or appliance, using thread sealant. Tighten fitting to termination point using an adjustable wrench on the body hex only. Figure: 4-8



Do not make this connection by tightening the nut, or the assembly of the fitting to the pipe will not be possible without disassembly and reassembly of the fitting components.

4. PIPE TO FITTING CONNECTION: This step applies to straight and coupling fittings. Loosen nut on the fitting 1 to 1-1/2 turns. Straighten pipe end and insert into the back of the fitting until it snaps into place. Figure: 4-9 While holding the tubing firmly into the fitting, tighten the nut by hand to capture the first corrugation. If inserted correctly, a gradual resistance to tightening by hand will be felt. If a dead stop is felt, the pipe is not inserted properly, back off nut, make sure the pipe is in completely and straight and re-tighten by hand to confirm proper fit. Check to make sure the tubing is captured by pulling on the tubing. If the tubing has been captured, use adjustable wrenches and continue

to tighten the nut to the specified torque value or until resistance has greatly increased. Table 4-5 When the nut is fully tightened leak tight, there should be no more than $\frac{1}{2}$ to 1 thread showing behind the nut.

5. USE A SECOND ADJUSTABLE END WRENCH ON THE FITTING BODY AS A BACK UP WHILE TIGHTENING THE NUT. HOLDING THE NUT AND TIGHTENING BY TURNING BODY MAY CAUSE THE PIPE TO TWIST. OVER TIGHTENING THE NUT MAY CAUSE DEFORMATION THAT WILL NOT ALLOW THE FITTING TO BE REUSED.

Size	Min Torque (ft-lbs)
3/8"	25
1/2"	30
3/4"	40
1"	45
1 1/4"	55
1 1/2"	75
2"	90

Table 4-5

O

0

B

INSTALLING FLANGE TERMINATION FITTINGS


- A. MOUNT FLANGE: Mount flange to desired location on wall stud or floor using appropriate size screws to provide a firm mount. Figure: 4-10 Do not attach the fitting to the flange at this point. This will be done after the fitting to pipe connection has been completed. Insert pipe through the back of the flange after preparing pipe in accordance with steps 1 thru 3, making sure to strip jacket to expose FIVE corrugations.
- **B. PIPE TO FITTING CONNECTION:** Attach fitting to pipe following all instructions in step 5. Figure:4-11 Once the fitting has been tightened to the pipe, slightly loosen this connection until the fitting can be rotated on the pipe. Figure: 4-12 Screw the fitting on to the flange and tighten. Holding the flange fitting nut, re-tighten the body. Figure: 4-13

⚠ CAUTION: This step must be followed to avoid excessive twisting of the pipe when tightened.

Figure: 4-10



Figure: 4-12



INSTRUCTIONS FOR RE-USING FITTINGS

If there is a leak in the fitting, the most probable cause is that the pipe was not properly prepared and has a tear or excessive deformation in the last corrugation that interferes with proper sealing. To remove the pipe from the fitting, strip the jacket back behind the fitting nut/ flange about 1". Disassemble the fitting completely, and push pipe through the nut to expose the snap ring. Gently pry the ring off of the pipe, and remove pipe from fitting. Inspect the ring for damage, and replace if necessary. Since the ring has been compressed into the back of the body, it must be re-sized before reusing. This is achieved by carefully spreading the ring open by hand or using small pliers. After opening up the ring, insert into fitting nut.

If it inserts without resistance, it must be opened further. Once the ring has been installed, thread the nut and body back together loosely. Re-cut the tubing and prepare per steps 1 thru 3, and assemble to fitting.

CAUTION: Knife blade and pipe ends are very sharp. Use care when stripping jacket and handling tubing.



AutoFlare® (Patented) - The Fitting is the Flaring Tool

SECTION 4.2.3 — TROUBLE SHOOTING FITTING CONNECTIONS

- 1. The tubing cut is the critical step in the fitup procedure. Always cut in a straight section of piping, rather than an area you have bent. Use light roller pressure applied on every revolution to cut tube evenly around its surface. Remember that this tube has a thinner wall than the copper tube you are accustomed to cutting. A sharp blade is very important, and it will be helpful to reserve one cutter for stainless steel only.
- 2. If the fitting connection cannot be made to seal upon applying torque per the instructions in Section 4.2, continue to tighten an additional quarter to a half turn. If leakage continues, do not continue to apply torque. Disassemble the fitting and inspect the sealing surfaces. The most likely cause of leakage is foreign material on the sealing surfaces. Wipe both fitting and tubing flare with a clean cloth. Inspect the formed flare on the tubing end, which should appear round when compared with the split ring washers and the nut in place. If any deformation is noted, the tubing can be recut and the fitting re-attached. The patented Autoflare fitting has an insert which is self piloting and does not require special tooling to make a leak proof fitting.
- 3. REASSEMBLY PROCEDURE- When reattaching the AutoFlare fitting, it is only necessary to re-insert the split rings into the space between the first two corrugations and to pull the nut back over the rings into position. The adapter can then be conveniently re-threaded into the nut and torqued as before. If the nut cannot be pulled into place, examine the split-rings, which may have been "coined" by the first torque operation. If this is the case, simply reverse the split-rings positioning to align with the nut and continue the assembly process. If the fitting is reattached more than three times, or if the nut cannot be pulled over the rings in any position, then the split-rings must be replaced. Packets of spare split-rings are available (P/N FGP-RING-SIZE) and the remaining fitting parts can be re-used.

SECTION 4.3 — ROUTING OF TUBING

Depending on local building codes and construction practice, Flexible gas piping can be routed:

 Beneath floor joists, through floor and ceiling joists, along side of floor and ceiling joists. This is the typical location for residences and commercial buildings with basements and for multi-floor sytems. Multiple tubing runs may be bundled. Exterior/interior wall cavities. Hollow interior wall cavities are the preferred location for vertical runs of tubing. Piping runs may be installed in insulated walls. For bat type insulation the piping may be placed within or in front of the insulation facing sheet. Piping restrained by rigid foam type insulation shall be protected along the entire vertical run in accordance with Section 4.4.1.

<u>ACAUTION:</u> Exposed stainless steel that may come in contact with spray foam insulation must be wrapped in self bonding silicone tape in accordance with Section 4.3.2.

- 3. Through approved conduit under ground or under building slabs. When piping runs are located below grade or under a concrete slab, the *TracPipe® Counter-Strike®* shall be routed within a non-metallic water-tight conduit. No tubing joints are permitted within the conduit. Gas piping runs beneath building slabs must be both sleeved and vented as per local codes. See Underground Installations Section 4.9 for underground use of *TracPipe PS-II. TracPipe PS-II* meets code requirements for underground and under building slab installation.
- 4. Clearance holes for routing the piping through studs, joists, plates etc. shall have a diameter at least 1/2 inch larger than the outside diameter of the piping. When a structural member must be drilled, conformance to building codes must be followed. No structural member shall be seriously weakened or impaired by cutting, notching or otherwise altering the member. Minimum drill hole sizes are listed in Table: 4-6. TracPipe® CounterStrike® shall not pass through a bored hole through which any metallic pipe, metallic tube, electrical conductor, electrical or electronic cable or electrical metallic raceway also passes.

Table 4-6
TUBING SIZE DRILL HOLE SIZE

3/8 inch	1-1/8 inch
1/2 inch	1-3/8 inch
3/4 inch	1-1/2 inch
1 inch	1-3/4 inch
1-1/4 inch	2-1/4 inch
1-1/2 inch	2-1/2 inch
2 inch	3 inch

5. METAL STUDS

For installations involving horizontal runs through galvanized steel studs, use the plastic grommets supplied by the stud manufacturer

6. Care shall be taken to route the tubing in areas that are least susceptible to potential threats wherever possible. Flexible gas piping larger than 1 inch nominal internal diameter installed within hollow cavity walls of 2 x 4 construction shall be protected along the entire concealed length.

SECTION 4.3.1 — CONCEALED LOCATIONS FOR FITTINGS — GENERAL PROVISIONS

The **TracPipe® AutoFlare®** mechanical attachment fittings have been tested and are listed per the requirements of ANSI LC1 and CSA 6.26 Standard (USA and CANADA). This specification provides test requirements which certify fittings for concealed installations and connections to appliances where concealing the fittings is the only practical alternative.

These guidelines address some of the known situations which may require the use of a concealed fitting. While accessibility of fittings may be desirable, there are often situations where concealing the fitting is the only practical option. This guide cannot address all applications of concealed fittings but provides instead typical instructions to demonstrate the principles which apply to fittings, listed for installation in concealed locations.

EXCLUSIONS:

 Manifold Stations (for 2 PSI systems) which include the multiport manifold, shut off valve, and pressure regulator <u>shall not</u> <u>be installed in concealed locations</u> regardless of the qualifications of tubing fittings.

NEW INSTALLATIONS:

 CSST may be connected to steel piping systems through threaded pipe connections. This can be a stub-out to an appliance connection or outdoors to a meter, etc. 2. Flexible piping connections to fireplace "key valves" can be located in a concealed location, when accessibility is not readily provided. See Figures:4-14 and 4-15




Figure: 4-14




Figure: 4-15

3. Multiple gas outlets – when multiple outlets are supplied from a single run of piping, each downstream outlet branch can be connected to the main run using a tee fitting which can be located in a concealed location. Figure: 4-16.

MODIFICATIONS TO INSTALLED SYSTEMS:

1. New ceilings in unfinished rooms/basements.




Figure: 4-16 Multiple outlets along main tubing run

Flexible piping fittings originally installed in accessible ceiling locations can be concealed at a later date in the event that a ceiling is installed. Precautions shall be taken to ensure that the newly concealed piping and fittings are adequately protected from accidental puncture in accordance with the instructions in this guideline.

- 2. Extensions to existing tubing runs-A tubing run can be modified to permit an extension to another appliance location provided there is sufficient capacity to supply both appliances at the same time. If an accessible location for the modification is not available, the existing tubing run can be modified with a tee fitting, resulting in a concealed fitting.
- Repairs to existing tubing runs-Damaged tubing runs shall be repaired in accordance with instructions in this guide (Section 5.2).
 The repair can result in a line splice which may ultimately be located in a concealed location.

SECTION 4.3.2 — OUTDOOR INSTALLATION ISSUES

The **TracPipe® CounterStrike®** jacket is resistant to UV and is able to withstand exposure to long periods of sunlight. ANSI/IAS LCI-CSA 6-26 contains test requirements determining suitability for exposure of CSST piping systems to outdoor environments. **TracPipe® CounterStrike®** is certified to this standard and is fully qualified for outdoor installations.

- 1. When installed outdoors, the plastic jacketing shall remain intact as much as practical for the given installation. Any portions of exposed stainless steel shall be wrapped with self bonding silicone tape sealing the fitting connection to prevent later corrosive attack by acid wash or chloride based compounds. Figures: 4-17 and 4-18.
- 2. When **TracPipe® CounterStrike®** is installed in a swimming pool mechanical

room or exposed to a corrosive environment which may be harmful to the tubing, all exposed portions of the stainless steel tubing shall be wrapped with self-bonding tape. Figures: 4-17, 4-18.

3. When installed along the side of a structure (between the ground and a height of 6 feet) in an exposed condition, the **TracPipe® CounterStrike®** shall be installed in a location which will not subject the piping to mechanical damage or be protected inside a conduit or protective cover.

NOTICE: For support and protection, **OmegaFlex**® recommends that outside runs along the side of a building shall be clipped securely to the wall or other structural component.

- 4. **TracPipe® CounterStrike®** SHALL NOT BE BURIED DIRECTLY IN THE GROUND OR PENETRATE CONCRETE UNLESS IT IS SLEEVED INSIDE OF A NON-METALLIC (PVC) WATER TIGHT CONDUIT or use **TracPipe PS-II**. The conduit shall be sealed at any exposed end to prevent water from entering. See instructions for underground installations Section 4.9.
- When installed underneath mobile homes or in crawl spaces, *TracPipe® Counter-Strike®* shall be installed in accordance with these outdoor instructions.




Figure: 4-17-Wrapping with self bonding silicone tape - begin on jacket.



Figure: 4-18 Wrapping with self bonding silicone tape - end on nut.

SECTION 4.4 — PROTECTION


The flexible gas piping must be adequately protected from puncture, shear, crush or other physical damage threats. The tubing shall be protected at points of support and when passing through structural members such as studs, joists and plates in accordance with this section. PROTECTION IS REQUIRED WHENEVER THE TUBING IS CONCEALED, RESTRAINED, AND WITHIN 3 INCHES OF A POTENTIAL THREAT. If the tubing requires protection, the following measures should be taken.

SECTION 4.4.1 — STRIKER PLATE REQUIREMENTS

 Install shielding devices i.e. striker plates to protect the tubing from penetration by drill bits, nails, screws, etc. in those areas where the tubing will be concealed and will not be free to move to avoid such puncture threats.

NOTICE: Only CSA approved hardened striker plates listed for CSST systems may be used.

a. At support points and points of penetration less than 2 inches away from any edge of a stud, joist, plate, etc. shielding is required at the area of support and within 5 inches of each side (if appropriate). Use a half striker or a full striker plate in these locations. Figure: 4-19.



b. At support points and points of penetration 2 to 3 inches from any edge of stud, joist plate, etc. shielding is required throughout area of support. Use a quarter striker plate in these locations. Figure: 4-8.

use include: (but are not limited to) outside walls of buildings with sheathing in place, between floors with enclosed joist areas, and retrofits in existing buildings with walls in place. Steel pipe having an inner diameter at




Figure: 4-20 Shielding Requirements at Support Area when Points of Penetration are 2-3 inches from any Edge of a Stud, Joist, Plate, etc.

c. Hardened steel striker plates provide the required protection through building structures as described above. Type RW Floppy steel conduit shall be installed as additional protection at termination points. Figure: 4-21.





Figure: 4-21

- d. When tubing is routed horizontally between studs, install quarter striker plates at each stud and floppy galvanized steel conduit (spiral metal hose) along the entire length.
- e. Schedule 40 steel pipe has been tested by CSA International and found acceptable for puncture protection. Steel pipe can be used where standard striker plates cannot reasonably be installed. Examples of this type of

least one-half inch larger than the **TracPipe® CounterStrike®** O.D. is approved by CSA International for this use as an alternate to striker plates. Protection must extend 5 inches beyond the penetration of the structural member(s). A 12 inch pipe length is appropriate for penetration of a single stud. OmegaFlex recommends the use of standard striker plates where the building construction permits their installation. See Chart for pipe sizes.

CounterStrike Size	Steel Pipe Size
3/8 inch	1-1/4 inch
1/2 inch	1-1/4 inch
3/4 inch	1-1/2 inch
1 inch	2 inch
1-1/4 inch	2-1/2 inch
1-1/2 inch	2-1/2 inch
2 inch	3-1/2 inch

- The best protection is to install the tubing in those out of the way areas where testing has shown no protection is necessary, for example:
 - a. Where the tubing is supported more than 3 inches from any outside edge of a stud, joist, plate, etc. or wall surface. Figure: 4-22.
 - Where any non-restrained tubing can be displaced from the direction of potential penetration.



No Shielding Requirement at Support Area when Points of Penetration are greater than 3 inches from any Edge of a Stud, Joist, Plate, etc.

and is not concealed by wallboard or ceilings.d. In unfinished garage walls where tubing is exposed.

SECTION 4.4.2 —THROUGH WALL PENETRATIONS


- TracPipe® CounterStrike® meets building code requirements (ASTM E84) with respect to flame spread and smoke density. This permits installation in drop ceilings used as return air plenums without jacket removal.
- 2. For through wall penetration fire stop instructions refer to the UL classification requirements shown in Appendix A. When passing through a fire stop (2 hr. wall) the jacket shall not be removed. Seal between building and *TracPipe® CounterStrike®* with an approved 3M type CP-25 or equivalent caulk.
- 3. **TracPipe® CounterStrike®** has through wall penetration UL Classifications for 1, 2, 3 and 4 hour requirements depending on materials and type of construction. See Appendix A.


NOTICE: For TracPipe PS-II tubing with black outer jacket, the installer shall address local building codes with respect to flame spread and smoke density regulations for


non-metallic materials. OmegaFlex® recommends either removing the black jacket or transitioning to the CounterStrike® product when passing through areas such as drop ceiling return plenums.

SECTION 4.5 — METER CONNECTIONS


- 1. Meters which depend on the service and house piping for support shall not be directly connected to the flexible piping. Instead, use a meter termination fitting or termination mount fitting with steel pipe for the outdoor portion of the connection. For mounting of meters, all fastener locations should be used when installing the flange or mounting plate. Figure: 4-23 and 4-24.
- 2. Meters which are independently supported with a bracket can be directly connected outdoors with TracPipe® CounterStrike® Figure: 4-25. If practical, direct connections shall include a 3 to 6 inch additional length of tubing to accommodate differential settling and meter movement. No mechanical protection of the tubing is required for outdoor connections. **NOTICE:** Prior to installing TracPipe® CounterStrike® directly to a meter, ensure that the local utility allows this practice and meter is independently supported as some utilities have regulations specifying meter attachments. Any exposed sections of stainless steel piping must be wrapped with a self-bonding silicone tape. This is especially important with masonry construction. Figure: 4-23.-A sleeve is required for TracPipe® CounterStrike® penetrations of masonry construction and recommended for wood frame construction.







Termination Mount (Mount on one stud.)



Stud Bracket (Mount between two studs.)

Figure: 4-24
Meter Mounting Accessories




Figure 4-25

SECTION 4.6 — APPLIANCE CONNECTIONS

A listed termination outlet (termination mount, flange fitting, or recessed wall box) are designed to be used at all floor & hollow wall piping outlets used for moveable appliances and quick disconnect devices. The termination outlets are intended to simplify the installation of gas connections for moveable appliances and minimize the need for concealed fittings. The flange fitting or plate shall be securely fastened in place during rough-in. It may be attached to a brace spanning between studs for a wall location, or directly to the floor Figure: 4-26. The flange may also be mounted with a flange L-bracket, which is nailed or screwed to a stud.

As an alternate to using a listed termination outlet for moveable appliances, a rigid termination can be made by transitioning the *TracPipe® CounterStrike®* to rigid black pipe at a suitable location. The rigid pipe stub-out must be secure-

ly fastened to the wall or floor using a pipe flange or other rigid mounting component. Another option is to use a termination mounting bracket fastened to the block wall and make the drop with *TracPipe® CounterStrike®*. Final connection is with a flexible appliance connector.

- 1. MOVABLE APPLIANCE CONNECTIONS (SUCH AS RANGES AND DRYERS) SHALL BE MADE USING APPROVED FLEXIBLE APPLIANCE CONNECTORS. Figure: 4- 27. See also recessed wall box Section 4.6.1.
- 2. FIXED APPLIANCE CONNECTIONS MAY BE DIRECTLY CONNECTED TO THE FLEXIBLE GAS PIPING SYSTEMS (in most jurisdictions). When the fixed appliance is located in a secure, dedicated space, such as a basement, attic, garage or utility closet, the flexible piping may be directly connected to the appliance shut-off valve without installation of a flange fitting or flexible appliance connector.





Figure: 4-27
Stainless Steel Gas Connector Connection to a Movable Gas Appliance

SECTION 4.6.1 — RECESSED WALL BOX


NOTICE: This *TracPipe® CounterStrike®* Gas Outlet Box has been tested and approved for 1 and 2 hr Fire Stop Systems in accordance with UL 1479. It installs with zero clearance for a finished appearance in laundry rooms, kitchens and mechanical rooms, and provides a rigid attachment point for appliance connectors serving movable appliances. This box is not suitable for use with black iron pipe or any CSST brand other than *TracPipe® CounterStrike®*.

Wall Box Installation Instructions

Remove knockout for appropriate size valve. The 3/8 inch and ½ inch size use the small knockout and the ¾ inch size uses the large knockout. Install *TracPipe® CounterStrike®* gas piping and cut to desired length using a standard tubing cutter with a sharp wheel. Strip jacket back approx. 2 inch. Inspect pipe for a clean cut without tears.




CAUTION: FGP-WBTM is fire rated to UL 1479. This box has been designed for use with *TracPipe® CounterStrike®* Flexible Gas Piping as an appliance termination and is not suitable for connection to any other CSST brand or black iron pipe. Installers must be trained on *TracPipe® CounterStrike®* before installing this product.



2. Remove box cover and slip locknut and box over end of pipe. Figure: 4-28

NOTICE: Mounting tabs are oriented for a single layer of drywall. When two layers are used for some 2-HR rated walls, remove screws on tabs and invert mounting tabs.






Figure: 4-29

3. Disassemble nut and split rings from valve. Figure: 4-29




Figure: 4-30

4. Slip nut over end of pipe and insert split rings into valley of the first corrugation. Figure: 4-30




Figure: 4-31

5. Thread 90 degree ball valve onto nut and tighten so valve outlet faces forward. It is recommended that crescent wrenches be used to avoid damaging valve or nut. Figure: 4-31 **Do not use thread seal-ants on this connection.**




Figure: 4-32

- Slide box up and over the threads on the bottom of the nut and mount box firmly to stud. Provide full support by fastening both mounting tabs to structure where required by local codes.
- 7. Secure valve assembly to box with locknut. Figure: 4-32




Figure: 4-33

8. Install box cover after completion of drywall. If the gap between the edges of the box and the drywall is less than 1/4", no fire caulking is required. Figure: 4-33

NOTICE: These instructions must be used in conjunction with the *TracPipe® Counter-Strike®* Design and Installation Guide. *TracPipe® CounterStrike®* flexible gas piping material must only be installed by a qualified person who has been trained through the *TracPipe® CounterStrike®* Gas Piping Installation Program.

SECTION 4.6.2 — PAD MOUNTED **EQUIPMENT, ROOF TOP EQUIPMENT**

1. Gas equipment mounted on concrete pads or blocks such as L.P. tanks, gas air conditioners, heat pumps, pool heaters, NGV refueling stations and gas generators, may be connected to the TracPipe® Counter-Strike® system at a termination fitting using either rigid pipe or an approved outdoor appliance connector. Direct connection of TracPipe® CounterStrike® to pad mounted equipment is permitted when the CSST is securely supported and located where it will be protected from physical damage. Follow local and state codes. Any portions




Figure: 4-34 Short (1-6 foot) outdoor connection to roof mounted equipment

of exposed stainless steel shall be wrapped with self bonding silicone tape sealing the fitting connection. Figures: 4-17 and 4-18. When the appliance is mounted on vibration isolations pads the TracPipe® Counter-Strike® shall be terminated with a listed termination fitting and the appliance shall be connected to the gas piping system with a listed appliance connector.

2. No special mechanical protection of the piping is required for connection to roof top

- equipment. Whenever possible, roof penetrations shall be located within 6 feet of the equipment to be connected as shown in Figure: 4-34. Long runs of tubing shall be supported with non-metallic blocks at the support interval listed in Table: 4-2, and raised above the roof a distance determined by local code/practice. Figure: 4-35. The blocks are to be attached to the roof surface in accordance with the roofing manufacturer's instructions.
- 3. TracPipe® CounterStrike® may be supported with strut/channel running from block to block beneath the flexible gas pipe. Galvanized shallow channel (13/16 inch) with splice plates at joints and bends provides a secure, damage resistant "track". With metallic strut support, blocks can be reduced to every 8 feet. The TracPipe® CounterStrike® should be firmly attached to each block with metallic clamps designed for the strut or appropriate fastening mechanism. Figure: 4-36. Black cable ties (UV resistant) at intermediate points facilitate rolling out the TracPipe® CounterStrike®.





Figure: 4-36

4. Piping run vertically up the side of the building shall be protected in accordance with the Section 4.3.2 Outdoor Installation Issues.



CODE REQUIREMENTS AND/OR WINTER ICE BUILDUP

SECTION 4.6.3 — OUTDOOR APPLIANCES — BARBEQUE GRILL AND GAS LIGHT CONNECTIONS

- Movable grills shall be connected using an approved outdoor appliance connector which shall be attached to the flexible piping system at either a termination mount fitting, a transition to a steel nipple, or a quick connect device such as the M. B. Sturgis Model 3/375 shown in Figure: 4-37-The quick-connect outlet shall be installed in accordance with manufacturer's instructions.
- 2. Permanently mounted grills located on decks shall be connected with the *TracPipe® CounterStrike®* system as shown in Figure: 4-38-and in accordance with this guide. The outdoor portion of the piping shall be supported against the side of any of the inside deck joists. If the elevation of the deck is below the top of the foundation, any exposed piping shall be protected using water-tight non-metallic conduit.

3. Permanently mounted lights located on decks shall be connected to the piping system the same as permanently mounted grills shown in Figure: 4-38 and in accordance with the manufacturer's instructions.




Figure: 4-38

4. Yard mounted lights shall be connected to the *TracPipe® CounterStrike®* system as shown in Figure: 4-39. All piping installed below grade shall be protected by non-metallic, water-tight conduit or *TracPipe PS-II* for underground use. Exposed ends of the conduit shall be sealed against water entry.




Figure: 4-37




Figure: 4-39

Section 4.6.4— FIREPLACE INSTALLATIONS

- TracPipe® CounterStrike® shall not be directly routed into a metallic gas appliance enclosure utilizing a metallic vent which penetrates a roofline. The TracPipe® CounterStrike® connection shall be made outside of the metallic gas appliance enclosure to a segment of rigid metallic pipe, a stub-out or a termination fitting (Figure 4-40).
- 2. **TracPipe® CounterStrike®** may be used to deliver gas directly to the control valve for approved unvented appliances, heat generating fireplaces with side-wall venting, gas logs used in masonry fireplaces, and pre-fabricated fireplace inserts with non-metallic venting.
- 3. **TracPipe® CounterStrike®** connections to approved unvented appliances and sidewall vented fireplaces may be made to the shut-off valve located in the control area beneath the burner unit without removal of the polyethylene jacket. When connecting to decorative gas logs the jacket shall be removed inside the fire box. Stainless steel melting temperatures (2000o F) are consistent with black iron.

↑ CAUTION: For gas log lighter installations in all-fuel fireplaces, the *TracPipe®* CounterStrike® run MUST be terminated at the key valve or another location outside the fireplace.

- 4. When it is permitted (see Item 1) to install *TracPipe® CounterStrike®* through sheet metal enclosures, such as those commonly used in decorative gas fireplaces, the manufacturer's recommendation is to leave the protective polyethylene jacket in place through the sheet metal penetration. The *TracPipe® CounterStrike®* should be clipped to the building structure at a suitable location outside the fireplace to limit the amount of motion after installation. If additional protection is required, a short piece of floppy conduit or PVC pipe may be used between the jacket and the enclosure.
- 5. In masonry fireplace installations of decorative gas appliances (log sets) it is recommended to leave the polyethylene jacket in place throughout the masonry penetration providing a non-metallic sleeve for the flexible stainless steel. Caulking can then take place between the jacket and the penetration at interior and/or exterior locations. Remove the jacket inside the firebox. If additional protection is required, the *TracPipe® CounterStrike®* may be sleeved using PVC pipe in addition to the included jacket.
- 6. The FGP-FPT may be used in all applications where it is desirable not to penetrate the enclosure with tubing. Figure: 4-41.

METAL FABRICATED FIREPLACE




Figure: 4-40




Figure: 4-41





Figure: 4-42

SECTION 4.7 — MANIFOLD & REGULATOR STATION

The use of a central manifold and regulator station is recommended for elevated pressure systems which are typically installed in a parallel arrangement to take advantage of the capacity of the regulator. Figure: 4-42. Manifolds are available with the *TracPipe® CounterStrike®* system, or the use of black iron pipe and tee fabricated manifolds is permitted with this system. The manifold/regulator station should be located nearby the largest gas consuming appliances, typically the furnace or boiler and the water heater in order to allow short runs to these units.

The manifold station MUST be located in an accessible location because of the shut-off valve(s) and regulator it contains. The manifold station may be contained in an enclosure box called a gas load center. Figure: 4-43. Optional gas shut-off valves may be mounted on the manifold for each appliance run.

Manifolds installed on low pressure systems or in locations removed from the regulator may be concealed.



Gas Load Center Figure: 4-43

SECTION 4.8 — REGULATORS AND ELEVATED PRESSURE SYSTEMS

A tubing system used at gas pressures exceeding 1/2 PSI but serving appliances rated for 1/2 PSI maximum, shall contain a pounds-to-inches regulator to limit the downstream pressure to no more than 1/2 PSI. Gas pressure regulators shall comply with a nationally recognized standard for pressure regulators.

Regulators used to reduce elevated system pressures for use by appliances must also conform to the following:

- 1. Must be sized to supply the required appliance load. Section 4.8.2
- 2. Must be equipped with an acceptable vent limiting device, supplied by the manufacturer, or be capable of being vented to the outdoors. *OmegaFlex*® ships all regulators with vent-limiters installed.
- 3. Must be installed in accordance with manufacturers instructions. When a vent-limiter is used the regulator must be mounted in an upright position. Install the regulator properly with gas flowing as indicated by the arrow on the casting.
- 4. Must be installed in a fully accessible area with an approved shut off valve ahead of regulator. A union will enable removal of the regulator if the location does not otherwise permit removal for servicing. The ability of the *TracPipe® AutoFlare®* or *AutoSnap®* fitting to allow disassembly and reattachment provides for regulator removal in most instances.
- 5. Line regulators do not vent gas under normal operating conditions. Any regulator found to be venting gas should be replaced immediately. Vent-limiters are required to limit venting in the event of a diaphram failure, within the regulator, to limits identical to those imposed on a gas appliance control valve.


6. For outdoor installations remove the vent limiter and mount regulator with the vent outlet pointing down to prevent the entrance of water. A plastic cap FGP-CAP-3 is available, for outdoor installations permitting the regulator to be mounted in an upright position, for some regulator models.

SECTION 4.8.1 REGULATOR ADJUSTMENTS

- Regulators can be adjusted to deliver different outlet pressures within a limited range. The range is determined by the spring installed.
- 2. Adjustment can be accomplished by first removing the regulator seal cap to expose the adjusting screw. Turning the screw clockwise will increase outlet pressure, turning it counter-clockwise will decrease pressure.

must be at least the same size as the regulator vent connection, and cannot exceed a length of 30 feet. The vent shall be designed to prevent entry of water, insects or other foreign materials that could cause blockage of the line. DO NOT VENT TO APPLIANCE FLUE OR BUILDING EXHAUST SYSTEM. DO NOT VENT TO PILOT LIGHT.

3. If spring adjustment will not produce desired outlet pressure, check to make sure supply pressure is at least equal to desired outlet pressure plus pressure drop of the regulator. If supply pressure is adequate, consult factory if adjustment still can not be made. Do not continue to turn regulator adjusting screw clockwise if outlet pressure readings do not continue to increase. THIS MAY RESULT IN OVER-FIRING DUE TO LOSS OF PRESSURE CONTROL, SHOULD THERE BE A SUBSEQUENT INCREASE IN INLET PRESSURE.



SECTION 4.8.2 REGULATOR SUPPLY PRESSURE AND CAPACITIES DROP FOR SINGLE AND MULTIPLE APPLIANCES

NATURAL GAS 0.64 SPECIFIC GRAVITY

REGULATOR CAPACITIES expressed in CFH (m3/h) 0.64 Specific Gravity Gas

						Operating	Inlet Pressure	
Regulator Application	Part Number	NPT SIZE	Maximum Single Appliance Load	Outlet Pressure Set Point	1/2 psi (34 mbar)	3/4 psi (52 mbar)	**1 psi (69 mbar)	***1-1/2 psi (103 mbar)
2 psig	FGP-REG-3	1/2"	140 (4.0)	8" w.c.	145 (4.1)	200 (5.7)	250 (7.1)	250 (7.1)
2 psig	FGP-REG-3P	1/2"	140 (4.0)	11" w.c.	93 (2.6)	172 (4.9)	225 (6.4)	250 (7.1)
2 psig	FGP-REG-5A	3/4"	300 (8.5)	8" w.c.	335 (9.5)	475 (13.5)	550 (15.6)	550 (15.6)
2 psig	FGP-REG-5P	3/4"	300 (8.5)	11" w.c.	211 (6.0)	391 (11.1)	511 (14.5)	550 (15.6)
2 psig	FGP-REG-7L	1"	900 (25.5)	8" w.c.	690 (19.5)	970 (27.5)	1000 (28.3)	1000 (28.3)
2 psig	FGP-REG-7L	1"	900 (25.5)	*11" w.c.	441 (12.5)	816 (23.1)	1000 (28.3)	1000 (28.3)

5 psig w/ OPD	FGP-REG-3L47	1/2"	125 (3.5)	8" w.c.	125 (3.5)	125 (3.5)	125 (3.5)	125 (3.5)
5 psig w/ OPD	FGP-REG-3L47	1/2"	125 (3.5)	*11" w.c.	105 (3.0)	125 (3.5)	125 (3.5)	125 (3.5)
5 psig w/ OPD	FGP-REG-3L48	1/2"	200 (5.7)	8" w.c.	160 (4.5)	200 (5.7)	200 (5.7)	200 (5.7)
5 psig w/ OPD	FGP-REG-3L48	1/2"	200 (5.7)	*11" w.c.	120 (3.4)	200 (5.7)	200 (5.7)	200 (5.7)
5 psig w/ OPD	FGP-REG-5AL48	3/4"	320 (9.1)	8" w.c.	320 (9.1)	320 (9.1)	320 (9.1)	320 (9.1)
5 psig w/ OPD	FGP-REG-5AL48	3/4"	320 (9.1)	*11" w.c.	245 (6.9)	320 (9.1)	320 (9.1)	320 (9.1)
5 psig w/ OPD	FGP-REG-5AL600	3/4"	425 (12.0)	8" w.c.	345 (9.8)	425 (12.0)	425 (12.0)	425 (12.0)
5 psig w/ OPD	FGP-REG-5AL600	3/4"	425 (12.0)	*11" w.c.	260 (7.3)	425 (12.0)	425 (12.0)	425 (12.0)
5 psig w/ OPD	FGP-REG-5AL601	1"	465 (13.2)	8" w.c.	375 (10.6)	465 (13.2)	465 (13.2)	465 (13.2)
5 psig w/ OPD	FGP-REG-5AL601	1"	465 (13.2)	*11" w.c.	285 (8.1)	465 (13.2)	465 (13.2)	465 (13.2)

^{*} Requires manual field adjustment of regulator to obtain 11" w.c. outlet pressure

^{**} Recommended sizing column for 2 psig Natural Gas TracPipe CounterStrike installations refer to Table N-5 Section 7.0.

^{***} Recommended sizing column for 5 psig Natural Gas TracPipe CounterStrike installations refer to Table N-6 Section 7.0.

(MBTUh values based on Gas with a heating value of 2520 BTU per cubic

foot)

REGULATOR CAPACITIES expressed in CFH (m3/h) 1.53 Specific Gravity Gas

						Operating	Inlet Pressure	
Regulator Application	Part Number	NPT SIZE	Maximum Single Appliance Load	Outlet Pressure Set Point	1/2 psi (34 mbar)	3/4 psi (52 mbar)	**1 psi (69 mbar)	1-1/2 psi (103 mbar)
2 psig	FGP-REG-3P	1/2"	91 (2.6) [229 MBTUh]	11" w.c.	60 (1.7) [152 MBTUh]	112 (3.2) [281 MBTUh]	146 (4.1) [368 MBTUh]	162 (4.6) [409 MBTUh]
2 psig	FGP-REG-5P	3/4"	195 (5.5) [491 MBTUh]	11" w.c.	137 (3.9) [345 MBTUh]	254 (7.2) [639 MBTUh]	332 (9.4) [836 MBTUh]	357 (10.1) [899 MBTUh]
2 psig	FGP-REG-7L	1"	584 (16.5) [1472 MBTUh]	*11" w.c.	286 (8.1) [721 MBTUh]	529 (15.0) [1334 MBTUh]	649 (18.4) [1635 MBTUh]	649 (18.4) [1635 MBTUh]

^{*} Requires manual field adjustment of regulator to obtain 11" w.c. outlet pressure

CONSULT THE REGULATOR MANUFACTURER FOR ADDITIONAL CAPACITY & PRESSURE DROP INFORMATION.

SECTION 4.8.3 — OVER-PRESSURE PROTECTION

At supply pressures in excess of 2-PSI the ANSI Z21.80 line regulator standard requires a means - (an over-pressure protection device (OPD) approved and tested with the regulator) to limit the downstream pressure to 2-PSI maximum, in the event of regulator failure.

To comply with the ANSI Standard and with all codes adopted in the US and Canada, all installations exceeding 2-PSI (primarily 5-PSI systems, but including all other elevated pressure installations higher than 2-PSI nominal) require a tested and approved overpressure protection device for use with the pounds to inches regulator. This requirement applies to line regulators but not to appliance regulators.

Regulators for 5 PSI systems must be shipped as an assembled unit from the factory, regulator with OPD attached. Consult the current **TracPipe® CounterStrike®** Price List for information regarding part numbers and capacity.

NOTICE: For systems operating above 5-PSI or incorporating regulators approved to a standard other than ANSI Z21.80 consult your local code authority regarding over-pressure protection requirements.

^{**} Recommended sizing column for 2 psig Propane TracPipe CounterStrike installations refer to Table P-3 Section 7.0.

SECTION 4.9 — UNDERGROUND INSTALLATIONS

1. CODE REQUIREMENTS

When gas piping runs are located below grade in contact with earth or other material that could corrode the piping, codes require that the gas piping shall be protected against corrosion.

When piping is installed underground beneath buildings, codes require that the piping shall be encased in a conduit and be vented in accordance with the code. Table: 4-7. The conduit shall be designed to withstand the superimposed loads. NO FITTINGS OR COUPLINGS ARE PERMITTED BENEATH BUILDINGS.

Table: 4-7

CounterStrike Size	Min. Conduit Size
3/8 inch	1-1/4 inch
1/2 inch	1-1/4 inch
3/4 inch	1-1/2 inch
1 inch	2 inch
1-1/4 inch	2-1/2 inch
1-1/2 inch	2-1/2 inch
2 inch	3-1/2 inch

Larger Conduit may be required to accommodate any bends in the piping.

2. MODEL CODES

TracPipe® PS-II (patented) installations conform to the underground fuel gas installation requirements of:
The National Fuel Gas Code NFPA 54
The International Fuel Gas Code
The Uniform Plumbing Code UPC®
The LP Gas Code NFPA 58

SECTION 4.9.1— GUIDELINES FOR UNDERGROUND INSTALLATIONS

 Lay TracPipe® PS-II in a trench. Install the gas piping with a substantially continuous bearing on the bottom of the trench, to the appropriate burial depth as defined in Table: 4-8 and shown in Figure: 4-44.

▲ CAUTION: TracPipe® PS-II systems must only be installed by a qualified person who has been trained through the TracPipe® CounterStrike® Gas Piping Installation Program. All installations must comply with local code requirements and the instructions contained in the TracPipe® CounterStrike® Design and Installation Guide.




Figure: 4-44

Minimum cover requirements for *TracPipe®* PS-II, Burial in inches (cover is defined as the shortest distance measured between a point on top surface of the outer sleeve and the top surface of finished grade, concrete or similar cover)

Location of buried TracPipe® PS-II	Minimum cover for direct burial without concrete encasement
All locations not specified below	18 inch
In trench below 2-in thick concrete or equivalent	12 inch
Under a building with interior slab	4 inch
Under minimum of 4-in. thick concrete exterior slab with no vehicular traffic and the slab extending not less than 6-in beyond the underground installation	4 inch
Under streets, highways, roads, alleys, driveways, and parking lots	24 inch
One and two family dwelling driveways and parking lots and used only for dwelling-related purposes	18 inch
In or under airport runways, including adjacent areas where trespassing prohibited	18 inch

Note: When encased in concrete, the concrete envelope shall not be less than 2 inches thick.

2. When transitioning **TracPipe® PS-II** from below grade or under slab to above grade, use the recommended minimum bend radius as shown in Table: 4-9.

TABLE: 4-9


	ENDED MINIMUM BENDING JS FOR <i>TracPipe® PS-II</i>
Tubing Size	Minimum Bend Radius R
	PS-II
3/8 inch	6 inch
1/2 inch	6 inch
3/4 inch	8 inch
1 inch	10 inch
1-1/4 inch	12 inch
1-1/2 inch	16 inch
2 inch	18 inch

- Recommended exposed clearance height (height to the *TracPipe® AutoFlare®* fitting above grade) is 12 inches when terminating at this point. For vertical runs up the outside of a building in traffic areas, protect the *TracPipe® PS-II* as explained in Section 4.3.2.
- 4. Avoid bending the above grade vertical portion of the *TracPipe® PS-II* piping beyond the minimum bend radius in Table:

- 4-9. To make a tighter bend in order to line up for a wall penetration, use a rigid fitting such as a malleable iron elbow.
- 5. **TracPipe® PS-II** is suitable for above ground installations and is resistant to U.V. exposure. Portions rising above grade should be rigidly supported by direct attachment to a wall or independent support, (e.g. metallic strut) or by connection to rigid downstream piping or fittings (e.g. at a meter or propane second stage regulator).
- 6. When installing **TracPipe® PS-II** underground through a foundation, the space between the outer jacket and the building shall be sealed to prevent entry of gas or water.
- TracPipe® PS-II can penetrate directly through a concrete slab unless other requirements are established by local codes concerning slab penetrations and firestop requirements.
- 8. **TracPipe® PS-II** can be transitioned to standard **TracPipe® CounterStrike®** piping above grade using **TracPipe® CounterStrike® AutoFlare®** fittings with a **TracPipe® PS-II** Coupling P/N FGP-UGC-SIZE. Remove the black plastic vent coupling on the standard **TracPipe® CounterStrike®** side.

- Alternatively use a malleable iron coupling for the transition.
- 9. **TracPipe® PS-II** must be transitioned above ground to standard **TracPipe® CounterStrike®** when routing through plenums or through firestop penetrations. The black **TracPipe® PS-II** sleeve is not qualified for these locations.
- 10. Venting of *TracPipe® PS-II* shall be in accordance with local codes to prevent

- the entrance of water, insects or foreign materials.
- 11. Typical underground installations for corrugated stainless steel tubing include, but are not limited to:
 - Pool and spa heaters
 - School science laboratories
 - Gas service to outbuildings
 - Gas lamp posts and grills






Figure: 4-45

SECTION 4.9.2— TRACPIPE PS-II


- TracPipe® PS-II is a patented system suitable for above ground and underground use. It is designed with our standard CSST tubing and incorporates an internally ribbed sleeve (conduit), and specially designed end fittings that provide vent capability at either end of a piping run in the event of a leak in the CSST. Figure: 4-45
- 2. **TracPipe® PS-II** complies with all model code requirements for underground/under slab burial and carries the following listings / certifications:
 - ICC-ES PMG-1052 Listing LC1023 PMG Listing Criteria
 - IAPMO tested and UPC listed for underground use per IGC 201-2004
 - CSA listed to ANSI/CSA LC-1 for above ground use.

NOTICE: The ANSI /CSA LC-1
Standard has no provisions for evaluating CSST for direct burial.

3. For above ground *TracPipe® PS-II* installations, the installer shall meet local build-

- ing codes with respect to flame spread and smoke density regulations for non-metallic materials. *TracPipe® PS-II* is not suitable for use in return air plenums or through penetration fire stop systems per UL classification requirements.
- 4. **TracPipe® PS-II** is supplied in standard lengths on reels or custom cut lengths. Standard reel lengths are 100, 150, and 250 feet (100 foot lengths for sizes up to 1 inch.)
- 5. **TracPipe® PS-II** lengths can be spliced together by using available couplings. All metallic portions of the fittings underground shall be mastic-wrapped to conform to local codes for under ground piping. Be certain prior to back-filling that no metallic portions of the piping system will be exposed to earth. **No fittings or couplings are permitted under building slabs.**
- 6. When pressure testing *TracPipe® PS-II*, it is necessary to remove at least one fitting vent plug to insure proper test results on the stainless steel tubing. Codes do not require pressure testing of the sleeve. If local jurisdictions require the sleeve to be tested, do not exceed the pressure of the pipe (25 PSI maximum).

SECTION 4.9.3— TRACPIPE PS-II FITTING ATTACHMENT



 TracPipe® PS-II is constructed from OmegaFlex® standard stainless steel fexible gas pipe sleeved in a fully vent-capable polyethylene sleeve.




Figure: 4-46

- TracPipe PS-II fittings are constructed from TracPipe® CounterStrike® patented AutoFlare® fittings with a plastic containment coupling and 1/4 inch NPT vent port. Fittings assemble without special tools. Figure 4-46
- When pressure testing TracPipe PS-II, it is necessary to remove at least one fitting vent plug to insure proper test results on the stainless steel tubing.

Tools Required for Assembly

- * Utility knife with sharp blade
- * Appropriate size adjustable or monkey wrenches
- * Tubing Cutter:

For up to 3/4" -#151 Ridgid® tubing cutter (FGP-TC-151) w/TracPipe cutting wheel (FGP-E-5272) For 1" and up -#152 Ridgid® tubing cutter (FGP-TC-152) w/TracPipe cutting wheel (FGP-E-5272)

* Reciprocating saw or hacksaw




Figure: 4-47

1.Unreel pipe into trench or on the ground and cut to desired length plus one additional foot. Cutting up to 1" size can be done with a large tubing cutter. For 1-1/4 to 2 inch sizes, a reciprocating saw is recommended. Figure: 4-47




Figure: 4-48

2. Mark the sleeve at specified length on the Strip Length Chart Table: 4-10 - plus 2 inches. Figure: 4-48

Table: 4-10

Jacket Strip Length / Fitting Torque / Superimposed Loading Chart

Size	3/8	1/2	3/4	1	1-1/4	1-1/2	2
Jacket Strip Length	1-1/2"	1-1/2"	1-3/4"	2"	2-1/4"	2-1/2"	2-3/4"
Fitting Torque Value	40 ft-lb	42 ft-lb	45 ft-lb	75 ft-lb	150 ft-lb	200 ft-lb	250 ft-lb
OD for Core Hole Sizing	.820	1.08	1.32	1.6	1.96	2.18	2.8
Max. Superimposed Loading <i>psf</i>	9640	7254	5409	4203	3390	2901	2124

Notes: 1. Super-imposed loading includes all dead load and live load combinations. 2. Maximum buried depth of 36"; 3. Soil Density: 120 pcf; 4. Factor of safety used: 4.




Figure: 4-49

3. Using the appropriate tubing cutter with **TracPipe®** #FGP-E-5272 cutting wheel, score the black sleeve approximately half of the way through. Figure: 4-49. Use extreme care not to cut or score the stainless corrugated pipe! Typically, no more than two turns in on the cutter is sufficient.




Figure: 4-50

4. Finish cutting through the sleeve down to the stainless corrugated pipe using a sharp utility knife. Figure: 4-50




Figure: 4-51

5. Using a twisting motion, remove the black sleeve from the pipe. Figure: 4-51. It may be necessary to cut sleeve longitudinally and peel off for larger sizes. <u>Inspect</u> <u>stainless pipe for scoring from the</u> <u>tubing cutter.</u>




Figure: 4-52

6. Using the tubing cutter, trim corrugated pipe to strip length specified in Table: 4-8. Cut slowly in the root of the corrugation in the same manner you would cut copper tubing. Inspect end of pipe for a clean cut without tears in corrugation. Figure: 4-52.




Figure: 4-53

7. Remove adapter and split rings from fitting. Attach adapter to equipment. Slip coupling and nut over end of pipe all the way to expose first corrugations of pipe. Insert split rings into first corrugation as shown. Figure: 4-53





Figure: 4-54

8. Holding the black coupling, slide fitting up to capture split rings into nut. Be sure split rings slip all the way to the base of the internal threads. Assembly is now ready to be attached to the adapter on the equipment. Figure: 4-54



9. Thread nut onto adapter previously installed on the equipment. Using appropriate wrenches, hold adapter and tighten nut to proper torque specified. Figure: 4-55. Do not over tighten or use any pipe dope or thread sealants on this connection. This is a metal-to-metal seat and will not seal if pipe dope or thread sealants are used. Sealants are to be used on the NPT connection to the equipment only!

NOTICE: When installing coupling FGP-UGC-SIZE the same instructions apply, except metallic parts of the fitting must be wrapped in a code approved manner (e.g. mastic used for wrapping metallic pipe).

SECTION 4.10 — ELECTRICAL BONDING/GROUNDING

WARNING! FIRE / FUEL GAS PIPING

Non-conductive jacketed CSST systems or systems that contain non-conductive jacketed CSST must be additionally bonded per the 2009 or later edition of the UPC, IFGC or NFPA-54.

It is **HIGHLY RECOMMENDED** to equipotentially bond all mechanical systems to the building's grounding electrode.

1. Definitions:

Grounding: The process of making an electrical connection to the general mass of the earth. This is most often accomplished with ground rods, ground mats or some other grounding system. Low resistance grounding is critical to the operation of lightning protection techniques.

Bonding: The process of making an electrical connection between the grounding electrode and any equipment, appliance, or metal conductor: pipes, plumbing, flues, etc. Equipment bonding serves to protect people and equipment in the event of an electrical fault.

Equipotential Bonding: The process of making an electrical connection between the grounding electrode and any metal conductor: pipes, plumbing, flues, etc., which may be exposed to a lightning strike and can be a conductive path for lightning energy towards or away from the grounding electrode.

The TracPipe® CounterStrike® gas piping system shall be bonded in accordance with these instructions and local codes. In the event of a conflict between these instructions and local codes, the local codes shall control. The piping system is not to be used as a grounding conductor or electrode for an electrical system.

SECTION 4.10.1 - TRACPIPE® COUNTERSTRIKE® BONDING INSTRUCTIONS For all products date coded

0731 and higher (manufactured after July 30, 2007)

- The instructions for cutting tubing and for making fitting connections to *TracPipe® CounterStrike®* are located in Section 4.2 of this manual.
- 2. There are no additional bonding requirements for *TracPipe® CounterStrike®* and underground *TracPipe PS-II* imposed by the manufacturer's installation instructions. *TracPipe® CounterStrike®* is to be bonded in accordance with the National Electrical Code NFPA 70 Article 250.104(B) in the same manner as the minimum requirements for rigid metal piping. Installers must always adhere to any local requirements that may be stricter than these instructions. In these cases see Section 4.10.2.
- 3. Do not apply any non-metallic labels or paint to *TracPipe® CounterStrike®*.

SECTION 4.10.2— WHEN BONDING IS REQUIRED

1. When additional bonding of the *TracPipe® CounterStrike®*, yellow jacketed *TracPipe®* or *TracPipe® PS-II®* system is required by local codes, a bonding clamp must be attached to either the brass *TracPipe® AutoFlare® or AutoSnap®* fitting adapter Figure: 4-56, or to a black pipe component (pipe or fitting) within the gas piping system. The corrugated stainless steel portion of the gas piping system SHALL NOT be used as the bonding attachment point.

The bonding should be in accordance with the National Electrical Code NFPA 70. Bonding electrode conductor sizing shall be in accordance with NFPA 70 Article 250.66 and Table: 250-66.




Figure: 4-56

BRASS BONDING CLAMPS

Part No.	Fits <i>TracPipe</i> ® AutoFlare® Fitting	Fits Iron Pipe size
FGP-GC-1	3/8", 1/2"	1/2", 3/4", 1
FGP-GC-2	3/4", 1", 1-1/4"	1-1/4", 1-1/2", 2"
FGP-GC-3	1-1/2", 2"	2-1/2", 3", 4"

Table: 4-11

- 2. **TracPipe®** bonding clamps have been tested and approved by CSA in accordance with UL 467 / CSA C22.2 No. 41-07 when installed on black iron/galvanized steel pipe and **TracPipe® AutoFlare®** or **AutoSnap®** brass hex fittings. Only a single point of attachment is required to protect the entire gas piping system. Table: 4-11.
- 3. If possible, avoid running the bonding conductor a long distance through the building. The connection should be as short as practical. The bonding clamp can be connected at a point on the piping system near the grounding electrode system.
- Lightning induced voltages seeking ground are subject to impedance; consider utilizing a multi-stranded bonding jumper for greater surface area, rather than solid wire.

- 5. Multiple gas meters used for a single building may be bonded with a single bonding conductor installed in a "daisy chain" configuration.
- 6. Original yellow jacketed **TracPipe®** must be bonded in accordance with this Section.

△ WARNING

- Failure to properly bond the TracPipe® CounterStrike® flexible gas piping system in accordance with NEC/NFPA 70 may lead to damage to the CSST system in the event of a lightning strike.
- A lightning induced fire in the building could lead to serious personal injury or significant property damage.
- Lightning is a powerful and unpredictable natural force, and it has the capacity of damaging gas piping systems due to arcing between the gas piping system and other metallic systems in the building.
- If the building to be piped is in a high lightning flash density area or a region with a high number of thunderstorm days per year, consideration should be given to utilizing the Lightning Risk Assessment method given in Annex L of NFPA 780 for a determination of the need for a lightning protection system.

All references to model building codes are to the version of those codes adopted by the local authority having jurisdiction. If there are no such local codes, refer to the current edition of the National Fuel Gas Code NFPA 54 and National Electrical Code NFPA 70.

CHAPTER 5 INSPECTION, REPAIR AND REPLACEMENT

SECTION 5.1 — MINIMUM INSPECTION REQUIREMENTS

TracPipe® CounterStrike® Inspection Checklist

All installations shall be inspected by the authority having jurisdiction in accordance with state and local mechanical/plumbing codes or the National Fuel Gas Code NFPA 54 (ANSI Z 223.1), IFGC or UPC.

Installer has <i>TracPipe® CounterStrike®</i> Training Certification card.
Inspection and pressure test completed at rough in.
Strike protection in place where required.
TracPipe® CounterStrike® tubing is supported at proper interval.
No damaged tubing dents or defects. (See 5.2).
Inspect for elecrical bonding where required.

TracPipe® CounterStrike® Flexible Gas Piping

Omega Flex, Inc.

451 Creamery Way, Exton, PA 19341-2509

Toll free: (800) 671-8622

Tel: (610) 524-7272 Fax: (610) 524-7282

SECTION 5.2 — REPAIR OF DAMAGED PIPING

If the tubing is damaged, refer to the following sections to determine the severity of damage and, if necessary, the method of repair.

- 1. No repairs or replacement of the tubing is necessary if the tubing is only slightly dented due to impact or crushing as indicated in Figure: 5-1.
- 2. The tubing must be replaced under the following circumstances:
 - a. The tubing has been significantly crushed or dented Figure: 5-2.
 - b. The tubing has been damaged by puncture of any kind, i.e., nails, screws, drill bits, etc.
 - c. The tubing has been bent beyond its minimum bend radius so that a crease or kink remains. Figure: 5-3.

METHOD OF REPAIR

A line splice can be made using a **TracPipe® CounterStrike® AutoFlare®** or **AutoSnap®** coupling, If the tubing run is short and easily accessible, the preferred repair method is to replace the entire length. Tubing run can often be replaced faster than repairing the damaged section with a splice as this does not add any additional fitting joints to the system.

1. Where repairs or replacements involve corrugated stainless steel tubing systems of different manufacturers, the systems can be joined again through standard pipe couplings and the appropriate CSST fittings. Figure: 5-4.

SECTION 5.3 — REPAIR OF DAMAGED JACKET

If the **TracPipe® CounterStrike®** jacket has been ripped, torn, cut or has been exposed to an electrical arc, a repair is required. The jacket shall be wrapped using self-bonding silicone tape over the damaged area insuring that the damaged jacket is fully covered and fully wrapped around the jacket circumference.



Figure: 5-1 – Repair Unnecessary.

No Significant Damage to the Tubing

Due to Impact or Crushing




Figure: 5-2 – Repair Necessary.
Significant Damage to the Tubing
Due to Impact or Crushing




Figure: 5-3 – Repair Necessary.

Damage Due to Bending Beyond

Minimum Bend Radius




Figure: 5-4 – Repair of Damaged Tubing with a New Section of Tubing and a joint splice or a **TracPipe® CounterStrike® AutoFlare®** or **AutoSnap®** Coupling

CHAPTER 6 PRESSURE/LEAKAGE TESTING

SECTION 6.0 — PRESSURE TEST PROCEDURE

The final installation must be inspected and tested for leaks at 1 1/2 times the maximum working pressure, but not less than 3 PSI, using the procedures specified in Chapter 8 "Inspection, Testing and Purging" of the National Fuel Gas Code*, NFPA 54/ANSI Z223. 1* or pressure test according to these guidelines or to local codes. When local codes are more stringent, local codes must be followed. If no local codes apply, test according to the National Fuel Gas Code or IFGC or UPC. The installer should never pressure test with the pounds-to-inches regulator installed. This may damage the regulator.

- Pressure testing should be performed during rough construction of the facility before interior walls are finished. This will permit a more complete inspection of the piping system during the pressure testing, and save costly rework in the event of leaks or other problems. *TracPipe® CounterStrike®* is not responsible for repairs necessary to correct defects discovered after interior walls are finished.
- 2. Do not connect appliances or pressurize the system with fuel gas until after the pressure test is completed.
- 3. All gas outlets for appliance connections should be capped during pressure testing.
- 4. USE ONLY NON-CORROSIVE LEAK CHECK SOLUTIONS. Rinse with water and dry the tubing thoroughly after leak detection. (Available: Leak Check Solution P/N FGP-LCS).
- 5. Most utilities perform a leak test after setting the gas meter and prior to turning on the gas. This test is performed after the final construction is complete and finished interior walls are in place. This test is performed to assure no damage was done to the tubing during the closing-in construc-

tion process.

6. **NOTICE:** When pressure testing **TracPipe® PS-II**, it is necessary to remove at least one fitting vent plug to insure proper test results on the stainless steel tubing. Codes do not require pressure testing of the sleeve. If local jurisdictions require the sleeve to be tested, do not exceed the pressure of the pipe (25 psi maximum).

SECTION 6.1 — Pressure Test for Elevated Pressure Systems

NOTICE: Do not subject_*TracPipe*® **CounterStrike** Sizes 1-1/2 inch or 2 inch to excessive pressure. Pressure test 1-1/2 inch and 2 inch sizes to local code requirements but not to exceed 40 PSI. In the absence of code requirements, test to 1-1/2 times actual working pressure, not to exceed 40 PSI.

Systems above 1/2 PSI requires a two-part pressure test. (See Figure: 6-1) The first part is performed on the elevated pressure section, between the meter connection and the pounds-to-inches line gas pressure regulator.

The second part is performed on the low pressure section, between the pounds-to-inches line gas pressure regulator and the gas appliance outlet. If a steel pipe "jumper" is inserted in place of the line gas pressure regulator the entire system can be pressure tested in one step.




Figure: 6-1 – Pressure Test Requirement for a 2 PSI System

SECTION 6.1.1 — APPLIANCE CONNECTION LEAKAGE CHECK PROCEDURE

- After the final pressure test, inspection and final construction is complete (finished interior walls) connect the appliances to the tubing system.
- This final connection can be accomplished by a stainless steel flexible connector, direct connection with CSST tubing or with rigid black pipe. See section 4.6 for installation details and guidelines.
- 3. Turn the gas on at the meter and inspect for leakage before operating the appliances.
- 4. Connections made at the appliances should be leak checked with a bubble solution. Before placing the appliances in operation the tubing system should be purged. This displaces the air in the system with fuel gas. Be sure to bleed tubing system into a well ventilated area.

CAUTION: Leak test solutions may cause corrosion to some types of material in the gas tubing system. Be sure to water rinse after the test and thoroughly dry all contacted material. Also, the vent limiter should not be leak tested with a liquid test solution. This will contaminate the internal ball check mechanism or plug the breathing hole, resulting in erratic regulator operation.

SECTION 6.1.2 — REGULATOR PERFORMANCE - OPTIONAL TESTING

A. Load Response

1. A performance test should be conducted while operating all appliances at full load.

This will insure adequate pressure to each appliance under full-load conditions. To accomplish this, measure the line pressure at the appliance connection while operating the appliance.

2. The inlet pressure for typical natural gas appliances should measure between 4 and 6 inches water column under full-load conditions. If this pressure can not be obtained a slight adjustment to the pounds-to-inches regulator may be necessary to increase the line pressure. Do not set any system regulator over the system design pressure (2 PSI).

B. Spring Adjustment

- 1. The 2 PSI system pounds-to-inches line gas pressure regulator can be adjusted with an outlet pressure ranging between 7 and 11 inches of water column. The regulator must be adjusted according to the manufacturer's recommended procedure. A pressure gauge mounted just downstream of the regulator can monitor the set pressure under various loads.
- 2. The regulator is typically set when the system is operating at approximately 75 percent of maximum load.
- 3. The average natural gas appliance is designed to operate at 3 to 4 inches water column manifold pressure, and a pressure difference of 1 to 2 inches of water column across the appliance regulator which will prevent slow regulator response. Thus, the appliance regulator will operate best at 5 to 6 inches water column inlet pressure. In this case, the 2 PSI line gas pressure regulator should be reset to deliver approximately 8 to 10 inches of water column outlet pressure under load to allow for 3 inches of water column pressure drop in the tubing. Some appliances may have different inlet pressure requirements.

CHAPTER 7 CAPACITY TABLES

SECTION 7.0 — SIZING TABLES

for TracPipe® CounterStrike® and TracPipe® PS-II Flexible Gas Piping

STANDARD TABLES

Natural Gas 6-7 inch w.c. / 0.5 inch w.c. drop

8 inch w.c. / 3 inch w.c. drop 12-14 inch w.c. / 6 inch w.c. drop

2 PSI / 1 PSI drop 5 PSI / 3.5 PSI drop

Propane 11 inch w.c. / 0.5 inch w.c. drop

2 PSI / 1 PSI drop 5 PSI / 3.5 PSI drop

ADDITIONAL TABLES

Natural Gas 6-7 inch w.c. / 1 inch w.c. drop

7-8 inch w.c. / 1.5 inch w.c. drop 7-8 inch w.c. / 2 inch w.c. drop 8 inch w.c. / 2.5 inch w.c. drop 11 inch w.c. / 5 inch w.c. drop

2 PSI / 1.5 PSI drop 10 PSI / 7 PSI drop 25 PSI / 10 PSI drop

Propane 11-12 inch w.c. / 1.0 inch w.c. drop

12-14 inch w.c. / 2.0 inch w.c. drop 12-14 inch w.c. / 2.5 inch w.c. drop

10 PSI / 7 PSI drop 25 PSI / 10 PSI drop

Table N-1 Low Pressure (Standard)

EHD

3/8"

1/2"

see notes below* EHD (Equivalent Hydraulic Diameter) A theoretical size which reflects the hydraulic performance of the tubing. It is not a true physical measure. This number is used to compare individual sizes between different manufactures. The higher the EHD number the greater the flow capacity of the piping.

1 1/2"46

1 1/4"39

4 8 8 21

4 0

4 9 22

Table N-2A Low Pressure (Canada & USA 1 in drop)

Maximum Capacity of OmegaFlex TracPipe CSST in Cubic Feet per Hour (CFH) of Natural Gas (1000 BTU per cubic foot approx)

in w.c.

Min. Gas Pressure: 6-7

*Notes: Tables above include losses for four 90-degree bends and two end fittings. Tubing runs with larger numbers of bends and/or fittings shall be increased by the equivalent length of tubing to the following equation: L=1.3n where L is the additional length of tubing and n is the number of additional fittings and/or bends.

Table N-2B Low Pressure (Canada & USA 1.5 in drop)

					1100	8	17	42	71	134	204	488
					1000	8	18	4	75	141	214	512
					006	6	19	46	79	148	226	540
					800	6	20	49	83	157	239	572
					700	10	21	52	89	168	256	612
×					009	11	23	57	96	181	277	661
t appro					200	12	25	62	105	198	304	723
oic foo'					400	13	28	69	117	221	340	808
per cul					300	15	32	80	135	254	393	933
00 BTU					250	91	35	87	148	278	431	1021
as (100					200	18	39	26	165	310	483	1141
tural G					150	21	45	112	190	358	559	1317 1141 1021
of Nat					125	23	49	122	208	391	613	1612 1442
ur (CFH				et)	100	26	55	136	232	436	989	1612
per Ho				th (fe	06	27	28	143	244	460	723	1698
ic Feet				Leng	80	28	61	152	259	487	768	1801
lin Cub			ı	Tubing Length (feet)	75	29	63	157	267	503	793	1860
pacity of OmegaFlex TracPipe CSST in Cubic Feet per Hour (CFH) of Natural Gas (1000 BTU per cubic foot approx)	in w.c.	Pressure Drop: 1.5 in w.c.	ity Gas)	_	70	30	9	162	276	520	821	1925
«TracPi			ic Grav		09	33	70	175	298	561	888	2078
egaFle	re: 7-8	1.5) Specif		20	35	77	191	326	614	974	2276
of Om	n. Gas Pressure: 7-8	Drop:	n a 0.60		40	39	98	213	364	685	1090	
apacit	Min. Gas	ressure	Based c		30	45	66	245	419	789	1261	2934 2543
Maximum Ca	~	4	=		25	49	108	268	458	863	1383	3213
Maxi					20	55	120	299	511	963	1548	3590
					15	63	138	344	589	1109	1790	4142
					10	92	168	419	719	1353	2197	6905
					5	105	235	287	1010	1905	3119	7156
					EHD	15	19	25	31 1	39 1	46	62 7
					Size	3/8"	1/2"	3/4"	1"	1 1/4"	1 1/2"	2"

_

see notes bebow*
EHD (Equivalent Hydraulic Diameter) A theoretical size which reflects the hydraulic performance of the tubing. It is not a true physical measure. This number is used to compare individual sizes between different manufactures.
The higher the EHD number the greater the flow capacity of the piping.

Table N-2C Low Pressure (Canada & USA 2.0 in drop)

Maximum Capacity of OmegaFlex TracPipe CSST in Cubic Feet per Hour (CFH) of Natural Gas (1000 BTU per cubic foot approx)

		700 800 900 1000 1100 1200 1300 1400 1500	12 11 11 10 10 9 9 8 8	24 23 22 20 19 19 18 17 17	60 57 53 51 48 46 45 43 42	103 96 91 86 82 79 76 73 70	193 181 171 162 155 148 142 137 133	296 277 261 247 236 226 217 209 201	706 661 623 591 564 540 519 500 483	
		009	4	56	65	111	208	320	762	doi:
		200	15	29	71	121	228	351	835	llouisse o
		400	17	32	80	135	254	393	933	of order of a
		300	19	37	92	156	293	455	1076	onid
		250	21	40	100	170	320	499	7 1179	denough to
		200	24	45	112	190	358	559	0 1317	olarimo
		150	26	52) 129	219) 412	9 646	4 1520	odt ved be
		125	29	57	7 140	7 240	3 450	3 709	0 1664	in case of
	eet)	100	31	63	157	267	503	793	1860	od Hodoo
	gth (f	06	33	99	165	281	529	837	1960	00149.07
	g Len	80	34	70	175	298	561	888	2078	bac space
ıi ıi	īubin	75	35	73	180	308	579	917	2146	d go mod
in w.c. in w.c.	/ity Gas	70	37	75	186	318	599	950	2221	00000
8 0	(Based on a 0.60 Specific Gravity Ga sTubing Length (feet)	09	4	81	201	343	646	1027	2398	of abite and
Min. Gas Pressure: 7-8 Pressure Drop: 2.0	50 Spec	20	45	88	220	376	707	1126	2626	Tubing
s Pressı e Drop:	on a 0.6	40	52	66	245	419	789	1261	2934	Continued L
Min. Gas Pressu Pressure Drop:	Based	30	26	113	282	483	806	1458	3386	of the contract to
		25	63	124	308	528	994	1599	3707	ac aband
		20	72	138	344	589	1109	1790	4142	موسومات در
		15	87	159	395	678	1277	2070	4780	When the bear for the bear for the form of the seal tries and fution of fution in the control of the seal of the fution of the seal in the
		10	120	193	482	827	1558	2541	5848	open open
		5	15	270	675	1162	2191	3607	8257	ai or ode
		Size EHD	" 153/8"	19	" 25	31	39	46	62	17.7
		Size	3/8"	1/2"	3/4"		1 1/4"	1 1/2"	2"	1 4 9

*Notes: Tables above include losses for four 90-degree bends and two end fittings. Tubing runs with larger numbers of bends and/or fittings shall be increased by the equivalent length of tubing to the following equation: L=1.3n where L is the additional length of tubing and n is the number of additional fittings and/or bends.

Table N-2D Low Pressure (Canada & USA 2.5 in drop)

Size 3/8" 1/2" 3/4"

 1 1/2"

Table N-3 Regulator Outlet (8 inches W.C.)

Maximum Capacity of OmegaFlex TracPipe CSST in Cubic Feet per Hour (CFH) of Natural Gas (1000 BTU per cubic foot approx)

in w.c. in w.c.

(Based on a 0.60 Specific Gravity Gas)

Min. Gas Pressure: 8

Pressure Drop:

Notes: Tables above include losses for four 90-degree bends and two end fittings. Tubing runs with larger numbers of bends and/or fittings shall be increased by the equivalent length of tubing to the following equation: L=1.3n where L is the additional ength of tubing and n is the number of additional fittings and/or bends.

see notes below*
FFID (Equivalent Hydraulic Diameter) A theoretical size which reflects the hydraulic performance of the tubing. It is not a true physical measure. This number is used to compare individual sizes between different manufactures.
The higher the EHD number the greater the flow capacity of the piping.

Table N-3A 3P Regulator Outlet (11 inches W.C.)

Maximum Capacity of OmegaFlex TracPipe CSST in Cubic Feet per Hour (CFH) of Natural Gas (1000 BTU per cubic foot approx)

Pressure Drop: 5.0 in w.c. (Based on a 0.60 Specific Gravity Gas) Min Gas Pressure: 11

 see notes below*
FHD (Equivalent Hidraulic Diameter) A theoretical size which reflects the hydraulic performance of the tubing. It is not a true physical measure. This number is used to compare individual sizes between different manufactures. The higher the EHD number the greater the flow capacity of the piping.

Table N-4 Medium Pressure

Maximum Capacity of OmegaFlex TracPipe CSST in Cubic Feet per Hour (CFH) of Natural Gas (1000 BTU per cubic foot approx)

(1/2 PSIG) in w.c. in w.c. Min Gas Pressure: 12-14 Pressure Drop:

(Based on a 0.60 Specific Gravity Gas)

Tubing Length (feet)

											•	2			' ':																	
Size EHD		2	10	15	20	25	30	40	20	09	20	75	80	06	100	125	150	200	250	300	400	200	2 009	200	5 008	900	1000	1100	1200	1300	1400	1500
3/8" 15		229	160	130	112	66	06	78	69	63	28	56	55	52	49	4	14	35	32	29	56	23	21	20	18	17	16	16	15	15	4	4
1/2" 19		461	329	270	235	211	193	168	151	138	128	124	120	113	108	97	88	77	69	63	55	49	45	42	39	37	35	33	32	31	30	29
3/4" 25		1153 8	823	675	287	526	482	419	375	344	319	308	299	282	268	240	220	191	171	157	136	122	112	104	26	92	87	83	80	9/	74	71
=	31 16	1992	1418 1	1162	1010	902	827	719	644	589	546	528	511	483	458	411	376	326	292	267	232	208	. 061	. 9/1	165	156	148	141	135	130	125	121
1 1/4" 39		3757 2	2673 2	2191	1902	1704 1558		1353	1213	1109	1028	994	963	806	863	773	707	614	550	503	436	391	358	331	310 2	293	278	265	254	244	236	228
1 1/2"	46 67	6286 4	4428 3	3607	3119 2	2786	2541	2197	1963	1790	1656	1599	1548	1458	1383	1235	1126	974	870	793	989	613	529	517	483 4	455 4	431 4	411	393	378	364	351
2" (62 14	14263 10103	0103	8257	7156 6	6404	5848	6905	4536	4142	3837	3707	3590	3386	3213	2875	2626	2276	2036	1860	1612	1442 1	1317	1220	1141	1076 1	1021	974	933	968	864	835

Notes: Tables above include losses for four 90-degree bends and two end fittings. Tubing runs with larger numbers of bends and/or fittings shall be increased by the equivalent length of tubing to the following equation: L=1.3n where L is the additional length of tubing and n is the number of additional fittings and/or bends.

Table N-5 Elevated Pressure 2 psig

3/8" 1/2" 1 1/4"

3/4"

EHD (Equivalent Hydraulic Diameter). A theoretical size which reflects the hydraulic performance of the tubing. It is not a true physical measure. This number is used to compare individual sizes between different manufactures. Pressure drop across a say 14 PSI pressure drop at a flow of 250 cubic feet per hour. regulator. The higher the EHD number the greater the flow capacity of the piping. Table does not include effect of pressure drop across the line regulator. CAUTION: Capacities shown in table may exceed the maximum capacity for a slected regulator.

Table N-5A Elevated Pressure 2 psig

Maximum Capacity of OmegaFlex TracPipe CSST in Cubic Feet per Hour (CFH) of Natural Gas (1000 BTU per cubic foot approx)

psig

Gas Pressure:

L=1.3n where L is the additional length of tubing and n is the number of additional fittings and/or bends. Table does not include effect of pressure drop across the line regulator. If regulator loss exceeds 1/4 PSI (based on 8 inch outlet pressure) Do not use this chart. Pressure drop across a regulator will vary with flow rate. FGP-REG-3 has a 1/4 PSI pressure drop at a flow of 145 cubic feet per hour. CAUTION: Capacities shown in table may exceed the maximum capacity for a selected Notes: Tables above include losses for four 90-degree bends and two end fittings. Tubing runs with larger numbers of bends and/or fittings shall be increased by the equivalent length of tubing to the following equation:

Table N-6 Elevated Pressure 5 psig

					1			(1	1	ω	÷	3
					1400	53	116	287	492	926	1487	3452
					1300	54	120	298	510	096	1544	3582
					1200	57	125	310	531	666	1608	3727 3582
					1100	59	130	323	554	1043	1680	3892
					1000	62	136	339	580	1093	1763	4081
					006	9	143	356	611	1151	1860	4301
					800	89	152	378	647	1219	1974	4561
					700	73	162	403	169	1302	2111	4874
×					009	78	174	434	746	1536 1404	2283	5262
tappro					200	89	190	475	815		2503	5762 5262
bic foo					400	100	212	529	910	1714	2802	6439
per cu					300	116	244	609	1048	1974	3240	7430
00 BTU					250	128	566	665	1146	2159	3977 3553	8135
3as (10					200	143	297	742	1278	2774 2409 2159		0606
atural (150	166	341	853	1472	2774	4600	10489
H) of N					125	182	373	933	1609	3034	5044	11485
ur (CF				et)	100	205	415	1040	1795	3386	5646	12834
per Ho				Tubing Length (feet)	06	216	437	1095	1891	3565	5955	13524
oic Feet				y Leng	80	230	463	1159	2003	3778	6320	14341
in Cuk				ubing	75	238	479	1196	2067	3899	6530	14809
cPipe CSST in Cubic Feet per Hour (CFH) of Natural Gas (1000 BTU per cubic foot approx)	psig	psi	ravity Gas)	_	70	246	493	1237	2139	4034	6762	15326 14809 14341 13524 12834 11485 10489 9090 8135 7430
TracPip			c Gravi		09	267	532	1333	2307	4351	7310	16547
gaFlex	2	3.5	Specifi		20	293	286	1457	2522	4759	8015	8119
ofOme	nre:	Drop:	1 a 0.60		40	329	654	1625	2814	5310	8972	0246
pacity	Gas Pressure:	Pressure Drop:	(Based on a 0.60 Specific Gr		30	382	755	1869	3240	6116	8 222	3361 2
Maximum Capacity of OmegaFlex Trac	Ğ	Pr	(B)		25	420	827	2042 1	3543 3	9 8899	14730 12737 11378 10377	56970 40353 32981 28583 25580 23361 20246 18119
Maxin					20	475 4	3 506	2277 2	3953 3	7463 6	1 1.	3583 2
					15	552 4	1040	2619 22	4552 39	8595 74	730 12	981 28
					1		1304 10					53 329
					10	6 672	-	72 3191	00 5659	14743 10489	25665 18080	70 403
					D 5	5 736	1769	5 4472	1800			
					EHD	15	19	25	31	39	46	62

3/8" 1/2" 3/4"

400 1500

112

51

278

476 895 1487 1436

ee notes below*

1 1/2* 1/4"

Maximum Capacity of OmegaFlex TracPipe CSST in Cubic Feet per Hour (CFH) of Natural Gas (1000 BTU per cubic foot approx)

Pressure Drop: 7.0 psi (Based on a 0.60 Specific Gravity Gas)

psig psi

10

Gas Pressure:

3336

Table N-7 Elevated Pressure 10 psig

											Ĕ	ubing	Leng	lubing Length (feet)	et)																
Size	Size EHD	2	10	15	20	25	30	40	20	09	70	75	80	06	100	125	150	200	250	300	400	200	600 7	700 8	800	900 1000 1100 1200 1300 1400	11	00 120	00 130	00 140	0 1500
3/8"	3/8" 15	1117	814	929	293	535	492	432	390	359	334	324	314	298	284	256	236	207	187	172	150	136	125 1	116 1	109	104 9	66	95 91	1 88	3 85	82
1/2"	1/2" 19	2584	1879	1560	1367	1233	1134	994	897	825	292	744	723	685	652	589	541	474	428	394	345	311	286 2	266 2	251 23	237 22	226 216	16 208	18 200	0 194	188
3/4"	3/4" 25	6126	4488	3741	3288	2975	2741	2409 2179		2008	1874	1817	1765	1674	1597	1444	1331	1170	1058	975	857	775	714 6	9 999	628 59	295 26	568 54	544 523	3 505	5 488	473
1.	31	10350	7602	6347	5584	5056	4662	4102	3714	3424	3197	3101	3013	2859	2728	2470	2277	2004	1814	1673	1472	1332	1229	1147 10	1081	1026 97	979 93	938 902	871	1 842	817
1 1/4"	39	1 1/4" 39 15935 11800	11800	6686	8739	7933	7330	7330 6471 5875		5428	2078	4928	4792	4554	4350	3949	3649	3222	2925	2702	2386	2386 2166 2001 1872	100	872 1:	1767 1679 1604 1539	379 16	12	39 148	1482 1431 1386	31 138	1345
1 1/2"	1 1/2" 46	30140	30140 21882 18145 15887	18145	15887	14331 13174 11534 10405	13174	11534	_	9564	8907	8627	8374	7931	7554	6814	6264	5484	4947	4547	3981	3591 3	3301 30	3074 28	2890 27	2737 26	2607 2495	95 2397		2310 2232	2 2162
2"	62	62 56970 41709 35073 31015 28194 26081 23064 20966 19394	41709	35073	31015	28194	26081	23064	509602		18158	7630	7150	16308	15590	14172	13110	17630 17150 16308 15590 14172 13110 11593 10539 9749 8621 7837 7249 6787 6410 6096 5827 5595 5390 5209 5047	10539	9749	8621	7837 7	7249 6	787 6-	410 60	96 58	27 55	95 53	90 520	99 504	7 4900
												ŀ																			

*Notes. Tables above include losses for four 90-degree bends and two end fittings. Tubing runs with larger numbers of bends and/or fittings shall be increased by the equivalent length of tubing to the following equation: L=1.3n where L is the additional length of tubing and n is the number of additional fittings and/or bends. Table does not include effect of pressure drop across the line regulator. User must size regulator based on an inlet pressure between 3 and 10 psig with the desired outlet pressure and capacity required.

EHD (Equivalent Hydraulic Diameter) A theoretical size which reflects the hydraulic performance of the tubing. It is not a true physical measure. This number is used to compare individual sizes between different manufactures. The higher the EHD number the greater the flow capacity of the piping. Table does not include effect of pressure drop across the line regulator if the regulator loss exceeds 1 PSI (based on 8 inch outlet pressure). Do not use this chart. PEP-REG-5A has a 1 PSI pressure drop at a flow of 673 cubic feet per hour. CAUTION: Capacities shown in the table may exceed the maximum capacity for a selected regulator.

Table N-8 Elevated Pressure 25 psig

					Ma	dimum	Capacit	y of On	negaFle.	x TracPi _l	oe CSST	in Cub	ic Feet p	ser Hou	ır (CFH)	Maximum Capacity of OmegaFlex TracPipe CSST in Cubic Feet per Hour (CFH) of Natural Gas (1000 BTU per cubic foot approx)	ral Gas (1000 B	TU per	cubic fc	ot app	rox)									
							Gas Pressure: Pressure Drop	Gas Pressure: Pressure Drop:	25	0	psig psi																				
							(Based	on a 0.6	(Based on a 0.60 Specific Gravity Gas)	fic Grav	ity Gas)																				
											_	Tubing Length (feet)	Leng	th (fe	et)																
Size	EHD	2	10	15	20	25	30	40	20	09	70	75	80	06	100	125	150	200	250	300	400	200	2 009	700	6 008	900 10	11 000	1000 1100 1200		1300 1400	0051 0
3/8"	3/8" 15	1731	1252	1036	906	816	750	655	591	542	505	489	474	449	427	385	353	309	278	256	223	201	185	172 1	161	153 14	45 13	145 139 134	4 129	9 124	. 120
1/2"	19	3751	2735	2274	1995	1802	1658	1454	1314	1209	1127	1092	1060	1005	958	865	96/	869	631	580	509	460 4	423	394 3	371 3	352 33	335 32	321 308	8 297	7 287	279
3/4"	3/4" 25	9332	6813	2995	4973		4494 4137 3631	3631	3281	3020	2816	2729	2650	2512	2395	2164	1992	1748		1580 1454 1276 1153	1276		1062	066	932 8	883	842 80	806 775	5 747	7 723	200
<u>-</u>	31 1	15861	11616	9681	8507	9692	7090	6230	5636	5193	4845	4697	4563	4328	4127	3734	3440	3023	2734	2519	2214 2002	_	1845 1	1721	1621 15	1538 14	166 14	1466 1405 1351		1303 1261	1 1222
1 1/4"	1 1/4" 39 2	24879	18276	24879 18276 15259 13426 12157 11209 9863	13426	12157	11209	9863	8930	8234	7689	7456 7245		6875	0959	5940	5477	4819	4364	4819 4364 4023 3540 3205	3540	3205 2	2956 2	760 2	900 5	2760 2600 2468 2355 2257 2171 2095 2027	355 22	57 217	71 209	15 202.	7 1966
1 1/2"	46	44300	32270	44300 32270 26810 23506 21227 19529 17122	23506	21227	19529	17122	15462	15462 14225	13257 12846 12472 11819 11263	12846	12472	11819		10171	9357	8204	7408	6816	5976	5396 4	4965 4	4627 4	4353 41	4125 3931 3763 3616 3486 3370	331 37	63 361	16 348	93370	3266
2"	62 ;	79820	59313	49856	44075	40057	37047	32751	29765	27529	25770	25019	24337	23139	22118	62 79820 59313 49856 44075 40057 37047 32751 29765 27529 25770 25019 24337 23139 22118 20102 18591 16436 14937 13815 12213 1099 10266	18591	16436	14937	13815	122131	1099	3 9970	6096	1075 8t	9075 8629 8248 7918 7628 7371 7141	248 79	18 762	737	1 714	1 6933

see notes below*
EHO (Equivalent Hydraulic Diameter). A theoretical size which reflects the hydraulic performance of the tubing. It is not a true physical measure. This number is used to compare individual sizes between different manufactures.
The higher the EHD number the greater the flow capacity of the piping. Table does not include effect of pressure drop across the regulator. User must size the regulator based on an inlet pressure between 15 and 25 psig with the desired outlet pressure range and capacity required.

Table P-1 Propane Low Pressure (Standard)

Maximum Capacity of OmegaFlex TracPipe CSST in Thousands of BTU per Hour Propane Gas Min. Gas Pressure: 11

in w.c.

Pressure Drop: 0.5 in w.c. (Based on a 1.52 Specific Gravity / 2520 BTU per cubic foot Gas)

Tubing Length (feet)

1500

9

13

33 55

	J					` .	•	m
	1400	9	14	35	59	109	163	397
	1300	9	14	35	09	114	169	412
	1200	9	14	36	63	119	177	429
	1100	80	16	38	9	123	185	448
	1000	∞	16	14	89	130	195	469
	006	∞	17	43	73	136	204	494
	800	∞	17	46	9/	144	217	524
	700	0	19	49	82	154	233	260
	009	6	21	52	89	166	252	605
	200	=	22	57	97	182	275	663
	400	13	25	63	108	203	309	741
	300	14	30	73	125	234	358	855
	250	16	32	81	136	256	391	936
	200	17	36	06	152	287	439	1047
	150	19	41	103	176	329	507	1206
	125	22	46	112	192	361	556	1322
,	100	24	51	127	214	402	622	1477
	06	25	54	133	225	424	657	1556
	80	27	22	141	239	450	269	1650
	75	27	29	146	247	464	720	1704
	20	28	09	150	255	480	746	1764
	09	30	99	161	275	518	908	1905
	20	33	71	177	301	267	885	2085
	40	36	79	198	336	632	066	2331
	30	43	92	226	386	728	1145	2688
	25	46	100	249	423	962	1256	2945
	20	52	111	277	472	888	1406	3290
	15	59	128	318	543	1023	1626	3797
	10	71	157	388	663	1249	1997	4645
	2	100	218	545	933	1756	2834	6558
	EHD	15	19	25	31	39	46	62
	Size	3/8"	1/2"	3/4"		1 1/4"	1 1/2"	2"

*Notes: Tables above include losses for four 90-degree bends and two end fittings. Tubing runs with larger numbers of bends and/or fittings shall be increased by the equivalent length of tubing to the following equation:

383

158 106

Table P-1A Propane Low Pressure

Maximum Capacity of TracPipe CSST in Thousands of BTU per Hour Propane Gas

in w.c. Min. Gas Pressure: 11-12

Pressure Drop: 1.0 in w.c. (Based on a 1.52 Specific Gravity / 2520 BTU per cubic foot Gas)

Tubing Length (feet)

Size EHD	D 5	10	15	20	25	30	40	20	09	70	75	80	06	100	125	150	200	250	300	400	200	009	700	800	. 006	10001	1100 1200		1300 1400		1500
3/8" 15	15 138	3 100	82	71	9	65	52	46	43	40	38	36	35	33	30	27	24	22	19	11	16	14	13	13	11	11	11	6	6 6		6
19	306	5 218	179	157	139	128	111	100	92	85	82	79	74	7.1	63	59	51	46	41	36	32	30	27	25	24	22	22	21	21 1	19 1	19
3/4" 25	5 763	545	446	388	348	318	277	249	226	211	204	198	187	177	158	146	127	112	103	06	81	73	89	63	09	57	54	25	51 4	49 4	47
31	1309	9 933	765	663	595	543	472	423	386	359	347	336	317	301	269	247	214	192	176	152	136	125	116	108	101	97	92	68	85 82		79
3,	1 1/4" 39 2467	7 1756	1438	1249	1119	1023	888	796	728	674	652	632	265	267	202	464	402	361	329	287	256	234	217	203	192	182	174	166	160	154 1,	149
1 1/2" 46	6 4023	3 2834	1 2308	1997	1783	1626	1406	1256	1145	1059	1023	066	933	885	790	720	622	556	202	439	391	358	331	309	291	275	263 2	252	241 233		225
62	9259	9 6558	5361	4645	4158	3797	3290	4158 3797 3290 2945	2688	2490	2407	2331	2198	2085	1867	1704	1477	1322	1206	1047	936	855	792	741	869	663	632 6	605	581 560		541
۱																					I	I	l	l							

Notes: EHD (Equivalent Hydraulic Diameter) A theoretical size which reflects the hydraulic performance of the tubing. It is not a true physical measure. This number is used to compare individual sizes between different manufactures.
The higher the EHD number the greater the flow capacity of the piping. Tables above include losses for four 90-degree bends and two end fittings. Tubing runs with larger numbers of bends and/or fittings shall be increased by the equivalent length of tubing and n is the number of additional fittings and/or bends.

Table P-1B Propane

				Max	ximum	Capacit	y of Tra	Maximum Capacity of TracPipe CSST in Thousands of BTU per Hour Propane Gas	SST in T	housan	ds of BT	'U per h	lour Prc	opane G	as															
						Min. Ga	is Pressi	ē.	-14	in w.c.																				
						Pressure Drop:	e Drop.	0.2	,	IN W.C.	į	-		,																
						(Based	on a 1.5	(Based on a 1.52 Specific Gravity /	nc Grav.	ity / 252	20 BTU	2520 BTU per cubic foot Gas)	ic foot (Gas)																
										-	ubing	Tubing Length (feet)	th (fe	et)																
Size EHD	2	10	15	20	25	30	40	20	09	70	75	80	06	100	125	150	200	250	300	400	200	2 009	700 80	800	900 100	00 110	1000 1100 1200		1300 1400	1500
3/8" 15	190	138	114	100	68	82	71	65	59	55	54	52	49	46	14	38	33	30	27	24	22	19	17 1		16	16 14	<u>+</u>	13	13	13
1/2" 19	427	306	252	218	196	179	157	139	128	119	116	111	104	100	06	82	71	63	59	51	46	41	38 3	36 3	35 3.	32 30	30	28	27	27
3/4" 25	1069	763	625	545	488	446	388	348	318	294	285	277	261	249	222	204	177	158	146	127	112	103	95 6	8 06	84 81	1 76	5 73	71	89	99
1" 31	1840	1309	1073	933	836	765	663	595	543	503	488	472	445	423	380	347	301	569	247	214	192	176	163	152 1	144 13	136 130	0 125	120	116	111
1 1/4" 39	3469	2467	2022	1756	1574	1438	1249	1119	1023	948	917	888	838	962	712	652	267	202	464	402	361	329 3	306 28	287 2:	271 25	256 245	5 234	225	217	211
1 1/2" 46	5711	4023	3277	2834	2532	2308	1997	1783	1626	1504	1452	1406	1325	1256	1123	1023	885	790	720	622	556	507 4	469 43	439 4	413 391	91 374	4 358	344	331	318
2" 62		13073 9259	7568	6558	5869	5361	4645	4645 4158	3797	3516	16 3398	3290	3103	2945	2635	2407	2085	1867	1704	1477 1322	1322	1206 1118	118 10	1047 98	986 93	936 893	3 855	822	792	763
tes: EHD (l	Equivalen: e EHD nur	Notes: EHD (Equivalent Hydraulic Diameter) A theoretical size which re The higher the EHD number the greater the flow capacity of the piping.	Diameter preater the) A theore flow capa	tical size	which refle piping.	ects the h	/draulic pe	erformance	e of the tu	bing. It is	not a true	physical	measure.	This numb	Notes: EHD (Equivalent Hydraulic Diameter) A theoretical size which reflects the hydraulic performance of the tubing. It is not a true physical measure. This number is used to compare individual sizes between different manufactures. The higher the EHD number the greater the flow capacity of the piping.	to compan	e individu	al sizes be	tween dif	ferent ma.	nufacture	Š.							

Table P-2 Propane Medium Pressure

					Max	Maximum Capacity of TracPipe CSST in Thousands of BTU per Hour Propane Gas	Capacity	y of Trac	cPipe C	SST in Ti	housan	ds of BT	-U per F	Hour Pro	pane (jas															
						_ u	Min. Gas Pressu Pressure Drop:	s Pressu	Min. Gas Pressure: 13-14 Pressure Drop: 25	-14	in w.c.																				
							Based c	n a 1.5.	0,	fic Gravi	ity / 252	 20 BTU t	ser cub	ic foot (jas)																
									-		_	ubing	Leng	ubing Length (feet)	; ,																
Size	EHD	5	10	15	20	25	30	40	20	09	70	75	80	06	100	125	150	200	250	300	400	200	2 009	3 002	6 008	900 10	00 110	1000 1100 1200	0 1300	0 1400	1500
3/8"	15	222	159	131	114	102	86	81	23	29	62	09	58	55	52	46	43	36	33	30	27	24	22	21	19 1	17 17	7 16	91 9	14	14	14
1/2"	19	491	353	290	254	228	209	182	164	150	140	135	131	124	118	108	26	85	9/	70	57	51	46	43	40	38 3	36 35	5 33	32	30	30
3/4" 25		1192	850	869	909	545	497	432	388	355	329	318	309	291	277	249	226	198	177	161	141	127	116	106	100	95 9	90 85	5 82	79	9/	73
1.	31 2	2512 1	1863	1720	1343	1106	926	883	825	177	719	969	673	632	969	533	470	398	352	320	239	214	196	182	169	160 15	152 14	146 139	9 133	128	125
1 1/4"	39	3870 2	2753	2256	1959	1756	1605 1393		1249	1142	1058	1023	166	936	888	962	728	632	295	518	450	405	367	340	320 3	301 28	287 272	72 261	1 252	242	234
1 1/2	46	6393 4	4503	3668	3173	2834	2584	2234	1997	1821	1685	1626	1574	1484	1406	1256	1145	066	885	908	269	622	999	2 925	491 4	462 43	439 41	418 401	1 385	370	358
2"	62 14	14609 10347		8456	7329	6558	5990	5192	4645	4243	3930	3797	3676	3467	3290	2945	2688	2331	2085	1905	1650 1477		1349 1	1249 1	168 11	1168 1102 1047 997	47 99	955	5 918	885	855
*Notes:	Tables ak	bove inclu	nde losses	for four 9	0-degree	bends an	d two end	fittings.	Tubing ru	ns with lar	ger numk	ers of ben	ids and/oi	r fittings s	hall be inc	*Notes: Tables above include losses for four 90-degree bends and two end fittings. Tubing runs with larger numbers of bends and/or fittings shall be increased by the equivalent length of tubing to the following equation:	the equiva	alent leng	th of tubir	ng to the f	ollowing	equation:									

Le1.3n where L is the additional length of tubing and n is the number of additional fittings and/or bends.

Table P-3 Propane Elevated Pressure 2 psig

Maximum Capacity of TracPipe CSST in Thousands of BTU per Hour Propane Gas Pressure Drop: 1.0 psi (Based on a 1.52 Specific Gravity / 2520 BTU per cubic foot Gas) psig psi Min. Gas Pressure: 2

Tubing Length (feet)

1300 1400 1500	46 44	97	239	407	992	1206	31
	9			4	7	12	283.
	4	100	247	421	792	1249	2931
	47	103	256	437	822	1298 1249	3040
1000 1100 1200	49	108	266	454	855	1351	3163
1100	52	112	277	473	891	1482 1412 1351	3464 3304 3163
1000	54	117	291	497	934		3464
006	57	123	306	522	985	1563	3651
800	09	131	325	554	1202 1113 1043	1659	4466 4137 3871
700	63	139	347	592	1113	1919 1775	4137
009	89	150	374	638			4466
200	74	165	408	869	1314	2104	4891
400	84	184	454	779	1466	2354	5465
300	96	211	524	868	1689	2723	6306
250	105	230	572	982	1848	2986	9069
200	118	256	638	1094	2061	3342	7717
150	137	294	735	1260	2373	3866	8904
125	144	321	803	1379	2597	4240	9750
100	169	358	895	1537	2897	4745	10894
06	177	377	942	1620	3051	5005	11480
80	189	399	266	1716	3233	5312	12174 11
75	196	412	1029	1770	3338	5489	12571
70	203	426	1064	1832	3452	5684	13010
09	220	459	1254 1146	1976	4072 3724	6737 6145	14047
20	243	502	1254	2161	4072		15381
40	271	559	1398	2775 2410	4544	7541	17186
30	316	643	1607	2775	5233	8722 7541	19832
25	347	701	1757 1607 1398	3035	5724 5233 4544	9565	21715
20	389	781	1959	3387	6387	10706	24265
15	453	868		3900	7356	1 1/12 46 21574 15198 12381 10706 9565	48362 34257 27999 24265 21715 19832 17186 15381 14047
10	558	1106	3/4" 25 3847 2745 2253	4756	1 1/4" 39 12617 8977	15198	34257
5	649	1528	3847	6681	12617	21574	
Size EHD	3/8" 15	1/2" 19	25	31	39	. 46	62
Size	3/8	1/2	3/4'	1	1 1/4	1 1/2	2"

Notes: EHD (Equivalent Hydraulic Diameter) A theoretical size which reflects the hydraulic performance of the tubing. It is not a true physical measure. This number is used to compare individual sizes between different manufactures. The higher the EHD number the greater the flow capacity of the piping. Table does not include effect of pressure drop across the line regulator, if the regulator hose exceeds 1/2 PSI (based on 11 inch outlet pressure.) Do not use this chart. Pressure drop at a flow of 307 cubic feet per hour (774 MBTUh). CAUTION: Capacities shown in the table may exceed the maximum capacity for a selected regulator.

Table P-6 Propane Elevated Pressure 25 psig

Maximum Capacity of TracPipe CSST in Thousands of BTU per Hour Propane Gas (Based on a 1.52 Specific Gravity / 2520 BTU per cubic foot Gas) psig psi Min. Gas Pressure: 25 Pressure Drop:

Tubing Length (feet)

1500	190	442	1108	1935	3113	5171	10977
800 900 1000 1100 1200 1300 1400 1500	196	454		1997		5336	11306
1300	230 220 212 204 196	470	1183	2063	3317	5519	11670
1200	212	488	1227	2139	3437	5725	12077
1100	220	208	1276	2224	3573	5958	12530
1000	230	530	1333	2321	3729	6224	1305
006	242	557	1398	2435	3908	6531	313662
800	255	587	1567 1476 1398 1333 1276 1227 1183 1145	2725 2566 2435 2321 2224 2139 2063 1997	4370 4116 3908 3729 3573 3437 3317 3209	7326 6892 6531 6224 5958 5725 5519 5336	14368
200	272	624	1567	2725	4370	7326	15214
009	293	029	1681	2921	4680	7861	16254
200	318	728	1826	3170	5074	8543	17573
400 500	353	908	2020	3505	5605 5074	9462	19336
300	405	918	2768 2502 2302 2020 1826	3988 3505 3170	6989	10792	21873
250	440	666	2502	4329	6069	11729	23649
200	489	1105	2768	4786	7630	12989	26023
150	559	1260	3154	5446	8672	14815	29435
125	610	1370	3426	5912	9405	11/4" 46 70139 51092 42447 37216 33608 30920 27109 24480 22522 20989 20339 19747 18713 17832 16103 14815 12989 11729 10792 9462 8543	2" 62 126376 93908 78935 69783 63421 88655 51854 47126 43586 40801 39612 38532 36635 35019 31827 29435 26023 23649 21873 19336 7573 16254 15214 14368 13662 13059 1253
100	929	1517	3792	6534	10386	17832	35019
06	711	1591	4196 3977 3792	6852	74 11805 11471 10885 10386	18713	36635
80	052	1678	4196	7224	11471	19747	38532
75	774	1729	4321	7437	11805	20339	39612
70	800	1784	4458	7671	12174	20989	40801
09	828	1914	4781	8222	13037	22522	43586
20	936	2080	5195	8923	14139	24480	47126
40		2302	5749		15616	27109	51854
30	1187	2625	6550	11225	17747	30920	58655
25	1292 1187 1037	2853 2625	7115	12185	19248	33608	63421
20	1640 1434	3159	7874	15328 13469 12185 11225 9864	21257	37216	69783
15		3600	8972	15328	24159	42447	78935
10	1982	4330	3/4" 25 14775 10787 8972 7874 7115 6550 5749 5195	1" 31 25112 18391	39390 28936 24159 21257 19248 17747 15616 14139 13037 1217	51092	93908
	3/8" 15 2741	5939	14775	25112		70139	126376
Size EHD 5	15	1/2" 19	25	31	1 1/4" 39	3" 46	62
Size	3/8"	1/2	3/4"		1 1/4"	11/	2"

Table does not include effect of pressure drop across the line regulator. If the regulator loss exceeds 1 PSI (based on 11 inch outlet pressure) Do not use this chart. Pressure drops across a regulator will vary with flow rate. FGP-REG-5P has a 1 PSI pressure drop at a flow of 434 cubic feet per hour (1094 MBTUh). CAUTION: Capacities shown in the table may exceed the maximum capacity for a selected regulator.

Table P-5 Propane Elevated Pressure 10 psig

					•	•		•	_	7	4	6
					800	173	397	994	1712	3778 3429 3168 2964 2798 2	4576	10149
					700	184	421	1130 1054	1816	2964	5226 4867	10746
					009	198	453		1946	3168		11477
					200	215	492	1227	2109	3429	5686	12408
					400	237	546	1357	2331		6303	13649
					300	272	624	1544	2649	4278	7199	15435
					250	296	829	1675	2872	4631	7832	16686
					200	328	750	1852	3173	5101	8683	18355
					150	374	857	2107	3605	5777	9918	49105 44639 41293 36516 33195 30706 28749 27913 27153 25820 24683 22438 20757 18355 16686 15435 13649 12408 11477 0746 10149 9
Sas					125	405	933	2286	3911	6252	10788	22438
opane ((Gas)	et)	100	450	1032	2528	4319	6887	11960	24683
Hour Pre			ic toot	Inbing Length (feet)	06	472	1085	2650	4527	7210	12557 11960 10788	25820
TU per ŀ		-	per cub	y Leng	80	497	1145	2794	4770	7587	13258	27153
ds of Bl		i	20 BIU	ubing	75	513	1178	2877	4910	7802	13659	27913
Maximum Capacity of TracPipe CSST in Thousands of BTU per Hour Propane Gas	psig	ısd :	(Based on a 1.52 Specific Gravity / 2520 BTU per cubic foot Gas)		70	529	1216	2967	5062	8040	16474 15142 14102 13659	28749
SST in T		(nc Grav		09	268	1306	3179	5421	8594	15142	30706
:Pipe C	ire: 10). /	2 Specii		20	617	1420	3450	5880	9302	16474	33195
/ of Trac	Pressu	Urop:	on a 1.5.		40	684	1574	3814	6495	10245	18261	36516
.apacit	Min. Gas Pressure: 10	riessure Diop:	Based c		30	779	1795	4340	7381	11605	20858	41293
imum C	< 0	•	ت		25	847	1952	4710	8005	12560	22690	44639
Maxi					20	939	2164	5206	8841	13836 12560 11605 10245	25153 22690 20858	49105
					15	1070	2470	5923	10049	15673		55530
					10	1289	2975	7106	12036	18683	34645 28728	90199 66037 55530
					5	6921	4091	6696	16387	25229 1	47720 3	0199
							4	٠,	-	7	4	δ

3/8" 15 Size EHD

1/2"

3/4"

8247 7991

1300 1400

1000 1100

Notes: EHD (Equivalent Hydraulic Diameter). A theoretical size which reflects the hydraulic performance of the tubing. It is not a true physical measure. This number is used to compare individual sizes between different manufactures. The higher the EHD number the greater the flow capacity of the piping. Table does not include effect of pressure drop across the regulator. User must size the regulator based on an inlet pressure between 3 and 10 psig with the desired outlet pressure range and capacity required.

Table P-6 Propane Elevated Pressure 25 psig

Maximum Capacity of TracPipe CSST in Thousands of BTU per Hour Propane Gas

							3	2	_
		1400	196	454	1145	1997		5336	11306
		1300	204	470	1183	2063	3317	5519	11670
		1200	212	488	1227	2139	4370 4116 3908 3729 3573 3437 3317 3209	5725 5519	12077
		1100	220	208	1276	2224	3573	5958	12536
		1000	230	530	1333	2321	3729	6224	13059
		006	242	557	1398	2435	3908	6531	13662
		800	255	287	1476	2566	4116	6892	14368
		700	272	624	1567	2725		7326	15214
		009	293	029	1681	2921	4680	7861	16254
		200	318	728	1826	3170	5605 5074	8543	17573
		400	353	908	2020	3505	5095	9462	19336
		300	405	918	2302	3988	6989	11729 10792	21873
		250	440	666	2502	4329	6069	11729	23649
		200	489	1105	2768	4786	7630	14815 12989 1	26023
		150	559	1260	3154	5446	8672	14815	29435
		125	610	1370	3426	5912	9405	16103	40801 39612 38532 36635 35019 31827 29435 26023 23649 21873 19336 17573 16254 15214 14368 13662 13059 12536 12077 11670 11306 10
	Gas)	100	929	1517	3792	6534	10386	17832	35019
	ity / 2520 BTU per cubic foot Gas) Tubing Length (feet)	06	711	1591	3977	6852	12174 11805 11471 10885 10386	20989 20339 19747 18713	36635
	per cul	80	750	1678	4196	7224	11471	19747	38532
	Zo BTU Tubin e	75	774	1729	4321	7437	11805	20339	39612
psig psi	ity / 25	70	800	1784	4458	7671	12174	20989	40801
0.	(Based on a 1.52 Specific Grav	09	828	1914	4781	8222	13037	22522	43586
Min. Gas Pressure: 25 Pressure Drop: 10.0	2 Speci	20	936	2080	5195	8923	14139	24480	47126
Min. Gas Pressu Pressure Drop:	on a 1.5	40	1037	2302	5749	9864	15616	27109	51854
Ain. Ga ressure	Based	30	1187	2625	6550	11225	17747	30920	58655
_ 11		25	1292	2853	7115	13469 12185 11225 9864	19248	33608	63421
		20	1434	3159	7874	13469	39390 28936 24159 21257 19248 17747 15616 14139 13037	51092 42447 37216 33608 30920 27109 24480 22522	126376 93908 78935 69783 63421 58655 51854 47126 43586
		15	1640	3600	8972	15328	24159	42447	78935
		10	1982	4330	10787	18391	28936	51092	93908
		5	15 2741	5939	14775 10787	25112	39390	70139	26376
		EHD	15	19	25	31		46	62
		Size EHD	3/8"	1/2"	3/4" 25	1	1 1/4" 39	1 1/2"	2"

*Notes: Tables above include losses for four 90-degree bends and two end fittings. Tubing runs with larger numbers of bends and/or fittings shall be increased by the equivalent length of tubing to the following equation: L=13n where L is the additional length of tubing and n is the number of additional fittings and/or bends. Table does not include effect of pressure drop across the line regulator. User must size regulator based on an inlet pressure between 15 and 25 psig with the desired outlet pressure and capacity required.

1 1/2"

5"

1 1/4" -

SECTION 7.1 — PRESSURE DROP PER FOOT TABLESNATURAL GAS for *TracPipe® CounterStrike®*

and Steel Pipe

For propane (LP) gas applications:

- 1. Convert propane BTU load to CFH propane (divide by 2520 BTU per cubic foot).
- 2. Multiply CFH propane (1.52 SG) value by 1.5916 to obtain equivalent CFH Natural Gas (0.6 SG) value.
- 3. Find pressure drop per foot using CFH Natural Gas value from Step 2. This is the pressure drop per foot for Propane at the given BTU load.
- 4. Follow Sum of Pressure Loss instructions.

To convert 1,000 BTU values to CFH (Propane) use the following formula:

Propane = 2520 BTU/Cu.Ft.

Section 7.1 - Table PD-1A

Pressure drop ("wc per foot) for TracPipe based on a given CFH Flow (Natural Gas SG = 0.60 Gas) at Inlet Pressures up to 5 psig

Note: For Propane (LP) Gas applications, obtain Pressure Drop per foot values by following the Propane conversion method detailed in Section 7.1 of the TracPipe D&l Guide.

CFH	3/8"	1/2"	3/4"	1"	1-1/4"	1-1/2"	2"
10	0.0019	0.0004	0.0001				
20	0.0085	0.0018	0.0003	0.0001			
30	0.0204	0.0042	0.0007	0.0002	0.0001		
40	0.0377	0.0077	0.0012	0.0004	0.0001	0.0001	
50	0.0609	0.0121	0.0019	0.0007	0.0002	0.0001	
60	0.0900	0.0177	0.0028	0.0009	0.0003	0.0001	
70	0.1253	0.0244	0.0038	0.0013	0.0004	0.0002	
80	0.1668	0.0321	0.0050	0.0017	0.0005	0.0002	
90	0.2146	0.0410	0.0064	0.0022	0.0006	0.0003	
100	0.2690	0.0509	0.0079	0.0027	0.0007	0.0003	0.0001
110	0.3300	0.0620	0.0096	0.0033	0.0009	0.0004	0.0001
120	0.3976	0.0743	0.0115	0.0039	0.0011	0.0005	0.0001
130	0.4721	0.0876	0.0135	0.0046	0.0013	0.0006	0.0001
140	0.5533	0.1022	0.0158	0.0053	0.0015	0.0006	0.0001
150	0.6415	0.1178	0.0182	0.0061	0.0017	0.0007	0.0001
160	0.7367	0.1347	0.0207	0.0070	0.0019	0.0008	0.0001
170	0.8389	0.1526	0.0235	0.0079	0.0022	0.0009	0.0002
180	0.9482	0.1718	0.0264	0.0089	0.0025	0.0011	0.0002
190	1.0647	0.1921	0.0295	0.0099	0.0028	0.0012	0.0002
200	1.1884	0.2136	0.0328	0.0110	0.0031	0.0013	0.0002
225	1.5297	0.2726	0.0418	0.0140	0.0039	0.0017	0.0003
250	1.9172	0.3390	0.0519	0.0174	0.0048	0.0020	0.0004
275	2.3517	0.4128	0.0631	0.0211	0.0058	0.0025	0.0004
300	2.8338	0.4943	0.0755	0.0252	0.0070	0.0029	0.0005
325	3.3642	0.5833	0.0890	0.0297	0.0082	0.0034	0.0006
350	3.9433	0.6799	0.1036	0.0345	0.0095	0.0040	0.0007
375	4.5717	0.7842	0.1193	0.0398	0.0110	0.0045	0.0008
400	5.2499	0.8962	0.1363	0.0454	0.0125	0.0052	0.0009
425	5.9783	1.0159	0.1543	0.0513	0.0142	0.0058	0.0010
450	6.7575	1.1434	0.1736	0.0577	0.0159	0.0065	0.0012
475	7.5877	1.2788	0.1940	0.0644	0.0178	0.0072	0.0013
500	8.4694	1.4219	0.2155	0.0715	0.0197	0.0080	0.0014
525	9.4030	1.5729	0.2382	0.0790	0.0218	0.0088	0.0016
550		1.7318	0.2621	0.0868	0.0240	0.0097	0.0017
575		1.8986	0.2872	0.0951	0.0262	0.0106	0.0019
600		2.0733	0.3134	0.1037	0.0286	0.0115	0.0021
625		2.2560	0.3408	0.1127	0.0311	0.0125	0.0022
650		2.4467	0.3694	0.1221	0.0337	0.0135	0.0024
675		2.6453	0.3992	0.1319	0.0364	0.0145	0.0026

Section 7.1 - Table PD-1A

Pressure drop ("wc per foot) for TracPipe based on a given CFH Flow (Natural Gas SG = 0.60 Gas) at Inlet Pressures up to 5 psig

Note: For Propane (LP) Gas applications, obtain Pressure Drop per foot values by following the Propane conversion method detailed in Section 7.1 of the TracPipe D&l Guide.

CFH	1/2"	3/4"	1"	1-1/4"	1-1/2"	2"
700	2.8520	0.4301	0.1420	0.0392	0.0156	0.0028
725	3.0668	0.4623	0.1526	0.0421	0.0167	0.0030
750	3.2895	0.4956	0.1635	0.0451	0.0179	0.0032
775	3.5204	0.5302	0.1748	0.0482	0.0191	0.0034
800	3.7594	0.5659	0.1865	0.0514	0.0203	0.0037
825	4.0065	0.6028	0.1986	0.0547	0.0216	0.0039
850	4.2617	0.6410	0.2110	0.0582	0.0229	0.0041
875	4.5250	0.6803	0.2239	0.0617	0.0243	0.0044
900	4.7966	0.7208	0.2371	0.0653	0.0256	0.0046
925	5.0763	0.7625	0.2507	0.0691	0.0271	0.0049
950	5.3642	0.8055	0.2648	0.0729	0.0285	0.0052
975	5.6603	0.8496	0.2792	0.0769	0.0300	0.0055
1000	5.9647	0.8950	0.2940	0.0810	0.0316	0.0057
1100	7.2646	1.0885	0.3571	0.0983	0.0381	0.0070
1200	8.6972	1.3015	0.4264	0.1174	0.0453	0.0083
1300		1.5341	0.5020	0.1382	0.0531	0.0097
1400		1.7864	0.5839	0.1607	0.0615	0.0113
1500		2.0584	0.6722	0.1849	0.0705	0.0130
1600		2.3502	0.7668	0.2109	0.0801	0.0148
1700		2.6619	0.8677	0.2386	0.0903	0.0167
1800		2.9935	0.9750	0.2680	0.1011	0.0187
1900		3.3451	1.0887	0.2992	0.1125	0.0209
2000		3.7168	1.2088	0.3322	0.1245	0.0231
2100		4.1086	1.3353	0.3669	0.1371	0.0255
2200		4.5206	1.4682	0.4033	0.1503	0.0280
2300		4.9528	1.6075	0.4415	0.1641	0.0306
2400		5.4053	1.7533	0.4815	0.1786	0.0334
2500		5.8781	1.9056	0.5233	0.1936	0.0362
2600		6.3713	2.0643	0.5668	0.2092	0.0392
2700		6.8848	2.2295	0.6120	0.2254	0.0423
2800		7.4189	2.4011	0.6591	0.2422	0.0455
2900		7.9734	2.5793	0.7079	0.2597	0.0488
3000		8.5484	2.7640	0.7585	0.2777	0.0523
3100		9.1441	2.9552	0.8109	0.2963	0.0558
3200		9.7603	3.1529	0.8650	0.3155	0.0595
3300			3.3571	0.9210	0.3353	0.0633
3400			3.5679	0.9787	0.3557	0.0672
3500			3.7853	1.0382	0.3767	0.0712
3600			4.0091	1.0995	0.3983	0.0754
3700			4.2396	1.1626	0.4205	0.0797

Section 7.1 - Table PD-1A

Pressure drop ("wc per foot) for TracPipe based on a given CFH Flow Natural Gas SG = 0.60 Gas) at Inlet Pressures up to 5 psig

Note: For Propane (LP) Gas applications, obtain Pressure Drop per foot values by following the Propane conversion method detailed in Section 7.1 of the TracPipe D&I Guide.

CFH	1"	1-1/4"	1 1/211	2"
СГП		1-1/4	1-1/2"	2
2000	4 4766	1 2275	0.4422	0.0041
3800	4.4766	1.2275	0.4433	0.0841
3900	4.7202	1.2941	0.4666	0.0886
4000	4.9704	1.3626	0.4906	0.0932
4100	5.2271	1.4329	0.5152	0.0979
4200	5.4905	1.5050	0.5403	0.1028
4300	5.7604	1.5788	0.5661	0.1078
4400	6.0370	1.6545	0.5924	0.1129
4500	6.3202	1.7320	0.6194	0.1181
4600	6.6100	1.8112	0.6469	0.1234
4700	6.9064	1.8923	0.6750	0.1289
4800	7.2094	1.9752	0.7037	0.1344
4900	7.5191	2.0599	0.7330	0.1401
5000	7.8355	2.1464	0.7629	0.1459
5250	8.6554	2.3706	0.8402	0.1610
5500	9.5170	2.6062	0.9212	0.1767
5750		2.8531	1.0059	0.1933
6000		3.1114	1.0943	0.2105
6250		3.3811	1.1864	0.2285
6500		3.6623	1.2821	0.2473
6750		3.9548	1.3815	0.2667
7000		4.2588	1.4846	0.2870
7250		4.5743	1.5913	0.3079
7500		4.9012	1.7017	0.3297
7750		5.2397	1.8158	0.3521
8000		5.5896	1.9335	0.3753
8250		5.9511	2.0549	0.3993
8500		6.3241	2.1799	0.4240
8750		6.7086	2.3086	0.4494
9000		7.1047	2.4409	0.4756
9250		7.5124	2.5769	0.5025
9500		7.9316	2.7166	0.5302
9750		8.3625	2.8598	0.5586
10000		8.8049	3.0067	0.5878
10500		9.7247	3.3115	0.6483

CFH	1-1/2"	2"
11000	3.6307	0.7119
11500	3.9645	0.7784
12000	4.3128	0.8479
12500	4.6756	0.9204
13000	5.0529	0.9959
13500	5.4447	1.0744
14000	5.8509	1.1559
14500	6.2716	1.2404
15000	6.7067	1.3278
16000	7.6202	1.5117
17000	8.5913	1.7077
18000	9.6200	1.9156
19000		2.1355
20000		2.3674
21000		2.6113
22000		2.8673
23000		3.1352
24000		3.4152
25000		3.7073
26000		4.0114
27000		4.3275
28000		4.6557
29000		4.9959
30000		5.3482
31000		5.7126
32000		6.0890
33000		6.4775
34000		6.8781
35000		7.2908
36000		7.7155
37000		8.1523
38000		8.6013
39000		9.0623
40000		9.5354

Section 7.1 - Table PD-2A

Pressure drop ("wc per foot) for Black Iron based on a given CFH Flow (Natural Gas SG = 0.60 Gas)

Note: For Propane (LP) Gas applications, obtain Pressure Drop per foot values by following the Propane conversion method detailed in Section 7.1 of the TracPipe D&l Guide.

CFH	1/2"	3/4"	1"	1-1/4"	1-1/2"	2"	2-1/2"	3"
10	0.0003	0.0001						
20	0.0009	0.0002	0.0001					
30	0.0020	0.0005	0.0002					
40	0.0033	0.0009	0.0003	0.0001				
50	0.0050	0.0013	0.0004	0.0001				
60	0.0071	0.0018	0.0006	0.0001	0.0001			
70	0.0094	0.0024	0.0007	0.0002	0.0001			
80	0.0120	0.0031	0.0009	0.0003	0.0001			
90	0.0149	0.0038	0.0012	0.0003	0.0001			
100	0.0181	0.0046	0.0014	0.0004	0.0002	0.0001		
110	0.0216	0.0055	0.0017	0.0005	0.0002	0.0001		
120	0.0254	0.0065	0.0020	0.0005	0.0003	0.0001		
130	0.0295	0.0075	0.0023	0.0006	0.0003	0.0001		
140	0.0338	0.0086	0.0027	0.0007	0.0003	0.0001		
150	0.0384	0.0098	0.0030	0.0008	0.0004	0.0001		
160	0.0433	0.0110	0.0034	0.0009	0.0004	0.0001	0.0001	
170	0.0484	0.0124	0.0038	0.0010	0.0005	0.0001	0.0001	
180	0.0538	0.0137	0.0043	0.0011	0.0005	0.0002	0.0001	
190	0.0595	0.0152	0.0047	0.0012	0.0006	0.0002	0.0001	
200	0.0654	0.0167	0.0052	0.0014	0.0006	0.0002	0.0001	
225	0.0813	0.0208	0.0064	0.0017	0.0008	0.0002	0.0001	
250	0.0988	0.0252	0.0078	0.0021	0.0010	0.0003	0.0001	
275	0.1178	0.0301	0.0093	0.0025	0.0012	0.0003	0.0001	0.0001
300	0.1384	0.0353	0.0109	0.0029	0.0014	0.0004	0.0002	0.0001
325	0.1605	0.0410	0.0127	0.0034	0.0016	0.0005	0.0002	0.0001
350	0.1840	0.0470	0.0146	0.0038	0.0018	0.0005	0.0002	0.0001
375	0.2091	0.0534	0.0165	0.0044	0.0021	0.0006	0.0003	0.0001
400	0.2356	0.0602	0.0186	0.0049	0.0023	0.0007	0.0003	0.0001
425	0.2635	0.0673	0.0208	0.0055	0.0026	0.0008	0.0003	0.0001
450	0.2929	0.0748	0.0232	0.0061	0.0029	0.0009	0.0004	0.0001
475	0.3237	0.0827	0.0256	0.0068	0.0032	0.0010	0.0004	0.0001
500	0.3559	0.0909	0.0282	0.0074	0.0035	0.0010	0.0004	0.0002
525	0.3896	0.0995	0.0308	0.0081	0.0039	0.0011	0.0005	0.0002
550	0.4246	0.1084	0.0336	0.0089	0.0042	0.0012	0.0005	0.0002
575	0.4609	0.1177	0.0365	0.0096	0.0046	0.0014	0.0006	0.0002
600	0.4987	0.1273	0.0394	0.0104	0.0049	0.0015	0.0006	0.0002
625	0.5378	0.1373	0.0425	0.0112	0.0053	0.0016	0.0007	0.0002
650	0.5783	0.1476	0.0457	0.0121	0.0057	0.0017	0.0007	0.0002
675	0.6201	0.1583	0.0490	0.0130	0.0061	0.0018	0.0008	0.0003

Tables calculated from Low-Pressure Gas Formula in NFPA -54

Section 7.1 - Table PD-2A

Pressure drop ("wc per foot) for Black Iron based on a given CFH Flow (Natural Gas SG = 0.60 Gas)

Note: For Propane (LP) Gas applications, obtain Pressure Drop per foot values by following the Propane conversion method detailed in Section 7.1 of the TracPipe D&l Guide..

CFH	1/2"	3/4"	1"	1-1/4"	1-1/2"	2"	2-1/2"	3"
700	0.6632	0.1693	0.0525	0.0139	0.0066	0.0019	0.0008	0.0003
725	0.7077	0.1807	0.0560	0.0148	0.0070	0.0021	0.0009	0.0003
750	0.7535	0.1924	0.0596	0.0157	0.0074	0.0022	0.0009	0.0003
775	0.8006	0.2044	0.0633	0.0167	0.0079	0.0024	0.0010	0.0003
800	0.8490	0.2168	0.0671	0.0177	0.0084	0.0025	0.0011	0.0004
825	0.8987	0.2295	0.0711	0.0188	0.0089	0.0026	0.0011	0.0004
850	0.9497	0.2425	0.0751	0.0198	0.0094	0.0028	0.0012	0.0004
875	1.0020	0.2559	0.0793	0.0209	0.0099	0.0029	0.0012	0.0004
900	1.0556	0.2695	0.0835	0.0221	0.0104	0.0031	0.0013	0.0005
925	1.1105	0.2835	0.0878	0.0232	0.0110	0.0033	0.0014	0.0005
950	1.1667	0.2979	0.0923	0.0244	0.0115	0.0034	0.0014	0.0005
975	1.2241	0.3125	0.0968	0.0256	0.0121	0.0036	0.0015	0.0005
1000	1.2828	0.3275	0.1015	0.0268	0.0127	0.0038	0.0016	0.0006
1100	1.5300	0.3907	0.1210	0.0320	0.0151	0.0045	0.0019	0.0007
1200	1.7972	0.4589	0.1421	0.0375	0.0178	0.0053	0.0022	0.0008
1300	2.0839	0.5321	0.1648	0.0435	0.0206	0.0061	0.0026	0.0009
1400	2.3901	0.6103	0.1890	0.0499	0.0236	0.0070	0.0030	0.0010
1500	2.7154	0.6933	0.2148	0.0567	0.0268	0.0080	0.0034	0.0012
1600	3.0596	0.7812	0.2420	0.0639	0.0302	0.0090	0.0038	0.0013
1700	3.4226	0.8739	0.2707	0.0715	0.0338	0.0101	0.0042	0.0015
1800	3.8043	0.9714	0.3009	0.0795	0.0376	0.0112	0.0047	0.0016
1900	4.2044	1.0735	0.3325	0.0878	0.0416	0.0124	0.0052	0.0018
2000	4.6228	1.1803	0.3656	0.0966	0.0457	0.0136	0.0057	0.0020
2100	5.0593	1.2918	0.4001	0.1057	0.0500	0.0149	0.0063	0.0022
2200	5.5139	1.4079	0.4361	0.1152	0.0545	0.0162	0.0068	0.0024
2300	5.9864	1.5285	0.4735	0.1251	0.0592	0.0176	0.0074	0.0026
2400	6.4766	1.6537	0.5122	0.1353	0.0640	0.0190	0.0080	0.0028
2500	6.9846	1.7834	0.5524	0.1459	0.0690	0.0205	0.0087	0.0030
2600	7.5100	1.9175	0.5940	0.1569	0.0742	0.0221	0.0093	0.0032
2700	8.0530	2.0562	0.6369	0.1682	0.0796	0.0237	0.0100	0.0035
2800	8.6133	2.1992	0.6812	0.1799	0.0851	0.0253	0.0107	0.0037
2900	9.1908	2.3467	0.7269	0.1920	0.0909	0.0270	0.0114	0.0040
3000	9.7856	2.4986	0.7740	0.2044	0.0967	0.0288	0.0121	0.0042
3100		2.6548	0.8223	0.2172	0.1028	0.0306	0.0129	0.0045
3200		2.8153	0.8721	0.2303	0.1090	0.0324	0.0137	0.0048
3300		2.9802	0.9232	0.2438	0.1154	0.0343	0.0145	0.0050
3400		3.1494	0.9756	0.2577	0.1219	0.0363	0.0153	0.0053
3500		3.3228	1.0293	0.2719	0.1286	0.0382	0.0161	0.0056
3600		3.5005	1.0843	0.2864	0.1355	0.0403	0.0170	0.0059
3700		3.6825	1.1407	0.3013	0.1426	0.0424	0.0179	0.0062
3800		3.8687	1.1984	0.3165	0.1498	0.0445	0.0188	0.0065
3900		4.0591	1.2573	0.3321	0.1571	0.0467	0.0197	0.0069

Tables calculated from Low-Pressure Gas Formula in NFPA -54

Section 7.1 - Table PD-2A

Pressure drop ("wc per foot) for Black Iron based on a given CFH Flow (Natural Gas SG = 0.60 Gas)

Note: For Propane (LP) Gas applications, obtain Pressure Drop per foot values by following the Propane conversion method detailed in Section 7.1 of the TracPipe D&I Guide..

CELL	2/4/	411	4.4.4	4.4/211	211	2.4/21	211
CFH	3/4"	1"	1-1/4"	1-1/2"	2"	2-1/2"	3"
4000	4 2527	1 2176	0.2400	0.1647	0.0400	0.0207	0.0073
4000	4.2537	1.3176	0.3480	0.1647	0.0490	0.0207	0.0072
4100	4.4524	1.3792	0.3643	0.1724	0.0513	0.0216	0.0075
4200	4.6554	1.4421	0.3809	0.1802	0.0536	0.0226	0.0079
4300	4.8624	1.5062	0.3978	0.1882	0.0560	0.0236	0.0082
4400	5.0737	1.5716	0.4151	0.1964	0.0584	0.0246	0.0086
4500	5.2890	1.6383	0.4327	0.2048	0.0609	0.0257	0.0090
4600	5.5084	1.7063	0.4507	0.2133	0.0634	0.0268	0.0093
4700	5.7319	1.7755	0.4690	0.2219	0.0660	0.0278	0.0097
4800	5.9595	1.8460	0.4876	0.2307	0.0686	0.0290	0.0101
4900	6.1912	1.9178	0.5066	0.2397	0.0713	0.0301	0.0105
5000	6.4269	1.9908	0.5258	0.2488	0.0740	0.0312	0.0109
5250	7.0338	2.1788	0.5755	0.2723	0.0810	0.0342	0.0119
5500	7.6658	2.3746	0.6272	0.2968	0.0882	0.0372	0.0130
5750	8.3227	2.5780	0.6810	0.3222	0.0958	0.0404	0.0141
6000	9.0043	2.7892	0.7367	0.3486	0.1036	0.0437	0.0152
6250	9.7104	3.0079	0.7945	0.3759	0.1118	0.0472	0.0164
6500		3.2342	0.8543	0.4042	0.1202	0.0507	0.0177
6750		3.4680	0.9160	0.4334	0.1289	0.0544	0.0189
7000		3.7093	0.9798	0.4636	0.1378	0.0582	0.0203
7250		3.9580	1.0455	0.4947	0.1471	0.0621	0.0216
7500		4.2142	1.1131	0.5267	0.1566	0.0661	0.0230
7750		4.4776	1.1827	0.5596	0.1664	0.0702	0.0245
8000		4.7484	1.2542	0.5935	0.1765	0.0745	0.0259
8250		5.0265	1.3277	0.6282	0.1868	0.0788	0.0275
8500		5.3119	1.4031	0.6639	0.1974	0.0833	0.0290
8750		5.6044	1.4803	0.7004	0.2083	0.0879	0.0306
9000		5.9042	1.5595	0.7379	0.2194	0.0926	0.0323
9250		6.2111	1.6406	0.7763	0.2308	0.0974	0.0339
9500		6.5251	1.7235	0.8155	0.2425	0.1023	0.0357
9750		6.8462	1.8083	0.8556	0.2544	0.1074	0.0374
10000		7.1744	1.8950	0.8967	0.2666	0.1125	0.0392
10500		7.8520	2.0740	0.9813	0.2918	0.1231	0.0429
11000		8.5574	2.2603	1.0695	0.3180	0.1342	0.0468
11500		9.2907	2.4540	1.1612	0.3452	0.1457	0.0508
12000			2.6550	1.2563	0.3735	0.1576	0.0549
12500			2.8632	1.3548	0.4028	0.1700	0.0592
13000			3.0786	1.4567	0.4331	0.1828	0.0637
13500			3.3012	1.5620	0.4644	0.1960	0.0683
14000			3.5309	1.6707	0.4967	0.2096	0.0730
14500			3.7676	1.7827	0.5300	0.2237	0.0779
15000			4.0114	1.8981	0.5643	0.2382	0.0830

Tables calculated from Low-Pressure Gas Formula in NFPA -54

Section 7.1 - Table PD-2A

Pressure drop ("wc per foot) for Black Iron based on a given CFH Flow (Natural Gas SG = 0.60 Gas)

Note: For Propane (LP) Gas applications, obtain Pressure Drop per foot values by following the Propane conversion method detailed in Section 7.1 of the TracPipe D&I Guide.

CFH	1-1/4"	1-1/2"	2"	2-1/2"	3"
16000	4.5200	2.1387	0.6359	0.2684	0.0935
17000	5.0563	2.3925	0.7113	0.3002	0.1046
18000	5.6201	2.6593	0.7907	0.3337	0.1163
19000	6.2112	2.9389	0.8738	0.3688	0.1285
20000	6.8293	3.2314	0.9608	0.4055	0.1413
21000	7.4742	3.5366	1.0515	0.4438	0.1546
22000	8.1457	3.8543	1.1460	0.4836	0.1685
23000	8.8437	4.1846	1.2442	0.5251	0.1829
24000	9.5680	4.5273	1.3461	0.5681	0.1979
25000		4.8823	1.4516	0.6126	0.2134
26000		5.2496	1.5608	0.6587	0.2295
27000		5.6292	1.6737	0.7063	0.2461
28000		6.0208	1.7901	0.7555	0.2632
29000		6.4245	1.9102	0.8061	0.2809
30000		6.8403	2.0338	0.8583	0.2990
31000		7.2679	2.1609	0.9120	0.3177
32000		7.7075	2.2916	0.9671	0.3369
33000		8.1589	2.4258	1.0238	0.3567
34000		8.6220	2.5635	1.0819	0.3769
35000		9.0969	2.7047	1.1415	0.3977
36000		9.5834	2.8494	1.2025	0.4189
37000			2.9975	1.2650	0.4407
38000			3.1490	1.3290	0.4630
39000			3.3040	1.3944	0.4858
40000			3.4624	1.4612	0.5091
41000			3.6242	1.5295	0.5329
42000			3.7894	1.5992	0.5572
43000			3.9579	1.6703	0.5819
44000			4.1299	1.7429	0.6072
45000			4.3051	1.8169	0.6330

SECTION 7.2 — SIZING TABLE FOR STEEL PIPE Natural Gas 0.5 PSI or less / 0.5 inch w.c. drop

SECTION 7.2

Table SP-1

Maximum Capacity of Sch. 40 Metallic Pipe in Cubic Feet of Gas per Hour for Gas Pressures of 0.5 PSI or Less and a Pressure Drop of 0.5 Inch Water Column (Based on a 0.6 Specific Gravity)

	200	8	19	35	72	135	280	430	800	1,280	2,280	4,600
	175	o	20	37	77	145	300	460	850	1,370	2,450	2,000
	150	10	22	40	84	160	325	200	950	1,500	2,650	5,500
	125	1	24	44	93	175	360	550	1,020	1,650	2,950	6,000
	100	12	27	20	103	195	400	620	1,150	1,850	3,250	6,700
	06	13	29	53	110	205	430	650	1,220	1,950	3,450	7,200
(Feet)	80	14	31	25	118	220	460	069	1,300	2,050	3,700	7,500
Length of Pipe (Feet)	70	15	33	61	125	240	490	750	1,400	2,250	3,900	8,100
Le	09	16	36	99	138	260	530	810	1,520	2,400	4,300	8,800
	20	18	40	73	151	285	580	006	1,680	2,650	4,750	9,700
	40	20	45	82	170	320	099	066	1,900	3,000	5,300	10,900
	30	24	52	26	200	375	770	1,180	2,200	3,520	6,250	12,800
	20	29	99	120	250	465	950	1,460	2,750	4,350	7,700	15,800
	10	43	98	175	360	680	1,400	2,100	3,950	6,300	11,000	23,000
Internal	(inches)	.364	.493	.622	.824	1.049	1.380	1.610	2.067	2.469	3.068	4.026
Normal Iron Pipe		1/4	3/8	1/2	3/4	-	1 1/4	1 1/2	2	2 1/2	က	4

CHAPTER 8 DEFINITION OF TERMINOLOGY

A.G.A. - American Gas Association

ANSI Z223.1 1988 – 1988 edition of the National Fuel Gas Code published by American National Standard Institute. Also known as NFPA 54 (National Fire Protection Association).

Appliance (Equipment) – Any device which utilizes natural gas or propane as a fuel or raw material to produce light, heat, power, refrigeration or air conditioning.

Approved – Acceptable to the authorities having jurisdiction.

Authority Having Jurisdiction – The organization, office or individual responsible for "approving" equipment, an installation or a procedure.

BTU – Abbreviation for British Thermal Unit, which is the quantity of heat required to raise the temperature of one pound of water one degree Fahrenheit.

CFH – Gas flow rate stated in cubic feet per hour.

Clothes Dryer – A device used to dry wet laundry by means of heat derived from the combustion of natural gases.

Design Pressure – The maximum operating pressure permitted by this document, as determined by the design procedures applicable to the materials involved.

Drip Leg – The container (dirt trap pocket) placed at a low point in a system of piping to collect foreign material or condensate and from which it may be removed.

EHD (Effective Hydraulic Diameter) – A relative measure of flow capacity; This number is used to compare individual sizes between different manufacturers. The higher the EHD number the greater flow capacity of the piping.

Full Lockup – The capability of totally stopping the flow of gas if the load goes to zero, thus preventing the downstream pressure from increasing more than a certain upper limit pressure above the set point.

Header (manifold) – A pipe or fitting to which a number of branch lines are connected.

ID – Inside diameter of pipe or tubing.

Inches (") W.C. – Method of stating pressure measured in inches of water column by a manometer or pressure gauge. Commonly used in the gas industry when the pressure is less than one (1) PSI.

1 PSI = 28 in. W.C. approximately

1/2 PSI = 14 in. W.C.

1/4 PSI = 7 in. W.C.

Load – The amount of gas in CFH required by an appliance, or group of appliances, per their rating plate.

L. P. Gas – Fuel gas that is stored and transported in a liquid state, i.e., propane, butane, and mixtures of these and other heavier hydrocarbons.

Meter – An instrument installed to measure the volume of gas delivered through a piping system.

Manometer – A "U" shaped tube filled with water, or mercury where the pressure applied to one leg of the "U" will push the liquid column a measurable distance. Also known as a "U" gauge.

0D – Outside Diameter of pipe or tubing.

1/2 PSI – A shortened way of stating 1/2 pounds per square inch gauge. Also the name of a low pressure piping system supplying gas from the meter at 1/2 PSI to each appliance pressure regulator.

Piping – As used in this document, either pipe or tubing, or both.

- a. pipe Rigid conduit of iron, steel, copper, brass or aluminum.
- tubing Semi rigid conduit of corrugated stainless steel.

Pressure – Unless otherwise stated, is expressed in pounds per square inch above atmospheric pressure, i.e. gage pressure (PSI).

Pressure Drop – The loss in static pressure of gas due to friction or obstruction in tubing, valves, fittings, regulators and burners.

Pressure Regulator – A device that reduces and controls pressure. It automatically opens and closes in response to changing pressure conditions in the downstream piping.

PSI – Pounds per square inch gauge. The pressure, as read from a measurement gage or device. Gauge pressure is pressure above atmospheric pressure.

Purge – To displace the original air, or gas, or a mixture of gas and air in a gas conduit with a new air/gas mixture.

Regulator, Appliance (inches w.c. – inches w.c.) – A device for controlling and maintaining a uniform pressure to the manifold of gas burning equipment. This valve is typically part of the appliance. It reduces the pressure from 5.5" w.c. to the manifold pressure in the appliance. (approximately 3.5" w.c.).

Regulator, Line Gas Pressure (PSI – inches w.c.) – A device placed in a gas line between the service regulator and the appliance regulator for controlling, maintaining or reducing the pressure in that portion of the piping system downstream of the device. This valve reduces the house line pressure (typically 2 PSI) to the regulator manifold pressure (typically 8-10" w.c.).

Regulator, Service (PSI – PSI or inches w.c.) – A device installed by the serving gas supplier to reduce and limit the service line gas pressure. This valve reduces the service pressure to the metering pressure. It is located upstream of the gas meter.

Regulator Vent – The opening in the atmospheric side of the regulator housing permitting the in and out movement of air to compensate for the movement of the regulator diaphragm.

Specific Gravity – As applied to gas, the ratio of the weight of a given volume to that of the same volume of air, both measured under the same conditions.

2 PSI – A shortened way of stating 2 pounds per square inch gauge pressure. Also the name of a piping system supplying gas at 2 PSI to a line gas pressure regulator which then reduces the pressure to inches W.C. upstream of the appliance regulator.

Valve, Manual Shut-off – A valve (located in the piping system and readily accessible and operable by the consumer) used to shut off individual equipment.


Vent Limiter Device – Restriction/orifice type device in the vent outlet of a pressure regulator that controls or limits leakage, in the event of a diaphragm leak. It also allows the diaphragm to move freely to control pressure.

APPENDIX A

UL CLASSIFICATION

System No. W-J-1106

F-Rating - 1 & 2 Hr T-Rating - 3/4 and 1-1/4 Hr



- 1. Wall Assembly- Min 4-7/8 in. or 6-1/8 in. thick lightweight or normal weight (100-150 pcf) concrete for 1 or 2 hr rated assemblies, respectively. Wall may also be constructed of any UL Classified Concrete Blocks*. Max diam of opening is 3-1/2 in.
 - See Concrete Blocks (CAZT) category in the Fire Resistance Directory for names of manufacturers.
- 2. Through Penetrating Products*-Flexible Metal Piping-Nom. 2 in. diam (or smaller) steel flexible metallic piping. Max one flexible metal piping to be installed either concentrically or eccentrically within opening. The annular space between piping and periphery of opening shall be min 0 (point contact) in. to max 1 in. Piping to be rigidly supported on both sides of wall assembly. Plastic covering on piping may or may not be removed on both sides of wall assembly.
 - Omegaflex Inc. Counterstrike Flexible Gas Piping.
- 3. Fill, Void, or Cavity Material*-Sealant -Min. 5/8 and 1 in. thickness of fill material for 1 and 2 hr fire-rated wall assemblies, respectively, applied within the annulus, flush with both surfaces of wall. An additional 1/2 in. diam of fill material applied at gypsum board/penetrant interface at point contact location on both surfaces of wall. Johns Manville International. Inc. — Firetemp™ Cl

*Bearing the UL Classification Marking

SYSTEM No. C-AJ-1340

Floor or Wall Assembly-Min 4-1/2 in. thick lightweight or normal weight (100 to 150 pcf) concrete. Wall may also be constructed of any UL Classified Concrete Blocks*. Diam of opening in floor or wall assembly to be min 3/4 in. to max 1-1/2 in. Larger than diam of flexible metal piping (Item 2) installed in through opening. Max diam of opening is 4 in. See Concrete Block (CAZT) category in the Fire Resistance Directory for names of manufacturers.

Through-Penetrant*-Omegaflex Gas Piping-Nom 2 in. diam (or smaller) flexible gas piping. One flexible gas piping to be installed either concentrically or eccentrically within the firestop system. The annular space between gas piping and periphery of opening shall be min 0 in. (point contact) to max. 1-1/2 in. Gas piping to be rigidly supported on both sides of floor or wall assembly. Plastic covering on piping may or may not be removed on both sides of floor or wall assembly. OmegaFlex, Inc.-CounterStrike Flexible

Firestop System -The firestop system shall consist of the following: A. Packing Material-Min 3-3/4 in. thickness of min 4 pcf mineral wool batt insulation firmly packed into opening as a permanent form. Packing

material to be recessed from top surface of floor or from both surfaces wall as required to accommodate the required thickness of fill material.


B. Fill, Void or Cavity Material* -Sealant Min 3/4 in. thickness of fill material applied within the annulus, flush with top surface of floor or both surfaces of wall. Min 1/2 in. diam bead of caulk applied to the penetrant/concrete or penetrant/concrete interface at the point contact location between penetrant and periphery of opening.

Passive Fire Protection Partners--4800DW

* Bearing the UL Classification Marking

XHEZ Through Penetration Firestop systems

System No. C-AJ-1340 F-Rating - 4 Hr **T-Rating - 2 1/4 Hr**



Underwriters Laboratories, Inc.®


UL CLASSIFICATION

SYSTEM NO. W-L-1195

- 1. Wall Assembly- The 1 or 2 hr fire rated gypsum wallboard/stud wall assembly shall be constructed of the materials and in the manner described in the individual U300 or U400 Series Wall and Partition Designs in the UL Fire Resistance Directory and shall include the following construction features:
- **A. Studs-** Wall framing may consist of either wood studs or steel channel studs. Wood studs to consist of nom 2 by 4 in. lumber spaced 16 in. OC with nom 2 by 4 in. Lumber end plates and cross braces. Steel studs to be min 3-5/8 in. wide by 1-3/8 in. deep channels spaced max 24 in. OC.
- **B. Wallboard, Gypsum*** Thickness, type, number of layers and fasteners as required in the individual Wall and Partition Design. Max diam of opening is 3-1/2 in.

The UL Through Penetration Firestop Systems in Appendix A are only a sample of the complete UL database. See NOTE below.

XXEZ
Through-Penetration Firestop Systems
System No. W-L-1195
F Rating - 1 & 2 hr (See Item 1)
T Rating - 3/4 & 1-1/4 hr(See Item 1)



Underwriters Laboratories inc.®

- 1. The hourly F rating of the firestop system is equal to the hourly fire rating of the wall assembly in which it is installed. The hourly T rating is 3/4 hr and 1-1/4 hr for 1 and 2 hr rated assemblies, respectively.
- 2. Through-Penetrating Product*-Flexible Metal Piping-Nom 2 in. diam (or smaller) steel Flexible Metal Piping. Max one flexible metal piping to be installed either concentrically or eccentrically within opening. The annular space between pipe and periphery of opening shall be min 0 in. (point contact)to max 1 in. Piping to be rigidly supported on both sides of wall assembly. Plastic covering on piping may or may not be removed for a distance of 2 ft. on both sides of wall assembly. OmegaFlex, Inc.- CounterStrike Flexible Gas Piping.
- **3. Fill, Void, or Cavity Material*-Sealant** Min 5/8 and 1 in. thickness of fill material for 1 and 2 hr fire-rated wall assemblies, respectively, applied within the annulus, flush with both surfaces of wall. An additional 1/2 in diameter of fill material applied at gypsum board/penetrant interface at point contact location on both surfaces of wall.

Johns Manville International, Inc. - Firetemp™CI

*Bearing the UL Classification Marking


NOTICE: to access the complete UL Through Penetration Firestop Systems database online:

- 1. Go to website www.ul.com
- 2. Click on: "CERTIFICATIONS" in left hand panel
- 3. Click on: "Company name/location" under General Search
- 4. Fill in OmegaFlex inc (3 words) in "Company Name" box
- 5. All approved systems are shown



F Rating - 1 and 2 Hr (See Item 1) T Rating - I Hr

F-C-1111



- 1. Floor Assembly The 1 or 2 hr fire-rated wood joist, wood truss or combination wood and steel truss Floor-Ceiling assembly shall be constructed of the materials and in the manner described in the individual L500 Series Design in the UL Fire Resistance Directory. The F Rating of the firestop system is equal to the rating of the floor-ceiling and wall assemblies. The general construction features of the floor-ceiling assembly are summarized below:
 - A. Flooring System Lumber or plywood subfloor with finish floor of lumber, plywood or Floor Topping Mixture* as specified in the individual Floor-Ceiling Design. Max diam of opening is 3 in. (76 mm).
 - B. Joists Nom 2 by 10 in. (51 by 254 mm) deep (or deeper) lumber joists spaced 16 in. (406 mm) OC or steel or combination lumber and steel joists, trusses or Structural Wood Members* with bridging as required and with ends firestopped.
 - C. Furring Channels (Not Shown) (As required) Resilient galvanized steel furring installed in accordance with the manner specified in the individual L500 Series Designs in the Fire Resistance Directory.
 - D. **Gypsum Board*** Thickness, type, number of layers and fasteners shall be as specified in the individual Floor-Ceiling Design. Max diam of opening is 3 in. (76 mm).
- 2. **Through Penetrating Products* Flexible Metal Piping-**Nom 2 in. (51 mm) diam (or smaller) steel Flexible Metal Piping with or without plastic covering on piping. Max one flexible metal piping to be installed near center of circular through opening in floor assembly. The annular space between the piping and periphery of opening shall be min 0 in. (0 mm) (point contact) to max 1/2 in. (13 mm). Piping to be rigidly supported on both sides of floor assembly.
- 3. **Fill, Void or Cavity Material* Sealant** Min 3/4 in. (19 mm) thickness of sealant applied within annulus on top surface of floor. Min 5/8 in. (16 mm) thickness of sealant applied within annulus on bottom surface of ceiling. At point contact location, a min 1/2 in. (13 mm) bead of sealant shall be applied to the penetrant/gypsum board interface on bottom surface of ceiling and at penetrant/flooring interface on top surface of floor.

Passive Fire Protection Partners** - 3600EX, 41GONS or 4800DW

- *Bearing the UL Classification Marking
- **Formerly Firestop Systems Inc.



09/03

APPENDIX B MANUFACTURED HOUSING GUIDELINES

A. CODE AND ADMINISTRATIVE REQUIREMENTS

- 1. Manufactured homes and mobile homes bearing an insignia or required to bear an insignia must comply with Title VI 24 Code of Federal Regulations, The National Manufactured Housing Act of 1974 Part 3280. In most jurisdictions this requirement remains in force when the structural, electrical plumbing or mechanical systems are altered. The Code of Federal Regulations, Housing and Urban Development, Part 3280 Manufactured Home Construction and Safety Standards is applicable throughout the USA for manufactured housing construction (also known as "HUD code" housing).
- 2. There are other types of factory-built housing that do not fall directly under the classification "HUD code" which must also be reviewed for special installation considerations when designing a CSST gas piping system or appliance retrofit. Some examples of this type of housing are Assembly Buildings, Panelized, Modular, and Production Build. *TracPipe® CounterStrike®* should not be considered for RVs, which are subject to over the road use and not just initial placement or repositioning.
- 3. Part 3280 Manufactured Home Construction and Safety Standards 1994 has not been revised or updated for several years. There has been an effort by both NFPA and CABO (now a part of the ICC) to have the US Congress adopt a new Manufactured Housing Code. The latest version of the CABO Code ICC/ANSI 2.0 Manufactured Housing Construction Safety Standards is available but has not been adopted by Congress.
- 4. Omegaflex has obtained a written opinion from the U.S. Department of Housing and Urban Development regarding the use of *TracPipe® CounterStrike®* CSST. This HUD decision states "CSST, such as *TracPipe® CounterStrike®*, is allowed to be used in HUD manufactured homes (based upon incorporation of *NFPA 54-1992 ANSI 223.1 The National Fuel Gas Code* into Section 3280.703 Minimum Standards)." This opinion shall be confirmed with State authorities responsible for inspections of HUD Code buildings prior to installing *TracPipe® CounterStrike®* after the home has left the factory. For factory installations, approval by the DAPIA (Manufacturer's Design Approval Primary Inspection Agency) is normally required for the piping system design. Contact Omegaflex for specification data and a copy of the HUD decision letter.


B. PIPING SYSTEM DESIGN REQUIREMENTS


1. The primary information for any *TracPipe® CounterStrike®* installation is contained in the *TracPipe® CounterStrike®* Design Guide and Installation Instructions (latest edition). This guide provides manufacturer's instructions that are a requirement of the ANSI/CSA LC-1 Standard governing certification and test requirements for Corrugated Stainless Steel Tubing. Manufacturer's instructions must be followed.

APPENDIX B MANUFACTURED HOUSING GUIDELINES

A. CODE AND ADMINISTRATIVE REQUIREMENTS

- 1. Manufactured homes and mobile homes bearing an insignia or required to bear an insignia must comply with Title VI 24 Code of Federal Regulations, The National Manufactured Housing Act of 1974 Part 3280. In most jurisdictions this requirement remains in force when the structural, electrical plumbing or mechanical systems are altered. The Code of Federal Regulations, Housing and Urban Development, Part 3280 Manufactured Home Construction and Safety Standards is applicable throughout the USA for manufactured housing construction (also known as "HUD code" housing).
- 2. There are other types of factory-built housing that do not fall directly under the classification "HUD code" which must also be reviewed for special installation considerations when designing a CSST gas piping system or appliance retrofit. Some examples of this type of housing are Assembly Buildings, Panelized, Modular, and Production Build. *TracPipe® CounterStrike®* should not be considered for RVs, which are subject to over the road use and not just initial placement or repositioning.
- 3. Part 3280 Manufactured Home Construction and Safety Standards 1994 has not been revised or updated for several years. There has been an effort by both NFPA and CABO (now a part of the ICC) to have the US Congress adopt a new Manufactured Housing Code. The latest version of the CABO Code ICC/ANSI 2.0 Manufactured Housing Construction Safety Standards is available but has not been adopted by Congress.
- 4. Omegaflex has obtained a written opinion from the U.S. Department of Housing and Urban Development regarding the use of *TracPipe® CounterStrike®* CSST. This HUD decision states "CSST, such as *TracPipe® CounterStrike®*, is allowed to be used in






HUD manufactured homes (based upon incorporation of *NFPA 54-1992 ANSI 223.1 The National Fuel Gas Code* into Section 3280.703 Minimum Standards)." This opinion shall be confirmed with State authorities responsible for inspections of HUD Code buildings prior to installing *TracPipe® CounterStrike®* after the home has left the factory. For factory installations, approval by the DAPIA (Manufacturer's Design Approval Primary Inspection Agency) is normally required for the piping system design. Contact Omegaflex for specification data and a copy of the HUD decision letter.

B. PIPING SYSTEM DESIGN REQUIREMENTS

- 1. The primary information for any *TracPipe® CounterStrike®* installation is contained in the *TracPipe® CounterStrike®* Design Guide and Installation Instructions (latest edition). This guide provides manufacturer's instructions that are a requirement of the ANSI/CSA LC-1 Standard governing certification and test requirements for Corrugated Stainless Steel Tubing. Manufacturer's instructions must be followed.
- 2. Sizing for gas piping systems in HUD Code homes must be performed in accordance with Part 3280 (Natural Gas piping system acceptable for LP-gas). System sizing is to be done with Low Pressure Capacity Charts utilizing 0.5-inch water column drop. (See Chart N-1 in the *TracPipe® CounterStrike®* Design Guide).
- 3. The natural gas supply connections shall not be less than the size of the gas piping but shall not be smaller than 3/4-inch nominal pipe size. Gas supply connection shall <u>not</u> be



beneath an exit door. Gas supply connection shall be rigidly anchored to a structural member within 6 inches of supply connection. All exterior openings around piping shall be sealed to resist the entrance of rodents.

- 4. Where fuel gas piping is to be installed in more than one section of an expandable or multiple-unit home, crossover connections between sections of the home shall be constructed by one of the following methods:
 - A. Listed quick disconnect device, designed to provide a positive seal of the supply side of the gas piping system when such device is separated.
 - B. Flexible connectors listed for exterior use and a shutoff valve of the non-displaceable rotor type conforming to ANSI Z21.15, installed on supply side.
 - C. Direct plumbing (CSST) sized in accordance with Natural Gas Low Pressure Capacity Chart N-1 in Chapter & of this installation guide.

- 5. The flexible connector, direct plumbing pipe or "quick-disconnect" device shall be provided with protection from mechanical and impact damage and located to minimize the possibility of tampering. For gas line crossover connections made with CSST or flexible connectors, the crossover points shall be capped on the supply side to provide a positive seal and covered on the other side with a suitable protective covering.
- 6. All points of crossover shall be accessible from the exterior of the home.

C. INSTALLATION REQUIREMENTS

- 1. The preferred location for CSST flexible gas piping is beneath the floor and inside or above the I-beam flange. This location will provide the best protection from transit damage. Appliance stub-outs are easily made utilizing termination mounts or flange mounts rigidly attached to the floor. Final connections can be made with approved flexible appliance connectors downstream from the appliance shut-off valve. All floor penetrations shall be sealed to resist the entrance of rodents. All CSST should be within the envelope or rigidly attached to the I-beam flange.
- 2. Where CSST must cross an I-beam flange, the piping shall be securely attached to the house flange to protect the CSST. Angle iron, C-channel or a wooden block are recommended means of attachment. It is preferred to drill through a wooden structural member if possible to avoid crossing the flange.
- 3. In open joist construction, routing should be within the open web portion of the fabricated joist wherever possible. This location provides necessary support points at each joist location.
- 4. In all locations, CSST must be supported in accordance with the manufacturer's instructions (every 4 feet-3/8 size, 6 feet-1/2 size, 8 feet-3/4 size and 1 inch size) Support should be with metal EMT conduit straps or two-point attachment plastic clips suitable for the size of the tubing.
- 5. If a manifold is used, it shall be rigidly mounted to the I-beam flange. This applies to parallel system layouts. Gas pressure in HUD Code homes is limited to 14 inches water column maximum. Line pressure regulators are not necessary for this pressure and should not be used.
- 6. The gas piping shall be bonded to the frame of the home by the use of:
 - a. Solderless type grounding terminal with a star washer bolted to the chassis;
 - b. Grounding clamp attached to a gas piping fitting. (For attachment of clamp to *TracPipe® AutoFlare®* fitting, refer to Section 4.10 Electrical Bonding/Grounding. Do not attach clamp to the stainless steel portion under any circumstances.); and
 - c. Bonding electrode conductor sizing shall be in accordance with NFPA 70 Article 250 Section and Table 250-66.

- 7. Concealed tubing: CSST shall not be run inside walls, partitions or roofs. Where tubing passes through walls, floors, partitions, roofs, or similar installations, such tubing shall be protected by the use of weather resistant grommets that shall snugly fit both the tubing and the hole through which the tubing passes. DO NOT remove the yellow polyethylene jacket in any penetrations.
- 8. All CSST tubing joints shall have any exposed sections of stainless steel piping wrapped with silicone self-bonding tape. The under-floor portion of the manufactured home is considered an outdoor location. Proper support (per item 4 above) is required under the floor.

9. Retrofit of appliances:

- a. The gas supply connection shall be rigidly anchored to a structural member within 6 inches of supply connection.
- b. CSST shall be supported and protected per manufacturer's instructions. (See items 4 and 7 above.)
- c. Pressure test gas piping per Item D 1 below before operating appliance.

D. INSPECTION AND TEST REQUIREMENTS

1. Pressure test in accordance with Part 3280.705k (8) testing for leakage (8 i) before appliances are connected and (8 ii) after appliances are connected.

APPENDIX C

SECTION C1.1 - AUTOTRIP® LOW PRESSURE EXCESS FLOW VALVES FOR NATURAL GAS AND PROPANE SERVICE

An excess flow valve (EFV) is a protective device to help control the discharge of fuel gas in the event of a complete breakage of pipe lines or flex connector rupture. Excess flow valves have been of help in limiting gas loss in many incidents involving breakage of piping; thus they do provide a useful safety function in gas systems. This section explains what protection excess flow valves can offer, points out conditions which can interfere with that protection, and offers suggestions for effective excess flow valve installation.

 There are two types of **AutoTrip**® EFVs: LFD Series Line/Meter excess flow valves and AFD Series Appliance Connector excess flow valves.



A. **AutoTrip® LFD Line/Meter Excess Flow Valves (EFVs)** protect against potential damage due to the release of fuel gas as a result of residential and commercial gas line breaks. **AutoTrip®** excess flow valves work in conjunction with all approved gas piping materials (**TracPipe® CounterStrike®**, other brands of CSST, steel pipe, and copper tube) at the gas meter, second stage regulator, the appliance branch line or manifold connection.

B. AutoTrip® AFD Appliance Connector Excess Flow Valves protect against potential damage due to the release of fuel gas when a flexible gas appliance connector line breaks.

AFD Series

AutoTrip® Appliance Connector EFVs act to restrict the flow of gas should the downstream appliance connector suffer a complete break or pull-out. The inlet side of the AutoTrip® Appliance Connector excess flow valve adapts to all approved gas piping materials (TracPipe® CounterStrike®, other brands of CSST, steel pipe, and copper tube) with an NPT connection. The Outlet side comes equipped with an SAE flare for connection to standard appliance connectors.

2. Quality Assurance

- AutoTrip® valves are Design-Certified by CSA International and manufactured and 100% factory tested in accordance with the IAS U.S. Requirements 3-92 for Excess Flow Valves.
- Listed by IAPMO File 5031-International Association of Plumbing and Mechanical Officials.
- Listed by CA-DSA-California Division of State Architect.

3. IMPORTANT NOTES and LIMITATIONS Regarding the Use of Excess Flow Valves

Installation of the *AutoTrip*® excess flow valve must only be performed by a qualified plumber or gas fitter who meets state and/or local requirements to perform work on fuel gas piping systems. The *AutoTrip*® valve must be installed in compliance with local codes or, in the absence of local codes, with the National Fuel Gas Code ANSI Z223.1/NFPA 54, The International Fuel Gas Code, or The Uniform Plumbing Code.

IMPORTANT

- 1. Read all installation instructions and limitations before installing.
- 2. Size the excess flow valve to match the gas demand for appliances installed. See sizing instructions below. DO NOT OVERSIZE the valve for anticipated appliance additions.
- 3. Prior to installing, TURN OFF gas supply using an upstream shut-off valve.
- 4. Install the excess flow valve with the proper flow direction as marked on the label and in the correct position (vertical up only for LFD models) and (multipoise [any position] for AFD models) as specified in these instructions.
- 5. After installation is complete, pressurize system by opening gas supply shut off valve VERY SLOWLY to initiate gas service.
- 6. Check all connections with a non-corrosive leak detector solution to assure connections are leak tight. (Available: TracPipe Leak Check Solution P/N FGP-LCS).

4. LIMITATIONS OF *AUTOTRIP* ® EXCESS FLOW VALVES FOR NATURAL GAS AND PROPANE SYSTEMS

AutoTrip® excess flow valves are designed to protect against complete breakage of gas lines DOWNSTREAM of the location of which the **AutoTrip**® excess flow valve is installed. **AutoTrip**® excess flow valves installed at the Meter are designed only to protect the main trunk line piping of like size of which it was installed. These devices may not protect against gas piping breaks at a given length downstream from the EFV or after a reduction in pipe size. Additional factors that may affect the proper function of an EFV:

- 1. The system was not sized properly to allow the EFV to close upon complete breakage of a gas line
- 2. The system was not sized properly with the EFV to allow proper operation of all appliances
- 3. The supply pressure is not great enough to provide the required capacity
- 4. Restrictions exist in the gas piping system that prevent proper operation of the EFV such as, but not limited to, reductions in pipe size, incomplete or partial breaks of gas lines, partially open or smaller than full-bore valves or components in the gas piping system, any additional restrictions that would prevent the required capacity of gas to escape from the system that would close the valve.
- 5. Foreign matter, such as pipe thread sealant, is lodged in valve, preventing closure.
- The excess flow valve has been damaged by fire or improper installation and is no longer in operating condition. NOTICE: If the valve is not in operating condition, IT MUST BE REPLACED.

SECTION C1.2 - AUTOTRIP LFD SERIES EXCESS FLOW VALVES FOR METER AND BRANCH LINE/MANIFOLD APPLICATIONS

LFD SERIES PRODUCT SPECIFICATIONS

Material Specification:

Body Brass Nickel Plated

Seat & Retainer Polyamide

Valve Float / Ball POM or PTFE

Operating Temperature: -20°F to 150°F

Operating Pressure: 0.18 PSI (5"wc) to 2 PSI Maximum Bypass Flow: 10 CFH (Air equivalent)

For additional product information including Model Numbers, inlet/outlet thread connections, Maximum load capacity and flow rates, & application please reference Table C.1.

C1.2.1 - APPLICATION, AND SELECTION OF *AUTOTRIP®* LFD SERIES EXCESS FLOW VALVES

- Application. Determine the Type of EFV based on the application (Ref. Figure: 3.10).
 - a) Meter
 - b) Branch Line
- 2. EFV Model Selection. From TABLE: C.1, select the appropriate **AutoTrip®** LFD Series EFV(s) based on the TOTAL BTU/hr load capacity of the appliance(s) it serves. For a Meter application, this is the TOTAL BTU/hr load capacity of ALL the appliance(s) served by the gas meter. For a Branch Line application, this is the BTU/hr load capacity of the appliance(s) on the branch for which the **AutoTrip®**




FIGURE: C-1

EFV is installed. The TOTAL BTU/hr load capacity of the appliance(s) should be equal to or less than the Maximum Load Capacity (BTU/hr) value of the **AutoTrip®** LFD Series EFV selected from TABLE: C.1.

TABLE: C.1

AutoTrip® LFD Series Excess Flow Valves Application Data

EFV Type - Application	OmegaFlex AutoTrip P/N	Mounting Position	Inlet Thread Connection(s)	Outlet Thread Connection(s)	Maximum Load Capacity (BTU/hr)	Nominal Closure Flow Rate (SCFH)
Appliance Branch Line	FGP-LFD-70	Vertical Up ONLY	3/4" M-NPT & 1/2" F-NPT	3/4" M-NPT & 1/2" F-NPT	70,000	97
Appliance Branch Line	FGP-LFD-125	Vertical Up ONLY	3/4" M-NPT & 1/2" F-NPT	3/4" M-NPT & 1/2" F-NPT	125,000	147
Meter / Branch Line	FGP-LFD-275A	Vertical Up ONLY	3/4" M-NPT & 1/2" F-NPT	3/4" M-NPT & 1/2" F-NPT	275,000	335
Meter / Branch Line	FGP-LFD-275B	Vertical Up ONLY	1" M-NPT & 3/4" F-NPT	1" M-NPT & 3/4" F-NPT	275,000	335
Meter / Branch Line	FGP-LFD-375	Vertical Up ONLY	1" M-NPT & 3/4" F-NPT	1" M-NPT & 3/4" F-NPT	375,000	460
Meter / Branch Line	FGP-LFD-500	Vertical Up ONLY	1 1/4" M-NPT & 1" F-NPT	1 1/4" M-NPT & 1" F-NPT	500,000	685

Notes:

- 1) Flow Rates given for 0.60 Specific Gravity Natural Gas with an Avg. Heating Value of 1000 BTU / cubic foot.
- 2) To convert Maximum Load Capacity value to BTU/hr Propane (1.52 Specific Gravity, 2520 BTU / cubic foot), multiply Natural Gas Value by 1.583.
- 3) To convert SCFH Nominal Closure Flow Rate to SCFH Propane, multiply Natural gas Value above by 0.628
- 4) Abbreviations: w.c. = inches water column.

SCFH = Standard Cubic Feet per Hour.

C1.2.2 - GAS PIPING SYSTEM SIZING WITH LFD SERIES EXCESS FLOW VALVES

AutoTrip® LFD Series excess flow valves must be sized properly for the gas piping system in which they are installed. When installing **AutoTrip**® excess flow valves within a fuel gas piping system, the user must assure that:

- The AutoTrip® LFD Series EFV will close upon a complete breakage or rupture of gas piping at an expected length downstream of the EFV. It is recommended that the installer conduct tests on the gas piping system to ensure the EFV(s) will function as intended. Note: Tests should be performed in accordance with all applicable local and national codes.
- 2. The addition of the *AutoTrip®* LFD Series EFV will allow all appliances to which the EFV serves to operate properly without the undue loss of pressure. It is recommended that the installer run all appliances with the EFV(s) installed to assure proper operation.

C1.2.3 - METHODS OF SIZING

STANDARD SIZING METHOD - When sizing a gas piping system including *AutoTrip*® LFD Series EFVs, size the gas piping system using the following Tables: (N-1AT, N-3AT, N-5AT, SP-1AT, P-1AT) using standard methods of gas pipe sizing – Branch Length or Longest Run Method.

ALTERNATE SIZING METHOD – If using an Engineered Method, i.e. "Sum of Pressures Method" of gas pipe sizing, use the pressure drop values in Figure C-3 in your gas piping calculations.

C1.2.4 - SIZING INSTRUCTIONS FOR AUTOTRIP LFD SERIES EFVS USED WITH COUNTERSTRIKE® CSST SYSTEMS

- A. Meter Applications (LFD Series LFD 275A, LFD-275B, LFD-375, LFD-500)
 - Choose the appropriate **AutoTrip®** LFD Series Meter EFV using TABLE C.1 based on the total capacity of the gas piping system served by that meter.
 - 2. Using the appropriate AutoTrip® Capacity Chart "Table N-1AT AutoTrip® Low Pressure" or "Table N-5AT AutoTrip® (2-PSI system)" based upon system pressure; determine the size of CSST based on the AutoTrip® EFV selected in Step 1 and the appropriate sizing length. This size of CSST is designed to allow the AutoTrip® EFV to act as a safety shutoff valve in the event of a complete breakage of the main trunk line piping.
- B. Branch Line/Manifold Applications (LFD Series LFD-70, LFD-125, LFD-275A, LFD-275B, LFD-375, and LFD-500):
 - 1. Elevated Pressure 2 PSI system. (Manifold with parallel arrangement).
 - a. Choose the appropriate size **AutoTrip®** LFD Series Appliance Branch Line EFV using TABLE: 3.1 based on the capacity for each manifold outlet. Select an EFV with sufficient capacity to supply the appliance(s) connected to the outlet.
 - b. Using **AutoTrip**® Capacity Chart "TABLE: N-3AT **AutoTrip**® Dual Pressure System" determine size of **CounterStrike®** CSST based on the **AutoTrip®** EFV selected in Step a and the appropriate sizing length from the manifold to the appliance(s). This size of CSST is designed to allow the **AutoTrip®** EFV to act as a safety shutoff valve in the event of the complete breakage of the downstream branch pipe line or flex connector rupture.

- 2. Series System Low Pressure
 - a. When there is no manifold, the EFV should be located at the tee or fitting where the appliance drop attaches to the trunk line. If this is a concealed location, follow local codes.
 - b.Choose the appropriate size **AutoTrip®** LFD Series Appliance Branch Line EFV using TABLE C.1 based on the capacity for that branch line. Select an EFV with sufficient capacity to supply the appliance(s) connected to that drop.
 - c. Using AutoTrip® Capacity Chart "Table N-1AT **AutoTrip**® Low Pressure" determine size of CounterStrike® CSST based on the **AutoTrip**® EFV selected in Step b and the appropriate sizing length from the appliance back to the meter. This size of CSST is designed to allow the AutoTrip® EFV to act as a safety shut-off valve in the event of a complete breakage of the downstream branch pipe line or flex connector rupture.

C1.2.5 - SIZING INSTRUCTIONS FOR *AUTOTRIP* LFD SERIES EFVS USED WITH LOW PRESSURE STEEL PIPE SYSTEMS

- Choose the *AutoTrip*[®] LFD Series EFV (Appliance branch line or Meter) using TABLE: C.1 which will supply the necessary capacity of the meter or appliance(s) it serves.
- 2. Using AutoTrip® Capacity Chart "Table SP-1AT AutoTrip® Steel Pipe Low Pressure" determine the size of steel pipe based on the AutoTrip® EFV selected in Step 1 and the appropriate sizing length. This size of steel pipe is designed to allow the AutoTrip® EFV to act as a safety shut-off valve in the event of a complete breakage of the main trunk line piping (Meter EFV) or of the downstream branch pipe line or flex connector rupture (Appliance Branch Line EFV).

C1.2.6 - LFD INSTALLATION INSTRUCTIONS

A. Installation of **AutoTrip®** LFD Series Meter Application excess flow valves downstream of the Gas Meter Outlet.

The **AutoTrip**® device can be installed downstream of the gas company meter and bypass tee outlet using standard pipe fittings and procedures. **AutoTrip** Meter Valves-LFD models must be installed within 5 degrees of the vertical position with the flow arrow pointing upward in the direction of flow. **NOTICE:** EFVs installed at the Meter are designed only to protect the main trunk line of like pipe size downstream of the EFV.

B. Installation of **AutoTrip®** LFD Series Branch Line excess flow valves at the Tee or Manifold connection of a Branch Line to an Appliance.

AutoTrip® Branch Line excess flow valves should be connected directly to the manifold outlet at the point between the manifold and the gas appliance lines. If there is no manifold, the valves could be located at the tee or fitting where the appliance drop attaches to the trunk line. **AutoTrip®** Branch Line excess flow valves must be installed in the vertical position (within 5 degrees) with the flow arrow pointing upward in the direction of flow.

C. Step-by-Step Installation Instructions

- 1. Prior to installing the **AutoTrip**® excess flow valve (EFV), turn gas supply off upstream of the EFV using appropriate shut-off valve. For a Meter EFV installation, this will be the main gas company shut-off valve.
- 2. Install **AutoTrip®** EFV into piping system at desired location using appropriate pipe fittings and tools. When using a thread sealant on pipe threads, do not allow the sealant, Teflon tape or any debris to enter the valve. Foreign matter can lodge in the valve and prevent proper operation.

- After AutoTrip® EFV is installed, insure all connections in the gas piping system are gas tight.
- 4. Re-open upstream shut-off valve SLOWLY to re-pressurize the system. NOTICE: If upstream shut-off valve is opened too quickly and an excess flow condition is created due to a pressure surge the AutoTrip® EFV may trip (close). If this occurs, reset the valve using the Resetting an AutoTrip® EFV instructions below.
- 5. Resetting an AutoTrip® EFV that has "tripped" (closed). Turn gas supply off upstream of the EFV using appropriate shut-off valve. For a Meter EFV installation, this will be the main gas company shut-off valve. Repair all damaged piping as required. Reset the AutoTrip® EFV by closing and sealing off all downstream connections.

Once the pressure in the upstream and downstream piping is equalized, the EFV will reset. This is evident by a "soft click" that can be heard from the **AutoTrip**® EFV. Typical time to reset is 1-2 minutes or of greater duration for larger diameter and/or longer lengths of downstream piping. Repeat Step 4. above to re-pressurize the system.

NOTICE: If there are any open connections (assure all appliance valves are shut) or leaks downstream of the *AutoTrip*® EFV, the EFV will not reset!

ACAUTION: Installer must assure at all times that any gas that may have escaped from the gas piping system as a result of a pipe break, valve testing, leakage, etc. is completely dissipated prior to opening appliance shut-offs and firing of appliances. Assure that there is no electrical or motorized equipment in use during this process.

SECTION C1.3 - *AUTOTRIP* AFD SERIES EXCESS FLOW VALVES FOR APPLIANCE CONNECTOR INLET APPLICATIONS

AFD SERIES PRODUCT SPECIFICATIONS

Material Specification:

Body Brass Nickel Plated

Seat Polyamide Valve Float Polyamide

Spring Stainless Steel

Operating Temperature: 32°F to 150°F

Operating Pressure: 0.18 PSI (5"wc) to 1/2 PSI

Maximum Bypass Flow: 10 CFH (Air equivalent)

For additional product information including Model Numbers, inlet/outlet thread connections, Maximum load capacity and flow rates, & application please reference Table: C.2.




FIGURE: C-2

C1.3.1 - APPLICATION AND SELECTION OF *AUTOTRIP®* AFD SERIES EXCESS FLOW VALVES

- Application. Determine the Type of EFV based on the application – for the AFD Series the application will be to install the EFV at the inlet to a flexible appliance connector (See Figure: C-2).
- AFD Series EFV Model Selection.
 From TABLE: C.2, select the appropriate
 AutoTrip® AFD EFV based on:
 - A. The BTU/hr load capacity of the appliance it serves. (NOTICE: AutoTrip® Appliance Connector EFVs will serve only the appliance for which the flexible appliance connector is installed to). The TOTAL BTU/hr load capacity of the appliance should be equal to or less than the Maximum Load Capacity (BTU/hr) value of the AutoTrip® AFD EFV in TABLE: C.2.

- B. Inlet side NPT and Outlet side SAE Flare connections, Nominal ID of the appliance connector being used.
- 3 Gas Piping System Sizing with an *AutoTrip*[®] AFD Series excess flow valve(s).

AutoTrip® excess flow valves must be sized properly for the gas piping system in which they are installed. When installing **AutoTrip**® excess flow valves within a fuel gas piping system, the user must assure that:

A. The **AutoTrip®** excess flow valve will close upon a complete breakage or rupture of the gas appliance connector piping downstream of the EFV. It is recommended that the installer conduct tests on the gas piping system to ensure the EFV(s) will function as intended. Note: Tests should be performed in accordance with all applicable local and national codes.

B. The addition of the EFV will allow the appliance to which the EFV serves to operate properly without the undue loss of pressure. It is recommended that the installer run all appliances with the EFV(s) installed to assure proper operation.

Based on the upstream gas piping system sizing and downstream appliance connector sizing, the user must assure that the addition of the AFD Series EFV will not reduce the inlet pressure to the appliance below the minimum required for proper operation.

NOTICE: AFD Series EFVs will add a Nominal 0.5 "wc pressure drop when operating at the Maximum Load Capacity (BTU/hr) of the EFV.

C1.3.2 INSTALLATION INSTRUCTIONS

A. Installation of **AutoTrip®** Appliance Connector excess flow valves to the Flare connection of a Flexible Appliance Connector. **AutoTrip®** Appliance Connector excess flow valves should be connected to the SAE Flare connection on the inlet side of an approved flexible appliance connector. **AutoTrip®** Appliance Connector excess flow valves are designed for multipoise installation so they may be installed in the vertical, horizontal, or any angle from the horizontal, positions. **NOTICE:** Appliance Connector **AutoTrip®** excess flow valves are designed to protect against a complete breakage or pull-out of the flexible appliance connector only. This device will not protect gas piping upstream of the device.

B. Step-by-Step Installation Instructions

1. Prior to installing the **AutoTrip**® excess flow valve (EFV), turn gas supply off upstream of the EFV using appropriate shut-off valve. If the appliance shut-off valve is installed upstream of the appliance connector, this valve may be used as the shut-off.

TABLE: C.2

AutoTrip® "AFD" Series Appliance Connector Inlet Excess Flow Valves Application Data

EFV Type - Application	OmegaFlex <i>AutoTrip</i> P/N	Fits Nominal Appliance Connector ID Size	Mounting Position	Inlet Thread Connection(s)	Outlet Thread Connection(s)	Maximum Load Capacity (BTU/hr)	Nominal Closure Flow Rate (SCFH)
Appliance connector	FGP-AFD-80	1/4"	Multipoise	1/2" M-NPT & 3/8" F-NPT	3/8" SAE Flare	80,000	110
Appliance connector	FGP-AFD-100A	3/8"	Multipoise	1/2" M-NPT & 3/8" F-NPT	1/2" SAE Flare	100,000	175
Appliance connector	FGP-AFD-130A	1/2"	Multipoise	1/2" M-NPT & 3/8" F-NPT	5/8" SAE Flare	130,000	200
Appliance connector	FGP-AFD-130B	1/2"	Multipoise	3/4" M-NPT & 1/2" F-NPT	5/8" SAE Flare	130,000	200

<u>Notes:</u>

- 1) Flow Rates given for 0.60 Specific Gravity Natural Gas with an Avg. Heating Value of 1000 BTU / cubic foot.
- 2) To convert Maximum Load Capacity value to BTU/hr Propane (1.52 Specific Gravity, 2520 BTU / cubic foot), multiply Natural Gas Value by 1.583.
- 3) To convert SCFH Nominal Closure Flow Rate to SCFH Propane, multiply Natural gas Value above by 0.628
- 4) Abbreviations: "w.c. = inches water column.
 - SCFH = Standard Cubic Feet per Hour.

- 2. Install **AutoTrip®** EFV at the inlet to the flexible appliance connector using appropriate pipe fittings and tools. When using a thread sealant on pipe threads, do not allow the sealant, Teflon tape or any debris to enter the valve. Foreign matter can lodge in the valve and prevent proper operation.
- After **AutoTrip®** EFV is installed, insure all connections in the gas piping system are gas tight.
- 4. Re-open upstream shut-off valve SLOWLY to re-pressurize the system.

 NOTICE: If upstream shut-off valve is opened too quickly and an excess flow condition is created due to a pressure surge the *AutoTrip*® EFV may trip (close). If this occurs, reset the valve using the Resetting an *AutoTrip*® EFV instructions below.
- has "tripped" (closed). Repair all damaged piping as required. Reset the AutoTrip® EFV by closing and sealing off all downstream connections. Once the pressure in the downstream piping is equalized, valve will reset. This is evident by a "soft click" that can be heard from the AutoTrip® EFV. Typical time to reset is 15-30 seconds or of greater duration for larger diameter or longer length appliance connectors.

NOTICE: If there are any open connections (assure all appliance valves are shut) or leaks downstream of the *AutoTrip*® EFV, valve will not reset!

NOTICE: Resetting **AutoTrip®** Appliance Connector EFVs with appliance shut-off valve installed UPSTREAM of the EFV – These valves may be reset by closing and SLOWLY re-opening the upstream appliance shut-off valve without "tripping" the EFV.

CAUTION: Installer must assure at all times that any gas that may have escaped from the gas piping system as a result of a pipe break, valve testing, leakage, etc. is completely dissipated prior to opening appliance shut-offs and firing of appliances. Assure that there is no electrical or motorized equipment in use during this process.

SECTION - C1.4 GASBREAKER® EXCESS FLOW VALVES

GasBreaker® excess flow valves (EFV) protect against residential and commercial gas line breaks. GasBreakers work in conjunction with *CounterStrike®*, other brands of CSST or rigid gas piping at the gas meter, second stage regulator, the appliance branch line or manifold connection. GasBreaker EFVs are available in several different sizes and load capacity ratings.

- The GasBreaker EFV can be installed downstream of the gas company meter and bypass tee outlet using standard pipe fittings and procedures. GasBreaker EFVs must be installed within 5 degrees of the vertical position with the flow arrow pointing upward in the direction of flow.
- 2. Use Table: C.4 for GasBreaker EFV capacity information and to determine the equivalent **AutoTrip**® LFD excess flow valve. For sizing of the **TracPipe® CounterStrike®** CSST system with GasBreaker EFV's utilize the equivalent **AutoTrip®** capacity chart data.

Determine TracPipe CounterStrike CSST size based upon the AutoTrip "LFD" Series EFV Chosen and Length of CSST Run TABLE N-1AT TRACPIPE® AUTOTRIP® - (Low Pressure System)

Standard Low Pressure 0.5 psi or less (7 in w.c.)—Piping Pressure Drop 0.5 in w.c.

Distance Range - Length in Feet

AutoTrip P/N	Max. Capacity BTU	0-10 Feet	<15	<20	<25	<40	<50	09>	06>		<100 <150	<200	<200 <250	<300
Appliance Branch Line Series														
FGP-LFD-70	70,000	1/2"	1/2"	3/4"	3/4"	3/4"	3/4"	3/4"	3/4"		-		Ŧ-	1-1/4"
FGP-LFD-125	125,000	3/4"	3/4"	3/4"	3/4"	1	1	1"	1"	1-1/4"	1-1/4"	1-1/2"	1-1/2"	1-1/2"
Meter / Line Series														
FGP-LFD-275A or -275B	275,000	1,,	1	1-1/4"	1-1/4"	1-1/4"	1-1/2"	1-1/2"	1-1/2"	1-1/2"	1-1/4" 1-1/4" 1-1/4" 1-1/2" 1-1/2" 1-1/2" 1-1/2" 1-1/2"	1-1/5"	2	2"
FGP-LFD-375	375,000	1	1-1/4"	1-1/4" 1-1/4"	1-1/5"	1-1/5"	1-1/5"	1-1/5"	1-1/2"	1-1/2"	5	7	2	2"
FGP-LFD-500	200,000	1-1/4"	1-1/2"	1-1/2" 1-1/2"	1-1/5"	1-1/2"	1-1/2"	1-1/2"	2"		2"	7	2	2

NOTE: If you are installing a brand of CSST other than TracPipe CounterStrike, size each run to supply the Max Capacity of the AutoTrip device instead of the capacity of appliances on that run.

Determine TracPipe CounterStrike CSST size based upon the AutoTrip "LFD" Series EFV Chosen and Length of CSST Run TABLE N-3AT TRACPIPE® AUTOTRIP® - (Dual Pressure System-8 in w.c. -Regulator outlet @ manifold) Regulator Outlet for 2-psi system (8 in w.c. with a Piping Pressure Drop of 3 in w.c.)

Distance Range - Length in Feet

GasBreaker P/N	Max. Capacity BTU	0-10 Feet	\ 5	²⁰	~25	<30	<40	<50	09>	08 >	06>	<100	<150	<200	<250	<300
Appliance Branch Line Series																
FGP-LFD-70	70,000	3/8"	3/8"	3/8"	1/2"	1/2"	1/2"	1/5"	1/2"	1/2"	1/2"	7/1	3/4"	3/4"	3/4"	3/4"
FGP-LFD-125	125,000	1/2"	1/2"	1/2"	1/5"	1/2"	3/4"	3/4"	3/4"	3/4"	3/4"	3/4"	3/4"	1		<u>_</u>
Meter / Line Series																
FGP-LFD-275A or -275B	275,000	3/4"	3/4"	3/4"	3/4"	3/4"	1"	1"	1"	1"	1"	"L	1-1/4"	1-1/4"	1-1/4"	1-1/2"
FGP-LFD-375	375,000	3/4"	3/4"	1"	1"	1	1"	1	1"	1-1/4"	1-1/4"	1-1/4"	1-1/2"	1-1/5"	1-1/2"	1-1/2"
FGP-LFD-500	500,000	1"	1"	1"	1"	1	1-1/4"	1-1/4"	1-1/4"	1-1/4"	1-1/2"	1-1/2"	1-1/2"	1-1/2"	1-1/2"	1-1/2"

NOTE: If you are installing a brand of CSST other than TracPipe CounterStrike, size each run to supply the Max Capacity of the AutoTrip device instead of the capacity of appliances on that run.

TABLE N-5AT TRACPIPE® AUTOTRIP® - (2-PSI system)

Determine TracPipe CounterStrike CSST size based upon the AutoTrip "LFD" Series EFV Chosen and Length of CSST Run Meter Outlet for 2-PSI system (Elevated Pressure) - Piping Pressure Drop 1-PSI

Distance Range - Length in Feet

GasBreaker P/N	Max. Capacity														
	BTU	0-10 Feet	~ 25	<30	<40	<20	<75	08	700	<120	<200	<250	<300	<400	<200
Meter / Line Series															
FGP-LFD-275A or -275B	275,000	3/8"	1/5"	1/2"	1/2"	1/2"	3/4"	3/4"	3/4"	3/4"	3/4"	3/4"	1"	1"	1
FGP-LFD-375	375,000	1/2"		1/2"	3/4"	3/4"	3/4"	3/4"	3/4"	3/4"	1"	1"	1"	1"	1"
FGP-LFD-500	200,000	1/2"	3/4"	3/4"	3/4"	3/4"	3/4"	3/4"	<u>-</u>		<u>-</u>	<u>-</u>	<u>-</u>	1-1/4"	1-1/4"

NOTE: If you are installing a brand of CSST other than TracPipe CounterStrike, size each run to supply the Max Capacity of the AutoTrip device instead of the capacity of appliances on that run.

TABLE SP-1AT TRACPIPE® AUTOTRIP® - STEEL PIPE LOW PRESSURE

Determine TracPipe® CounterStrike® pipe size based upon the AutoTrip "LFD" Series EFV Chosen and Length of Run Standard Low Pressure 0.5 PSI or less (7 in w.c.)—Piping Pressure Drop 0.5 in w.c.

Distance Range - Length in Feet

_				_	_	_	_	_	_	_	
		<300		1"	1-1/4"			1-1/2	2"	2"	
		<250		1"	1-1/4"			1-1/2	1-1/2"	2"	
		<200		3/4"	1			1-1/4"	1-1/2"	2"	
		<150		3/4"	1			1-1/4"	1-1/2"	1-1/2"	
		<125		3/4"	1			1-1/4"	1-1/2"	1-1/2"	
		<100		3/4"	1			1-1/4"	1-1/4"	1-1/2"	
		06>		3/4"	1			1-1/4"	1-1/4"	1-1/2"	
		<70		3/4"	3/4"			1-1/4"	1-1/4"	1-1/2"	
		09>		3/4"	3/4"			1-1/4"	1-1/4"	1-1/4"	
		<50		1/2"	3/4"			1"	1-1/4"	1-1/4"	
		<40		1/2"	3/4"			1"	1-1/4"	1-1/4"	
		<30		1/2"	3/4"			1"	1"	1-1/4"	
		<20		1/2"	3/4"			1"	1"	1-1/4"	
		0-10 Feet		1/2" Pipe	1/2" Pipe			3/4" Pipe	1" Pipe	1" Pipe	
Max	Capacity	ВТО		70,000	125,000			275,000	375,000	500,000	
GasBreaker	P/N		Appliance Branch Line Series	FGP-LFD-70	FGP-LFD-125		Meter / Line Series	FGP-LFD-275A or -275B	FGP-LFD-375	FGP-LFD-500	

PROPANE - TracPipe® AutoTrip® - "LFD" Series Excess Flow Valves TABLE 3.3

AutoTrip FI	ow Rates in 1	.52 S.G. / 252	AutoTrip Flow Rates in 1.52 S.G. / 2520 BTU/cu.ft. PROPANE	ROPANE		
Device		Btu/hr			SCFH	
	Typ. Load	Max Load	Max Load Nom. Closing	Typ. Load	Max Load	Nom. Closing
Appliance Branch Line Series						
FGP-LFD-70	110,779	110,779	158,256	44	44	63
FGP-LFD-125	189,907	197,820	276,948	75	62	110
Meter / Line Series						
FGP-LFD-275A	197,820	435,204	561,809	79	173	223
FGP-LFD-275B	276,948	435,204	561,809	110	173	223
FGP-LFD-375	284,861	593,460	751,716	113	236	298
FGP-LFD-500	284,861	791,280	1,084,054	113	314	430

TABLE P-1AT TRACPIPE® AUTOTRIP® - (Propane Low Pressure System 11 in w.c.)
Determine TracPipe CounterStrike CSST size based upon the AutoTrip "LFD" Series EFV Chosen and Length of CSST Run Standard Propane Low Pressure (11 in w.c.)—Piping Pressure Drop 0.5 in w.c.

Distance Range - Length in Feet

AutoTrip P/N	Max. Capacity BTU	0-10 Feet	<15	<20	<25	<40	<50	<60	<90	<100	<150	<200	<250	<300
Appliance Branch Line Series														
FGP-LFD-70	110,779	1/2"	1/2"	3/4"	3/4"	3/4"	3/4"	3/4"	1"	1"	1"	1"	1"	1-1/4"
FGP-LFD-125	197,820	3/4"	3/4"	3/4"	3/4"	1"	1"	1	1"	1-1/4"	1-1/4"	1-1/2"	1-1/2"	1-1/2"
Meter / Line Series														
FGP-LFD-275A or -275B	435,204	1"	1"	1-1/4"	1-1/4"	1-1/4"	1-1/2"	1-1/2"	1-1/2"	1-1/2"	1-1/2"	1-1/2"	2"	2"
FGP-LFD-375	593,460	1"	1-1/4"	1-1/4"	1-1/4"	1-1/2"	1-1/2"	1-1/2"	1-1/2"	1-1/2"	2"	2"	2"	2"
FGP-LFD-500	791,280	1-1/4"	1-1/2"	1-1/2"	1-1/2"	1-1/2"	1-1/2"	1-1/2"	2"	2"	2"	2"	2"	2"

NOTE: If you are installing a brand of CSST other than TracPipe CounterStrike, size each run to supply the Max Capacity of the AutoTrip device instead of the capacity of appliances on that run.

TABLE C.4 TracPipe® AUTOTRIP® - GasBreaker Equivalency Chart

EFV Type Application	Maximum Load Capacity(Btu/hr)	Auto Trip P/N	Auto Trip Inlet and Outlet Thread Connection(s)	Equivalent GasBreaker P/N	GasBreaker Inlet and Outlet Thread Connection
Appliance Branch Line	70,000	FGP-LFD-70	3/4" M-NPT & 1/2" F-NPT	FGP-GB090-075	3/4" M-NPT
Appliance Branch Line	125,000	FGP-LFD-125	3/4" M-NPT & 1/2" F-NPT	FGP-GB150-075	3/4" M-NPT
Meter / Branch Line	275,000	FGP-LFD-275A	3/4" M-NPT & 1/2" F-NPT	FGP-GB300-075	3/4" M-NPT
Meter / Branch Line	275,000	FGP-LFD-275B	1" M-NPT & 3/4" F-NPT	FGP-GB300-100	1" M-NPT
Meter / Branch Line	375,000	FGP-LFD-375	1" M-NPT & 3/4" F-NPT	FGP-GB400-100	1" M-NPT
Meter / Branch Line	500,000	FGP-LFD-500	1-1/4" M-NPT & 1" F-NPT	FGP-GB600-100	1" M-NPT

NOTE: For additional information regarding the AutoTrip or GasBreaker excess flow valves, please contact OmegaFlex at 800-671-8622.

FIGURE C-3
Pressure Drop across TracPipe® AutoTrip® - "LFD" Series EFV at given Flow Rates 550 200 450 400 350 Flow (CFH 0.6 S.G. Nat. Gas) 150 100 20 2.00 0.00 0.40 1.80 1.60 1.40 0.60 0.20

NOTES:	

NOTES:	

NOTES:	

For more information about TracPipe®CounterStrike® visit: tracpipe.com

For safety issues concerning gas piping systems visit: csstfacts.org



TracPipe® #CounterStrike® Flexible Gas Piping by OmegaFlex.

OmegaFlex[®]

451 Creamery Way, Exton, PA 19341-2509 1-800-671-8622 Fax: 610-524-7282 www.omegaflex.com